


**VACON NX**  
AC DRIVES

**LIQUID-COOLED DRIVES  
USER MANUAL**



**VACON**  
DRIVEN BY DRIVES



**INDEX**

Document ID: DPD00887A  
 Revision release date: 16.02.2012

<b>1. SAFETY .....</b>	<b>7</b>
1.1. Danger .....	7
1.2. Warnings .....	8
1.3. Cautions.....	9
1.4. Earthing and earth fault protection .....	9
1.5. Running the motor .....	10
<b>2. EU DIRECTIVE .....</b>	<b>11</b>
2.1. CE marking .....	11
2.2. EMC directive.....	11
2.2.1. General.....	11
2.2.2. Technical criteria .....	11
2.2.3. Vacon frequency converter EMC classification .....	11
2.2.3.1. IT networks .....	12
2.2.4. Manufacturer's declaration of conformity.....	12
<b>3. RECEIPT OF DELIVERY.....</b>	<b>13</b>
3.1. Type designation code.....	13
3.2. Storage and shipping .....	13
3.3. Maintenance .....	13
3.4. Warranty .....	14
<b>4. TECHNICAL DATA.....</b>	<b>15</b>
4.1. Introduction .....	15
4.2. Power ratings .....	18
4.2.1. Frequency converters .....	18
4.2.1.1. Vacon NX Liquid-Cooled Frequency Converter – Mains voltage 400–500 VAC .....	18
4.2.1.2. Vacon NX Liquid-Cooled Frequency Converter – Mains voltage 525–690 VAC .....	20
4.2.2. Inverter units.....	22
4.2.2.1. Vacon NX Liquid-Cooled Inverter Unit – Mains voltage 465–800 VDC.....	22
4.2.2.2. Vacon NX Liquid-Cooled Inverter Unit – Mains voltage 640–1100 VDC.....	24
4.3. Technical data .....	25
<b>5. INSTALLATION .....</b>	<b>29</b>
5.1. Mounting.....	29
5.1.1. Lifting the drive .....	29
5.1.2. NX Liquid-Cooled dimensions .....	32
5.1.2.1. Drives consisting of one module .....	32
5.1.2.2. Drives consisting of several modules.....	38
5.2. Cooling.....	45
5.2.1. Condensation .....	51
5.2.2. Cooling system connections .....	52
5.2.2.1. Pressure losses .....	54
5.2.2.2. Installation of flow switch.....	56

---

5.3.	Drive derating .....	58
5.4.	Input chokes .....	59
5.4.1.	Installation of input chokes.....	61
<b>6.</b>	<b>ELECTRICAL CABLING AND CONNECTIONS .....</b>	<b>64</b>
6.1.	Power unit .....	64
6.1.1.	Power connections.....	64
6.1.1.1.	Mains cable .....	64
6.1.1.2.	Motor cable .....	64
6.1.1.3.	Motor cable data .....	65
6.1.1.4.	Mains cable data for frequency converters.....	67
6.1.2.	Drive protection – Fuses .....	70
6.1.3.	Fuse sizes.....	70
6.1.3.1.	Frequency converters.....	71
6.1.3.2.	Fuse sizes, inverters .....	74
6.1.3.3.	Fuse sizes, Active Front End units (AC supply) .....	76
6.1.4.	Cable installation instructions.....	78
6.1.5.	Supply busbars for inverter units .....	80
6.1.6.	Installation space .....	81
6.1.7.	Earthing of power unit .....	81
6.1.8.	Installation of ferrite rings (option) on the motor cable.....	82
6.1.9.	Cable installation and the UL standards .....	82
6.1.10.	Cable and motor insulation checks .....	83
6.2.	Control unit.....	84
6.2.1.	Control board power-up .....	86
6.2.2.	Control connections .....	87
6.2.2.1.	Control cables .....	88
6.2.2.2.	Galvanic isolation barriers.....	88
6.2.3.	Control terminal signals .....	89
6.2.3.1.	Digital input signal inversions .....	90
6.2.3.2.	Jumper selections on the OPT-A1 basic board.....	91
6.2.4.	Control unit mounting box .....	93
6.2.4.1.	Installing the control unit mounting box .....	93
6.3.	Internal connections .....	95
6.3.1.	Connections between Power Unit ASIC and Driver Boards .....	95
6.3.2.	Connections between power unit ASIC and the control unit.....	98
6.3.2.1.	Connections with round cable .....	98
6.3.2.2.	Connections with optical cable .....	98
6.3.3.	Connections between mains device and inverter power module .....	100
<b>7.</b>	<b>CONTROL KEYPAD .....</b>	<b>103</b>
7.1.	Indications on the Keypad display.....	103
7.1.1.	Drive status indications .....	103
7.1.2.	Control place indications .....	104

7.1.3.	Status LEDs (green – green – red) .....	104
7.1.4.	Text lines .....	104
7.2.	Keypad push-buttons .....	105
7.2.1.	Button descriptions.....	105
7.3.	Navigation on the control keypad .....	106
7.3.1.	Monitoring menu (M1).....	107
7.3.2.	Parameter menu (M2).....	109
7.3.3.	Keypad control menu (M3).....	110
7.3.3.1.	Selection of control place .....	111
7.3.3.2.	Keypad reference .....	111
7.3.3.3.	Keypad direction .....	111
7.3.3.4.	Stop button activated .....	112
7.3.4.	Active faults menu (M4) .....	112
7.3.4.1.	Fault types.....	113
7.3.4.2.	Fault codes.....	114
7.3.4.3.	Fault time data record .....	119
7.3.5.	Fault history menu (M5).....	120
7.3.6.	System menu (M6) .....	121
7.3.6.1.	Language selection .....	123
7.3.6.2.	Application selection.....	123
7.3.6.3.	Copy parameters.....	124
7.3.6.4.	Parameter comparison.....	126
7.3.6.5.	Security .....	127
7.3.6.6.	Keypad settings.....	129
7.3.6.7.	Hardware settings .....	130
7.3.6.8.	System info.....	131
7.3.7.	Expander board menu (M7).....	134
7.4.	Further keypad functions .....	135
<b>8.</b>	<b>COMMISSIONING .....</b>	<b>136</b>
8.1.	Safety .....	136
8.2.	Commissioning of the frequency converter .....	137
<b>9.</b>	<b>FAULT TRACING .....</b>	<b>139</b>
9.1.	Fault codes .....	139
9.2.	Load test with motor .....	145
9.3.	DC link test (without motor).....	146
<b>10.</b>	<b>BRAKE CHOPPER UNIT (NXB) .....</b>	<b>147</b>
10.1.	Introduction .....	147
10.2.	Type designation code .....	147
10.3.	Diagrams .....	147
10.3.1.	NXB Brake Chopper Unit block diagram .....	147
10.3.2.	NXB topologies and connection .....	148
10.4.	Brake chopper unit technical data.....	149

10.5.	BCU power ratings .....	152
10.5.1.	Vacon NXB; DC voltage 460–800V .....	152
10.5.2.	Vacon NXB; DC voltage 640–1100V .....	153
10.6.	Vacon brake resistors and brake chopper dimensioning.....	154
10.6.1.	Braking energy and losses .....	154
10.6.2.	Braking power and resistance, mains voltage 380–500Vac/600–800Vdc .....	155
10.6.3.	Braking power and resistance, mains voltage 525–690Vac/840–1100Vdc .....	157
10.7.	Brake chopper unit – Fuse selection .....	159
<b>11.</b>	<b>APPENDICES .....</b>	<b>161</b>

---

**AT LEAST THE FOLLOWING STEPS OF THE *START-UP QUICK GUIDE* MUST BE PERFORMED DURING THE INSTALLATION AND COMMISSIONING.**

**IF ANY PROBLEMS OCCUR, PLEASE CONTACT YOUR LOCAL DISTRIBUTOR.**

### **Start-up Quick Guide**

1. Check that the delivery corresponds to your order, see Chapter 3.
2. Before taking any commissioning actions read carefully the safety instructions in Chapter 1.
3. Check the size of the motor cable, mains cable, mains fuses and check the cable connections, read Chapters 6.1.1.1 – 6.1.2.
4. Follow the installation instructions.
5. Control connections are explained in Chapter 6.2.2.
6. Ensure the adequate pressure and flow of the cooling agent you are using. See Chapter 5.2.
7. If the Start-Up wizard is active, select the language of the keypad and the application you want to use and confirm by pressing the *Enter button*. If the Start-Up wizard is not active, follow the instructions 7a and 7b.
  - 7a. Select the language of the keypad from the Menu M6, page 6.1. Instructions on using the keypad are given in Chapter 7.
  - 7b. Select the application you want to use from the Menu M6, page 6.2. Instructions on using the keypad are given in Chapter 7.
8. All parameters have factory default values. In order to ensure proper operation, check the rating plate data for the values below and the corresponding parameters of parameter group G2.1.
  - nominal voltage of the motor
  - nominal frequency of the motor
  - nominal speed of the motor
  - nominal current of the motor
  - motor cosφAll parameters are explained in the All in One Application Manual.
9. Follow the commissioning instructions, see Chapter 8.
10. The Vacon NX Liquid-Cooled Frequency Converter is now ready for use.

**Vacon Plc is not responsible for the use of its products against instructions.**

## **ABOUT THE VACON NX LIQUID-COOLED FREQUENCY CONVERTERS AND INVERTERS USER'S MANUAL**

Congratulations for choosing the Smooth Control provided by Vacon NX\_W Liquid Cooled drives!

The User's Manual will provide you with the necessary information about the installation, commissioning and operation of Vacon NX Liquid-Cooled drives. We recommend that you carefully study these instructions before powering up the frequency converter for the first time.

This manual is available in both paper and electronic editions. We recommend you to use the electronic version if possible. If you have the electronic version at your disposal you will be able to benefit from the following features:

The manual contains several links and cross-references to other locations in the manual which makes it easier for the reader to move around in the manual, to check and find things faster.

The manual also contains hyperlinks to web pages. To visit these web pages through the links you must have an internet browser installed on your computer.

## 1. SAFETY



**ONLY A COMPETENT ELECTRICIAN MAY CARRY OUT THE ELECTRICAL INSTALLATION!**

	= DANGEROUS VOLTAGE!
	= GENERAL WARNING

### 1.1 DANGER



The components of the power unit of the frequency converter are live when Vacon NX Liquid-Cooled drive is connected to mains potential. Coming into contact with this voltage is extremely dangerous and may cause death or severe injury.



The motor terminals U, V, W and the DC-link/brake resistor terminals are live when Vacon NX Liquid-Cooled drive is connected to mains, even if the motor is not running.



After disconnecting the frequency converter from the mains, wait until the indicators on the keypad go out (if no keypad is attached see the indicators on the cover). Wait 5 more minutes before doing any work on Vacon NX Liquid-Cooled drive connections. Do not touch the enclosure before this time has expired. Always ensure absence of voltage before starting any electrical work!



The control I/O-terminals are isolated from the mains potential. However, the relay outputs and other I/O-terminals may have a dangerous control voltage present even when Vacon NX Liquid-Cooled drive is disconnected from mains.



Before connecting the NX Liquid-Cooled drive to mains, ensure the functionality of the coolant circulation and check the circulation for possible leaks.



Before connecting the drive to mains make sure that the enclosure door is closed.



If Vacon NX\_ is disconnected from mains while running the motor, it remains live if the motor is energized by the process. In this case the motor functions as a generator feeding energy to the frequency converter.

## 1.2      WARNINGS



The Vacon NX Liquid-Cooled drive is meant for fixed installations only.



Do not perform any measurements when the frequency converter is connected to the mains. Prior to measurements on the motor or the motor cable, disconnect the motor cable from the frequency converter.



The earth leakage current of Vacon NX\_ frequency converters exceeds 3.5mA AC. According to standard EN61800-5-1, a reinforced protective ground connection must be ensured. See chapter 1.4.



If the frequency converter is used as a part of a machine, the machine manufacturer is responsible for providing the machine with a main switch (EN 61800-5-1).



Only spare parts delivered by Vacon can be used.



After the power-up, power brake or fault reset the motor will start immediately if the start signal is active, unless the pulse control for Start/Stop logic has been selected. Furthermore, the I/O functionalities (including start inputs) may change if parameters, applications or software are changed. Disconnect, therefore, the motor if an unexpected start can cause danger.



Prior to measurements on the motor or the motor cable, disconnect the motor cable from the frequency converter.

### 1.3 CAUTIONS

	<p>Do not perform any voltage withstand tests on any part of Vacon NX_. There is a certain procedure according to which the tests shall be performed. Ignoring this procedure may result in damaged product.</p> <p>Do not touch the components on the circuit boards. Static voltage discharge may damage the components.</p>
	<p>If a fault protection relay is used , it must be of at least type B, preferably B+ ( according to EN 50178) , with a trip level of 300 mA. This is for fire protection, not for touch protection in grounded systems.</p>

### 1.4 EARTHING AND EARTH FAULT PROTECTION

The Vacon NX Liquid-Cooled frequency converter must always be earthed with an earthing conductor connected to the earthing terminal  . See page 80.

The earth leakage current of Vacon NX\_ exceeds 3.5mA AC. According to EN61800-5-1, one or more of the following conditions for the associated protective circuit shall be satisfied:

- a. The protective conductor shall have a cross-sectional area of at least 10 mm<sup>2</sup> Cu or 16 mm<sup>2</sup> Al, through its total run.
- b. Where the protective conductor has a cross-sectional area of less than 10 mm<sup>2</sup> Cu or 16 mm<sup>2</sup> Al, a second protective conductor of at least the same cross-sectional area shall be provided up to a point where the protective conductor has a cross-sectional area not less than 10 mm<sup>2</sup> Cu or 16 mm<sup>2</sup> Al.
- c. Automatic disconnection of the supply in case of loss of continuity of the protective conductor.

The cross-sectional area of every protective earthing conductor which does not form part of the supply cable or cable enclosure shall, in any case, be not less than:

- 2,5mm<sup>2</sup> if mechanical protection is provided or
- 4mm<sup>2</sup> if mechanical protection is not provided.

The earth fault protection inside the frequency converter protects only the converter itself against earth faults in the motor or the motor cable. It is not intended for personal safety.

Due to the high capacitive currents present in the frequency converter, fault current protective switches may not function properly.

## 1.5 RUNNING THE MOTOR

### *Warning symbols*

For your own safety, please pay special attention to the instructions marked with the following symbols:

	= <i>Dangerous voltage</i>
	= <i>General warning</i>
	= <i>Hot surface – Risk of burn</i>

### *Motor run check list*



Before starting the motor, check that it is mounted properly and ensure that the machine connected to the motor allows the motor to be started.



Set the maximum motor speed (frequency) on the frequency converter according to the motor and the machine connected to it.



Before reversing the motor make sure that this can be done safely.



Make sure that no power correction capacitors are connected to the motor cable.



Make sure that the motor terminals are not connected to mains potential.



Before the NX\_W Liquid Cooled drive can be used to control the motor, the proper functioning of the liquid-cooling system must be ensured.

## 2. EU DIRECTIVE

### 2.1 CE MARKING

The CE marking on the product guarantees the free movement of the product within the EEA (European Economic Area).

Vacon NX frequency converters carry the CE label as a proof of compliance with the Low Voltage Directive and the Electro Magnetic Compatibility Directive (EMC). The company SGS FIMKO has acted as the Competent Body.

### 2.2 EMC DIRECTIVE

#### 2.2.1 GENERAL

The EMC Directive provides that the electrical apparatus must not excessively disturb the environment it is used in, and, on the other hand, it shall have an adequate level of immunity toward other disturbances from the same environment.

The compliance of Vacon NX Liquid-Cooled frequency converters with the EMC directive is verified with Technical Construction Files (TCF) checked and approved by SGS FIMKO, which is a Competent Body. The Technical Construction Files are used to authenticate the conformity of Vacon frequency converters with the Directive because such a large-sized product family is impossible to be tested in a laboratory environment and because the combinations of installation vary greatly.

#### 2.2.2 TECHNICAL CRITERIA

Our basic idea was to develop a range of frequency converters offering the best possible usability and cost-efficiency. EMC compliance was a major consideration from the outset of the design.

Vacon NX Liquid-Cooled frequency converters are marketed throughout the world, a fact which makes the EMC requirements of customers different. As far as the immunity is concerned, all Vacon NX Liquid-Cooled frequency converters are designed to fulfil even the strictest requirements.

#### 2.2.3 VACON FREQUENCY CONVERTER EMC CLASSIFICATION

Vacon NX Liquid-Cooled frequency converter and inverter modules delivered from factory fulfil all EMC immunity requirements (standard EN 61800-3).

The basic liquid cooled modules do not have any inherent emission filtering. If filtering is needed and a certain EMC emission level is required, external RFI filters must be used.

Class N:

The NX Liquid-Cooled drives of this class do not provide EMC emission protection. This kind of drives are mounted in enclosures. External EMC filtering is usually required to fulfil the EMC emission requirements.

Class T:

The T-class converters have a smaller earth leakage current and are intended to be used with IT supplies only. If they are used with other supplies no EMC requirements are complied with.

Warning: This is a product of the restricted sales distribution class according to IEC 61800-3. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### 2.2.3.1 IT networks

The grounding of input capacitors made by default with the grounding screw at terminal X41 of the bus board in all drives is imperative in all variations of TN/TT networks. Should a drive originally purchased for TN/TT networks be used in an IT network, the screw at X41 must be removed. It is strongly recommended that this be done by Vacon personnel. Ask your local distributor for more information.

### **2.2.4 MANUFACTURER'S DECLARATION OF CONFORMITY**

The following pages present the Manufacturer's Declarations of Conformity assuring the compliance of Vacon frequency converters with the EMC-directives.



#### **EC DECLARATION OF CONFORMITY**

We

**Manufacturer's name:** Vacon Oyj

**Manufacturer's address:** P.O.Box 25  
Runkorintie 7  
FIN-65381 Vaasa  
Finland

hereby declare that the product

**Product name:** Vacon NX Liquid-Cooled Frequency converter

**Model designation:** Vacon NX Liquid-Cooled 0016 5.... to 4140 5....  
Vacon NX Liquid-Cooled 0170 6.... to 3100 6....

has been designed and manufactured in accordance with the following standards:

**Safety:** EN 60204-1:2006+A1:2009 (as relevant)

EN 61800-5-1:2007

**EMC (immunity):** EN61800-3:2004 (only immunity)

and conforms to the relevant safety provisions of the Low Voltage Directive (2006/95/EC) and EMC Directive 2004/108/EC.

It is ensured through internal measures and quality control that the product conforms at all times to the requirements of the current Directive and the relevant standards.

In Vaasa, 24th of March, 2011

Vesa Laisi  
President

The year the CE marking was affixed: 2002

### 3. RECEIPT OF DELIVERY

The standard delivery of Vacon liquid-cooled drives includes all or part of the following components:

- power unit
- control unit
- main line connecting hoses and conduits (1.5m) + aluminium adapters for Ch5-Ch74
- Tema 1300 series fast connectors for Ch3-Ch4
- choke (not DC-fed inverters, type code I)
- control unit mounting kit
- optic fibre & cable set (1.5m) for control unit; Optic sets in different lengths also available
- optic fibre cable set for 2\*CH64/CH74: 1.8m/11 fibres (Power module 1) and 3.8m/8 fibres (Power module 2)


Vacon liquid-cooled frequency converters have undergone scrupulous tests and quality checks at the factory before they are delivered to the customer. However, after unpacking the product, check that no signs of transport damages are to be found on the product and that the delivery is complete (compare the type designation of the product to the code).

Should the drive have been damaged during the shipping, please contact primarily the cargo insurance company or the carrier.

If the delivery does not correspond to your order, contact the supplier immediately.

#### 3.1 TYPE DESIGNATION CODE

The type designation code for the NX Liquid-Cooled drives is presented below.



### 3.2 STORAGE AND SHIPPING

If the frequency converter is to be kept in store before use make sure that the ambient conditions are acceptable:

Storing temperature -40...+70°C (no cooling liquid inside cooling element allowed below 0°)  
Relative humidity <96%, no condensation

If the storage time exceeds 12 months the electrolytic DC capacitors need to be charged with caution. Therefore, such a long storage time is not recommended. See chapter 9.3 and the NX Liquid-Cooled Drives Service Manual for instructions on charging. See also chapter 3.3.

Warning: Always remove all cooling agent from the cooling element(s) before shipping to avoid damage caused by freezing.

### 3.3 MAINTENANCE

In normal conditions, Vacon NX Liquid-Cooled frequency converters are maintenance-free. However, if the frequency converter is used in conditions with temperatures below the freezing point and the liquid used for cooling is likely to freeze, be sure to empty the cooling element if the converter must be moved or if it is taken out of use for a longer time. See also chapter 3.2.

It may also be necessary to clean up the coolant ducts in the cooling element. Contact the factory for more information.

The instructions for the cooling system provided by its manufacturer shall be followed.

Change the glycol coolant every 2 years or add inhibitor.

### 3.4 WARRANTY

Only manufacturing defects are covered by the warranty. The manufacturer assumes no responsibility for damages caused during or resulting from transport, receipt of the delivery, installation, commissioning or use.

The manufacturer shall in no event and under no circumstances be held responsible for damages and failures resulting from misuse, wrong installation, unacceptable ambient temperature, running motor with lower coolant flow than minimum flow, condensation, dust, corrosive substances or operation outside the rated specifications.

Neither can the manufacturer be held responsible for consequential damages.

**NOTE!** Vacon NX Liquid-Cooled drives must not be run with the liquid cooling system disconnected. Furthermore, the requirements of the liquid cooling specifications, e.g. minimum flow rate (see chapter 5.2 and Table 15) must be satisfied. Ignoring this will render the warranty null and void.

The Manufacturer's time of warranty is 18 months from the delivery or 12 months from the commissioning whichever expires first (Vacon Warranty Terms).

The local distributor may grant a warranty time different from the above. This warranty time shall be specified in the distributor's sales and warranty terms. Vacon assumes no responsibility for any other warranties than that granted by Vacon itself.

In all matters concerning the warranty, please contact first your distributor.

## 4. TECHNICAL DATA

### 4.1 INTRODUCTION

The Vacon NX\_W liquid-cooled product range consists of both inverters and frequency converters. Figure 2 presents the block diagram of the Vacon NX Liquid-Cooled inverter and frequency converter. Mechanically, the product consists of two units, the Power Unit and the Control Unit. The power unit can contain one to six modules (cooling plates), depending on the drive size. Instead of air, Vacon NX Liquid-Cooled inverters and frequency converters use liquid for cooling. A charging circuit is embodied in the frequency converters but not in inverters.

An external three-phase AC-choke (1) at the mains input together with the DC-link capacitor (2) form an LC-filter. In frequency converters, the LC-filter together with the diode bridge produce the DC-voltage supply to the IGBT Inverter Bridge (3) block. The AC-choke also functions as a filter against High Frequency disturbances from the mains as well as against those caused by the frequency converter to the mains. In addition, it enhances the waveform of the input current to the frequency converter. In chasses with multiple parallel line-rectifiers (CH74) AC-chokes are required to balance the line current between the rectifiers.

The power drawn by the frequency converter from the mains is mostly active power.

The IGBT Inverter Bridge produces a symmetrical, 3-phase Pulse Width Modulated AC-voltage to the motor.


The Motor and Application Control Block is based on microprocessor software. The microprocessor controls the motor basing on the information it receives through measurements, parameter settings, control I/O and control keypad. The motor and application control block controls the motor control ASIC which, in turn, calculates the IGBT positions. Gate drivers amplify these signals for driving the IGBT inverter bridge.

The control keypad constitutes a link between the user and the frequency converter. The control keypad is used for parameter setting, reading status data and giving control commands. It is detachable and can be operated externally and connected via a cable to the frequency converter. Instead of the control keypad, a PC can also be used to control the frequency converter if connected through a similar cable ( $\pm 12V$ ).

You can have your frequency converter equipped with a control I/O board which is either isolated (OPT-A8) or not isolated (OPT-A1) from the frame. Optional I/O expander boards that increase the number of inputs and outputs to be used are also available. For closer information, contact the Manufacturer or your local distributor (see back cover).

The basic control interface and the parameters (the Basic Application) are easy to use. If a more versatile interface or parameters are required, a more suitable application can be chosen from the "All in One" Application Package. See the "All in One" Application Manual for more information on the different applications.

An internal brake chopper is available as standard for chassis CH3. For Ch72 (only 6-pulse) and Ch74, it is available as internal option while in all other sizes the brake chopper is available as option and installed externally. The standard product does not include a brake resistor. It should be acquired separately.



\*Brake resistor is available for all sizes [CH3 to CH7]. An internal brake chopper belongs to standard equipment in sizes CH3 . For Ch72 (only 6-pulse) and Ch74, it is available as internal option while in all other sizes it is optional but installed externally.

Figure 1. Vacon NX Liquid-Cooled converter principal block diagram




Figure 2. Vacon NX Liquid-Cooled inverter principal block diagram

## 4.2 POWER RATINGS

Vacon Liquid-Cooled product range consists of both frequency converters (AC input, AC output) and inverter units (DC input, AC output). The following tables present the drive output values for both and an indication of motor shaft power at  $I_{th}$  and  $I_L$  at different mains voltages as well as the drive losses and mechanical sizes. The power achieved is given as per the supply voltage.

### 4.2.1 FREQUENCY CONVERTERS

#### 4.2.1.1 Vacon NX Liquid-Cooled Frequency Converter – Mains voltage 400–500 VAC

*Table 1. Power ratings and dimensions of NX Liquid-Cooled frequency converter (6-pulse), supply voltage 400-500VAC*

Mains voltage 400-500 VAC, 50/60 Hz, 3~, 6-pulse drives									
Converter type	Drive output					Power loss c/a/T* [kW]	Chassis		
	Current			Motor output power					
	Thermal $I_{th}$ [A]	Rated cont. $I_L$ [A]	Rated contin. $I_H$ [A]	Optimum motor at $I_{th}$ (400V) [kW]	Optimum motor at $I_{th}$ (500V) [kW]				
0016_5	16	15	11	7.5	11	0.4/0.2/0.6	CH3		
0022_5	22	20	15	11	15	0.5/0.2/0.7	CH3		
0031_5	31	28	21	15	18.5	0.7/0.2/0.9	CH3		
0038_5	38	35	25	18.5	22	0.8/0.2/1.0	CH3		
0045_5	45	41	30	22	30	1.0/0.3/1.3	CH3		
0061_5	61	55	41	30	37	1.3/0.3/1.5	CH3		
0072_5	72	65	48	37	45	1.2/0.3/1.5	CH4		
0087_5	87	79	58	45	55	1.5/0.3/1.8	CH4		
0105_5	105	95	70	55	75	1.8/0.3/2.1	CH4		
0140_5	140	127	93	75	90	2.3/0.3/2.6	CH4		
0168_5	168	153	112	90	110	4.0/0.4/4.4	CH5		
0205_5	205	186	137	110	132	5.0/0.5/5.5	CH5		
0261_5	261	237	174	132	160	6.0/0.5/6.5	CH5		
0300_5	300	273	200	160	200	4.5/0.5/5.0	CH61		
0385_5	385	350	257	200	250	6.0/0.5/6.5	CH61		
0460_5	460	418	307	250	315	6.5/0.5/7.0	CH72		
0520_5	520	473	347	250	355	7.5/0.6/8.1	CH72		
0590_5	590	536	393	315	400	9.0/0.7/9.7	CH72		
0650_5	650	591	433	355	450	10.0/0.7/10.7	CH72		
0730_5	730	664	487	400	500	12.0/0.8/12.8	CH72		
0820_5	820	745	547	450	560	12.5/0.8/13.3	CH63		
0920_5	920	836	613	500	600	14.4/0.9/15.3	CH63		
1030_5	1030	936	687	560	700	16.5/1.0/17.5	CH63		
1150_5	1150	1045	766	600	750	18.5/1.2/19.7	CH63		
1370_5	1370	1245	913	700	900	19.0/1.2/20.2	CH74		
1640_5	1640	1491	1093	900	1100	24.0/1.4/25.4	CH74		
2060_5	2060	1873	1373	1100	1400	32.5/1.8/34.3	CH74		
2300_5	2300	2091	1533	1250	1500	36.3/2.0/38.3	CH74		
2470_5	2470	2245	1647	1300	1600	38.8/2.2/41.0	2*CH74		
2950_5	2950	2681	1967	1550	1950	46.3/2.6/48.9	2*CH74		

*Table 1. Power ratings and dimensions of NX Liquid-Cooled frequency converter (6-pulse), supply voltage 400-500VAC*

<b>Mains voltage 400-500 VAC, 50/60 Hz, 3~, 6-pulse drives</b>							
3710_5	3710	3372	2473	1950	2450	58.2/3.0/61.2	2*CH74
4140_5	4140	3763	2760	2150	2700	65.0/3.6/68.6	2*CH74

*Table 2. Power ratings and dimensions of NX Liquid-Cooled frequency converter (12-pulse), supply voltage 400-500VAC*

Converter type	Drive output					Power loss c/a/T*) [kW]	Chassis		
	Current			Motor output power					
	Thermal I <sub>th</sub> [A]	Rated cont. I <sub>L</sub> [A]	Rated contin. I <sub>H</sub> [A]	Optimum motor at I <sub>th</sub> (400V) [kW]	Optimum motor at I <sub>th</sub> (500V) [kW]				
0460_5	460	418	307	250	315	6.5/0.5/7.0	CH72		
0520_5	520	473	347	250	355	7.5/0.6/8.1	CH72		
0590_5	590	536	393	315	400	9.0/0.7/9.7	CH72		
0650_5	650	591	433	355	400	10.0/0.7/10.7	CH72		
0730_5	730	664	487	400	450	12.0/0.8/12.8	CH72		
1370_5	1370	1245	913	700	900	19.0/1.2/20.2	CH74		
1640_5	1640	1491	1093	850	1050	24.0/1.4/25.4	CH74		
2060_5	2060	1873	1373	1050	1350	32.5/1.8/34.3	CH74		
2470_5	2470	2245	1647	1300	1600	38.8/2.2/41.0	2*CH74		
2950_5	2950	2681	1967	1550	1950	46.3/2.6/48.9	2*CH74		
3710_5	3710	3372	2473	1950	2450	58.2/3.0/61.2	2*CH74		
4140_5	4140	3763	2760	2150	2700	65.0/3.6/68.6	2*CH74		

I<sub>th</sub> = Thermal maximum continuous RMS current. Dimensioning can be done according to this current if the process does not require any overloadability or the process does not include any load variation or margin for overloadability.

I<sub>L</sub> = Low overloadability current. Allows +10% load variation. 10% exceeding can be continuous.

I<sub>H</sub> = High overloadability current. Allows +50% load variation. 50% exceeding can be continuous.

All values with cosφ = 0,83 and efficiency = 97%

\*) c = power loss into coolant; a = power loss into air; T = total power loss; power losses of input chokes not included. All power losses obtained using max. supply voltage, I<sub>th</sub> and switching frequency of 3.6 kHz and ClosedLoop control mode. All power losses are worst case losses.

If some other mains voltage is used, apply the formula  $P = \frac{U_n}{I_n} \times \cos\varphi \times \text{eff}\%$  to calculate the NX Liquid-Cooled drive output power.

The enclosure class for all NX Liquid-Cooled frequency converters is IP00.

If the motor is continuously (besides start and stop ramps) run at frequencies below 5 Hz, pay attention to the drive dimensioning for low frequencies, i.e. maximum I<sub>H</sub> = 0.66\*I<sub>th</sub> or choose drive according to I<sub>H</sub>. It is recommended to check the rating with your distributor or Vacon.

Drive overrating may also be necessary if the process requires high starting torque.

Table 3. Internal brake chopper unit (BCU) ratings, braking voltage 460-800VDC

Internal brake chopper ratings, braking voltage 600-800 Vdc							
Converter type	Loadability		Braking capacity @ 600 Vdc		Braking capacity @ 800 Vdc		Chassis
	Rated min resistance [Ω]	Rated cont. braking power [kW]	BCU rated cont. braking current, $I_{br}$ [A]	Rated cont. braking power R@ 800VDC [kW]	BCU rated cont. braking current, $I_{br}$ [A]		
NX_460 5 <sup>1)</sup>	1,3	276	461	492	615	CH72	
NX_520 5 <sup>1)</sup>	1,3	276	461	492	615	CH72	
NX_590 5 <sup>1)</sup>	1,3	276	461	492	615	CH72	
NX_650 5 <sup>1)</sup>	1,3	276	461	492	615	CH72	
NX_730 5 <sup>1)</sup>	1,3	276	461	492	615	CH72	
NX_1370 5	1,3	276	461	492	615	CH74	
NX_1640 5	1,3	276	461	492	615	CH74	
NX_2060 5	1,3	276	461	492	615	CH74	
NX_2300 5	1,3	276	461	492	615	CH74	

**NOTE:** Braking power:  $P_{brake} = U_{brake}^2 / R_{brake}$

**NOTE:** Braking DC current:  $I_{in\_max} = P_{brake\_max} / U_{brake}$

<sup>1)</sup> Only 6 pulse drives

The internal brake chopper can also be used in motor application where 2...4 x Ch7x drives are used for a single motor, but in this case the DC connections of the power modules must be connected together. The break choppers are working independently of each other and because of this the DC connections must be connected together otherwise there can be unbalance between the power modules.

#### 4.2.1.2 Vacon NX Liquid-Cooled Frequency Converter – Mains voltage 525–690 VAC

Table 4. Power ratings and dimensions of NX Liquid-Cooled frequency converter (6-pulse), supply voltage 525–690VAC

Mains voltage 525–690 VAC, 50/60 Hz, 3~, 6-pulse drives							
Converter type	Drive output					Power loss c/a/T <sup>*</sup> [kW]	Chassis
	Current			Motor output power			
Thermal $I_{th}$ [A]	Rated contin. $I_L$ [A]	Rated contin. $I_H$ [A]	Optimum motor at $I_{th}$ (525V) [kW]	Optimum motor at $I_{th}$ (690V) [kW]			
0170_6	170	155	113	110	160	5.5/0.2/5.7	CH61
0208_6	208	189	139	132	200	6.5/0.3/6.8	CH61
0261_6	261	237	174	160	250	6.5/0.3/6.8	CH61
0325_6	325	295	217	200	300	7.5/0.4/7.9	CH72
0385_6	385	350	257	250	355	9.0/0.5/9.5	CH72
0416_6	416	378	277	250	355	9.4/0.5/9.9	CH72
0460_6	460	418	307	300	400	10.0/0.5/10.5	CH72
0502_6	502	456	335	355	450	12.0/0.6/12.6	CH72
0590_6	590	536	393	400	560	13.0/0.7/13.7	CH63
0650_6	650	591	433	450	600	16.0/0.8/16.8	CH63
0750_6	750	682	500	500	700	18.0/0.9/18.9	CH63
0820_6	820	745	547	560	800	19.0/1.0/20.0	CH74

*Table 4. Power ratings and dimensions of NX Liquid-Cooled frequency converter (6-pulse), supply voltage 525–690VAC*

<b>Mains voltage 525-690 VAC, 50/60 Hz, 3~, 6-pulse drives</b>							
0920_6	920	836	613	650	850	21.3/1.2/22.5	CH74
1030_6	1030	936	687	700	1000	22.0/1.1/23.1	CH74
1180_6	1180	1073	787	800	1100	25.0/1.3/26.3	CH74
1300_6	1300	1182	867	900	1200	31.0/1.6/32.6	CH74
1500_6	1500	1364	1000	1050	1400	38.0/1.9/39.9	CH74
1700_6	1700	1545	1133	1150	1550	38.0/1.9/39.9	CH74
1850_6	1850	1682	1233	1250	1650	39.6/2.0/41.6	2*CH74
2120_6	2120	1927	1413	1450	1900	45.0/2.4/47.4	2*CH74
2340_6	2340	2127	1560	1600	2100	55.8/2.9/58.7	2*CH74
2700_6	2700	2455	1800	1850	2450	68.4/3.4/71.8	2*CH74
3100_6	3100	2818	2066	2150	2800	68.4/3.4/71.8	2*CH74

*Table 5. Power ratings and dimensions of NX Liquid-Cooled frequency converter (12-pulse), supply voltage 525–690VAC*

<b>Mains voltage 525-690 VAC, 50/60 Hz, 3~, 12-pulse drives</b>									
Converter type	Drive output					Power loss c/a/T* [kW]	Chassis		
	Current			Motor output power					
	Thermal I <sub>th</sub> [A]	Rated contin. I <sub>L</sub> [A]	Rated contin. I <sub>H</sub> [A]	Optimum motor at I <sub>th</sub> (525V) [kW]	Optimum motor at I <sub>th</sub> (690V) [kW]				
0325_6	325	295	217	200	250	7.5/0.4/7.9	CH72		
0385_6	385	350	257	250	355	9.0/0.5/9.5	CH72		
0416_6	416	378	277	250	355	9.4/0.5/9.9	CH72		
0460_6	460	418	307	315	400	10.0/0.5/10.5	CH72		
0502_6	502	456	335	355	450	12.0/0.6/12.6	CH72		
0820_6	820	745	547	600	750	19.0/1.0/20.0	CH74		
0920_6	920	836	613	650	850	21.3/1.2/22.5	CH74		
1030_6	1030	936	687	750	950	22.0/1.1/23.1	CH74		
1180_6	1180	1073	787	800	1100	25.0/1.3/26.3	CH74		
1300_6	1300	1182	867	950	1200	31.0/1.6/32.6	CH74		
1500_6	1500	1364	1000	1050	1400	38.0/1.9/39.9	CH74		
1850_6	1850	1682	1233	1250	1650	39.6/2.0/41.6	2*CH74		
2120_6	2120	1927	1413	1450	1900	45.0/2.4/47.4	2*CH74		
2340_6	2340	2127	1560	1600	2100	55.8/2.9/58.7	2*CH74		
2700_6	2700	2455	1800	1850	2450	68.4/3.4/71.8	2*CH74		
3100_6	3100	2818	2067	2150	2800	68.4/3.4/71.8	2*CH74		

I<sub>th</sub> = Thermal maximum continuous RMS current. Dimensioning can be done according to this current if the process does not require any overloadability or the process does not include any load variation

I<sub>L</sub> = Low overloadability current. Allows +10% load variation. 10% exceeding can be continuous.

I<sub>H</sub> = High overloadability current. Allows +50% load variation. 50% exceeding can be continuous.

All values with cosφ = 0,83 and efficiency = 97%

\*) c = power loss into coolant; a = power loss into air; T = total power loss; power losses of input chokes not included. All power losses obtained using max. supply voltage, I<sub>th</sub> and switching frequency of 3.6 kHz and ClosedLoop control mode. All power losses are worst case losses.

If some other mains voltage is used, apply the formula  $P = \sqrt{3} \times U_n \times I_n \times \cos\varphi \times \text{eff\%}$  to calculate the NX Liquid-Cooled drive output power.

The enclosure class for all NX Liquid-Cooled frequency converters is IP00.

If the motor is continuously (besides start and stop ramps) run at frequencies below 5 Hz, pay attention to the drive dimensioning for low frequencies, i.e. maximum  $I_H = 0.66 \times I_{th}$  or choose drive according to  $I_H$ . It is recommended to check the rating with your distributor or Vacon.

Drive overrating may also be necessary if the process requires high starting torque.

*Table 6. Internal brake chopper unit (BCU) ratings, braking voltage 840-1100Vdc*

Internal brake chopper ratings, braking voltage 840-1100 Vdc						
Converter Type	Loadability	Braking capacity @ 840 Vdc		Braking capacity @ 1100 Vdc		Chassis
	Rated min resistance [Ω]	Rated cont. braking power [kW]	BCU rated cont. braking current, $I_{br}$ [A]	Rated cont. braking power [kW]	BCU rated cont. braking current, $I_{br}$ [A]	
NX_325 6 <sup>1)</sup>	2,8	252	300	432	392	Ch72
NX_385 6 <sup>1)</sup>	2,8	252	300	432	392	Ch72
NX_416 6 <sup>1)</sup>	2,8	252	300	432	392	Ch72
NX_460 6 <sup>1)</sup>	2,8	252	300	432	392	Ch72
NX_502 6 <sup>1)</sup>	2,8	252	300	432	392	Ch72
NX_820 6	2,8	252	300	432	392	Ch74
NX_920 6	2,8	252	300	432	392	Ch74
NX_1030 6	2,8	252	300	432	392	Ch74
NX_1180 6	2,8	252	300	432	392	Ch74
NX_1300 6	2,8	252	300	432	392	Ch74
NX_1500 6	2,8	252	300	432	392	Ch74

**NOTE:** Braking power:  $P_{brake} = U_{brake}^2 / R_{brake}$

**NOTE:** Braking DC current:  $I_{in\_max} = P_{brake\_max} / U_{brake}$

<sup>1)</sup> Only 6 pulse drives

The internal brake chopper can also be used in motor application where 2...4 x Ch7x drives are used for a single motor, but in this case the DC connections of the power modules must be connected together. The break choppers are working independently of each other and because of this the DC connections must be connected together otherwise there can be unbalance between the power modules.

#### 4.2.2 INVERTER UNITS

##### 4.2.2.1 Vacon NX Liquid-Cooled Inverter Unit – Mains voltage 465–800 VDC

*Table 7. Power ratings and dimensions of NX Liquid-Cooled inverter unit, supply voltage 540–675VDC*

Converter type	Mains voltage 465-800 VDC					Power loss c/a/T* [kW]	Chassis		
	Drive output			Motor output power					
	Thermal $I_{th}$ [A]	Rated cont. $I_L$ [A]	Rated cont. $I_H$ [A]	Optimum motor at $I_{th}$ (540VDC) [kW]	Optimum motor at $I_{th}$ (675VDC) [kW]				
0016_5	16	15	11	7,5	11	0,4/0,2/0,6	CH3		
0022_5	22	20	15	11	15	0,5/0,2/0,7	CH3		
0031_5	31	28	21	15	18,5	0,7/0,2/0,9	CH3		
0038_5	38	35	25	18,5	22	0,8/0,2/1,0	CH3		
0045_5	45	41	30	22	30	1,0/0,3/1,3	CH3		
0061_5	61	55	41	30	37	1,3/0,3/1,5	CH3		
0072_5	72	65	48	37	45	1,2/0,3/1,5	CH4		
0087_5	87	79	58	45	55	1,5/0,3/1,8	CH4		
0105_5	105	95	70	55	75	1,8/0,3/2,1	CH4		
0140_5	140	127	93	75	90	2,3/0,3/2,6	CH4		
0168_5	168	153	112	90	110	2,5/0,3/2,8	CH5		
0205_5	205	186	137	110	132	3,0/0,4/3,4	CH5		
0261_5	261	237	174	132	160	4,0/0,4/4,4	CH5		
0300_5	300	273	200	160	200	4,5/0,4/4,9	CH61		
0385_5	385	350	257	200	250	5,5/0,5/6,0	CH61		
0460_5	460	418	307	250	315	5,5/0,5/6,0	CH62		
0520_5	520	473	347	250	355	6,5/0,5/7,0	CH62		
0590_5	590	536	393	315	400	7,5/0,6/8,1	CH62		
0650_5	650	591	433	355	450	8,5/0,6/9,1	CH62		
0730_5	730	664	487	400	500	10,0/0,7/10,7	CH62		
0820_5	820	745	547	450	560	12,5/0,8/13,3	CH63		
0920_5	920	836	613	500	600	14,4/0,9/15,3	CH63		
1030_5	1030	936	687	560	700	16,5/1,0/17,5	CH63		
1150_5	1150	1045	766	600	750	18,4/1,1/19,5	CH63		
1370_5	1370	1245	913	700	900	15,5/1,0/16,5	CH64		
1640_5	1640	1491	1093	900	1100	19,5/1,2/20,7	CH64		
2060_5	2060	1873	1373	1100	1400	26,5/1,5/28,0	CH64		
2300_5	2300	2091	1533	1250	1500	29,6/1,7/31,3	CH64		
2470_5	2470	2245	1647	1300	1600	36,0/2,0/38,0	2*CH64		
2950_5	2950	2681	1967	1550	1950	39,0/2,4/41,4	2*CH64		
3710_5	3710	3372	2473	1950	2450	48,0/2,7/50,7	2*CH64		
4140_5	4140	3763	2760	2150	2700	53,0/3,0/56,0	2*CH64		

$I_{th}$  = Thermal maximum continuous RMS current. Dimensioning can be done according to this current if the process does not require any overloadability or the process does not include any load variation

$I_L$  = Low overloadability current. Allows +10% load variation. 10% exceeding can be continuous.

$I_H$  = High overloadability current. Allows +50% load variation. 50% exceeding can be continuous.

All values with  $\cos\varphi = 0,83$  and efficiency = 97%

\*) c = power loss into coolant; a = power loss into air; T = total power loss

All power losses obtained using max. supply voltage,  $I_{th}$  and switching frequency of 3.6 kHz and ClosedLoop control mode. All power losses are worst case losses.

If some other mains voltage is used, apply the formula  $DCP = (U_{DC}/1.35) * \sqrt{3} * I_n * \cos\varphi * \text{eff\%}$  to calculate the NX Liquid-Cooled drive electrical output power.

If the motor is continuously (besides start and stop ramps) run at frequencies below 5 Hz, pay attention to the drive dimensioning for low frequencies, i.e. maximum  $I_H = 0,66 * I_{th}$  or choose drive according to  $I_H$ . It is recommended to check the rating with your distributor or Vacon.

Drive overrating may also be necessary if the process requires high starting torque.

The voltage classes for the inverter units used in the tables above have been defined as follows:

*Input 540VDC* = Rectified 400VAC supply

*Input 675VDC* = Rectified 500VAC supply

The enclosure class of all inverter units is IP00. For more information, see chapter 10.

#### 4.2.2.2 Vacon NX Liquid-Cooled Inverter Unit – Mains voltage 640–1100 VDC

*Table 8. Power ratings and dimensions of NX Liquid-Cooled inverter unit, supply voltage 710–930VDC*

Inverter type	Mains voltage 640-1100 VDC					Power loss c/a/T <sup>*</sup> [kW]	Chassis		
	Drive output			Motor output power					
	Thermal $I_{th}$ [A]	Rated cont. $I_L$ [A]	Rated cont. $I_H$ [A]	Optimum motor at $I_{th}$ (710VDC) [kW]	Optimum motor at $I_{th}$ (930VDC) [kW]				
0170_6	170	155	113	110	160	4,5/0,2/4,7	CH61		
0208_6	208	189	139	132	200	5,5/0,3/5,8	CH61		
0261_6	261	237	174	160	250	5,5/0,3/5,8	CH61		
0325_6	325	295	217	200	300	6,5/0,3/6,8	CH62		
0385_6	385	350	257	250	355	7,5/0,4/7,9	CH62		
0416_6	416	378	277	250	355	8,0/0,4/8,4	CH62		
0460_6	460	418	307	300	400	8,5/0,4/8,9	CH62		
0502_6	502	456	335	355	450	10,0/0,5/10,5	CH62		
0590_6	590	536	393	400	560	10,0/0,5/10,5	CH63		
0650_6	650	591	433	450	600	13,5/0,7/14,2	CH63		
0750_6	750	682	500	500	700	16,0/0,8/16,8	CH63		
0820_6	820	745	547	560	800	16,0/0,8/16,8	CH64		
0920_6	920	836	613	650	850	18,0/0,9/18,9	CH64		
1030_6	1030	936	687	700	1000	19,0/1,0/20,0	CH64		
1180_6	1180	1073	787	800	1100	21,0/1,1/22,1	CH64		
1300_6	1300	1182	867	900	1200	27,0/1,4/28,4	CH64		
1500_6	1500	1364	1000	1050	1400	32,0/1,6/33,6	CH64		
1700_6	1700	1545	1133	1150	1550	38,0/1,9/39,9	CH64		
1850_6	1850	1682	1233	1250	1650	34,2/1,8/36,0	2*CH64		
2120_6	2120	1927	1413	1450	1900	37,8/2,0/39,8	2*CH64		
2340_6	2340	2127	1560	1600	2100	48,6/2,5/51,1	2*CH64		
2700_6	2700	2455	1800	1850	2450	57,6/3,0/60,6	2*CH64		
3100_6	3100	2818	2066	2150	2800	68,4/3,4/71,8	2*CH64		

$I_{th}$  = Thermal maximum continuous RMS current. Dimensioning can be done according to this current if the process does not require any overloadability or the process does not include any load variation

$I_L$  = Low overloadability current. Allows +10% load variation. 10% exceeding can be continuous.

$I_H$  = High overloadability current. Allows +50% load variation. 50% exceeding can be continuous.

All values with  $\cos\varphi = 0,83$  and efficiency = 97%

\*) c = power loss into coolant; a = power loss into air; T = total power loss

All power losses obtained using max. supply voltage,  $I_{th}$  and switching frequency of 3.6 kHz and ClosedLoop control mode. All power losses are worst case losses.

If some other mains voltage is used, apply the formula  $DCP = (U_{DC}/1.35) * \sqrt{3} * I_n * \cos\varphi * eff\%$  to calculate the NX Liquid-Cooled drive output power.

The voltage classes for the inverter units used in the tables above have been defined as follows:

*Input 710VDC* = Rectified 525VAC supply

*Input 930VDC* = Rectified 690VAC supply

The enclosure class of all inverter units is IP00.

If the motor is continuously (besides start and stop ramps) run at frequencies below 5 Hz, pay attention to the drive dimensioning for low frequencies, i.e. maximum  $I_H = 0.66 * I_{th}$  or choose drive according to  $I_H$ . It is recommended to check the rating with your distributor or Vacon.

Drive overrating may also be necessary if the process requires high starting torque.

For more information, see chapter 10.

## 4.3 TECHNICAL DATA

Table 9. Technical data

<b>Mains connection</b>	Input voltage $U_{in}$	400...500VAC; 525...690VAC; (-10%...+10%) 465...800VDC; 640...1100VDC (-0%...+0%)
	Input frequency	45...66 Hz
	Connection to mains	Once per minute or less
	DC bank capacitance	Voltage class 500V: Ch3 (16-31A units): 410 $\mu$ F Ch3 (38-61A units): 600 $\mu$ F CH4: 2400 $\mu$ F CH5: 7200 $\mu$ F CH61: 10800 $\mu$ F CH62/CH72: 10800 $\mu$ F CH63: 21600 $\mu$ F CH64/CH74: 32400 $\mu$ F 2*CH64/2*CH74: 64800 $\mu$ F CH61: 4800 $\mu$ F CH62/CH72: 4800 $\mu$ F CH63: 9600 $\mu$ F CH64/CH74: 14400 $\mu$ F 2*CH64/2*CH74: 28800 $\mu$ F
<b>Motor connection</b>	Output voltage	0— $U_{in}$
	Continuous output current	Rated current at nominal inflow cooling water temperature according to dimensioning charts
	Output frequency	0...320 Hz (standard); 7200 Hz (Special software)
	Frequency resolution	Application dependent
<b>Control characteristics</b>	Control method	Frequency control U/f Open Loop Sensorless Vector Control Closed Loop Vector Control
	Switching frequency (see parameter 2.6.9)	NX_5: Up to and including NX_0061: 1...16 kHz; Factory default 10 kHz From NX_0072: 1...12 kHz; Factory default 3.6 kHz NX_6: 1...6 kHz; Factory default 1.5 kHz Note! Derating required if higher switching frequency than the default is used!
	<u>Frequency reference</u> Analogue input Panel reference	Resolution 0.1% (10-bit), accuracy $\pm 1\%$ Resolution 0.01 Hz
	Field weakening point	8...320 Hz
	Acceleration time	0.1...3000 sec
	Deceleration time	0.1...3000 sec
	Braking torque	DC brake: 30% * $T_N$ (without brake option)

Table 9. Technical data

<b>Ambient conditions</b>	Ambient operating temperature	-10°C (no frost)...+50°C (at $I_{th}$ ) The NX liquid cooled drives must be used in an heated indoor controlled environment
	Installation temperature	0...+70°C
	Storage temperature	-40°C...+70°C; No liquid in heatsink under 0°C
	Relative humidity	5 to 96% RH, non-condensing, no dripping water
	Air quality:	IEC 60721-3-3, unit in operation, class 3C2 IEC 60721-3-3, unit in operation, class 3S2 (no conductive dust allowed) No corrosive gases
	Altitude	NX_5 [380...500 V]: max. 3000 m (in case network is not corner grounded) NX_6: max. 2000 m. For further requirements, contact factory 100-% load capacity (no derating) up to 1,000 m; above 1,000 m derating of maximum ambient operating temperature by 0,5°C per each 100 m is required
	Vibration EN50178/EN60068-2-6	5...150Hz Displacement amplitude 0.25 mm (peak) at 3...31 Hz Max acceleration amplitude 1 G at 31...150 Hz
	Shock EN50178, EN60068-2-27	UPS Drop Test (for applicable UPS weights) Storage and shipping: max 15 G, 11 ms (in package)
	Enclosure class	IP00/Open Frame standard in entire kW/HP range
<b>EMC</b>	Immunity	Fulfils all EMC immunity requirements
	Emissions	EMC level N for TN/TT networks EMC level T for IT networks
<b>Safety</b>		EN50178, EN61800-5-1, CE, UL, CUL, GOST R, (see unit nameplate for more detailed approvals)
	Safe Torque Off (STO) board	The drive is equipped with Vacon OPTAF board for prevention of torque on motor shaft. Standards: prEN ISO 13849-1 (2004), EN ISO 13849-2 (2003), EN 60079-14 (1997), EN 954-1 (1996), cat. 3 (hardware disable); IEC 61508-3(2001), prEN 50495 (2006). See Vacon manual ud01066 for detailed information.

Table 9. Technical data

<b>Control connections (apply to boards OPT-A1, OPT-A2 and OPT-A3)</b>	Analogue input voltage	0...+10V, $R_i = 200\text{k}\Omega$ , (-10V...+10V joystick control) Resolution 0.1%, accuracy $\pm 1\%$
	Analogue input current	0(4)...20 mA, $R_i = 250\text{W}$ differential
	Digital inputs (6)	Positive or negative logic; 18...24VDC
	Auxiliary voltage	+24V, $\pm 10\%$ , max volt. ripple < 100mVrms; max. 250mA Dimensioning: max. 1000mA/control box 1A external fuse required (no internal short-circuit protection on the control board)
	Output reference voltage	+10V, +3%, max. load 10mA
	Analogue output	0(4)...20mA; $R_L$ max. 500 $\Omega$ ; Resolution 10 bit; Accuracy $\pm 2\%$
	Digital outputs	Open collector output, 50mA/48V
	Relay outputs	2 programmable change-over relay outputs Switching capacity: 24VDC/8A, 250VAC/8A, 125VDC/0.4A Min. switching load: 5V/10mA
<b>Protections</b>	Oversupply trip limit	NX_5: 911V; NX_6 (CH62, CH63 & CH64): 1258V;
	Undervoltage trip limit	NX_6 (Other chassis): 1200V (all VDC)
	Earth fault protection	In case of earth fault in motor or motor cable, only the frequency converter is protected
	Mains supervision	Trips if any of the input phases is missing (frequency converters only)
	Motor phase supervision	Trips if any of the output phases is missing
	Unit overtemperature protection	Alarm limit: 65°C (heatsink); 70°C (circuit boards) Trip limit: 70°C (heatsink); 85°C (circuit boards)
	Overcurrent protection	Yes
	Motor overload protection	Yes
	Motor stall protection	Yes
	Motor underload protection	Yes
	Short-circuit protection of +24V and +10V reference voltages	Yes

Table 9. Technical data

<b>Liquid cooling</b>	Allowed cooling agents	Drinking water (see specification on page 49) Water-glycol mixture See derating specifications, chapter 5.3
	Volume	See page 51.
	Temperature of cooling agent	0...35°C ( $I_{th}$ )(input); 35...55°C: derating required, see Chapter 5.3 Max. temperature rise during circulation max. 5°C No condensation allowed. See Chapter 5.2.1.
	Cooling agent flow rates	See Table 15.
	System max. working pressure	6 bar
	System max. peak pressure	40 bar
	Pressure loss (at nom. flow)	Varies according to size. See Table 16.

## 5. INSTALLATION

### 5.1 MOUNTING

Vacon NX Liquid-Cooled Drive modules must be installed into an enclosure. The drives consisting of one module will be mounted on the mounting plate. The drives that include two or three modules are mounted inside a mounting bracket (see) which will then be installed in the enclosure.

**NOTE: If any other than vertical installation position is required, please contact your distributor!**

**NOTE:** The allowed installation temperature is 0...+70°C.

In chapter 5.1.2 you will find the dimensions of Vacon NX Liquid-Cooled drives installed on mounting bases (plates and brackets).

#### 5.1.1 LIFTING THE DRIVE

We recommend you to always use a jib crane or similar elevating device to lift the frequency converter/inverter unit. See figures below for correct lifting points.

For units with no mounting bracket (see chapter 5.1.2.2), the best place for hoisting is the hole(s) in the middle of the mounting plate (Lifting point 1). Vacon NX Liquid-Cooled drives consisting of several modules can the most safely and easily be lifted by the holes in the mounting bracket (Lifting point 2) using a screw pin shackle. Pay also attention to the recommended dimensions of the hoisting belt and the beam. See Figure 3.





Figure 1. Lifting points for drives consisting of one module (left) and several modules

In cabinet installation, the hoisting procedure described above right may, however, become difficult or even impossible if the cabinet width does not allow the use of the screw pin shackle in Lifting point 2 (see above).

In such case, follow the lifting procedure described in Figure 4. The mounting becomes easier and safer if the drive can be laid on a *supporting girder* fixed on the cabinet frame. We also recommend to use an *aligning stud* to guarantee an easy and safe mounting.



*Figure 2. Lifting of drive into a narrow mounting space*

To additionally stabilize the cabinet with the drive, we recommend to mount a fixing rail on the back of the cabinet, to which the top of the drive can be fastened with 5 or 6 M5 screws. The cut-out is compatible with Rittal or Veda cabinets. Also secure the drive with M8 nuts and studs to the supporting girder. See Figure 4 and Figure 5.

The NX liquid cooled drives are equipped with plastic handles and these handles can be used to lift drives consisting of one power module (CH61, CH62, & CH72). Recommended lifting point is mounting plate shown in Figure 3.

**Note:** A drive that includes two or three modules (CH63, CH64, & CH74) shall not and is never allowed to be lifted from one plastic handle. Recommended lifting procedure for these units are as described in Figure 3 and Figure 4.




Figure 3. Securing the drive to the cabinet frame


### 5.1.2 NX LIQUID-COOLED DIMENSIONS

#### 5.1.2.1 *Drives consisting of one module*

*Table 1. One-module drive dimensions (mounting base included)*

Chassis	Width	Height	Depth	Weight*
CH3	160	431	246	15
CH4	193	493	257	22
CH5	246	553	264	40
CH61/62	246	658	372	55
CH72	246	1076	372	90

\*. AC choke excluded.



*Figure 4. Vacon NX Liquid-Cooled drive dimensions, CH3*




Figure 5. Vacon NX Liquid-Cooled drive dimensions (frequency converter), CH4




Figure 6. Vacon NX Liquid-Cooled drive dimensions (inverter), CH4




Figure 7. Vacon NX Liquid-Cooled dimensions, CH5 frequency converter




Figure 8. Vacon NX Liquid-Cooled dimensions, CH5 inverter




Figure 9. Vacon Liquid-Cooled frequency converter, CH61




Figure 10. Vacon Liquid-Cooled inverter, CH61




Figure 11. Vacon Liquid-Cooled inverter, CH62




Figure 12. Vacon Liquid-Cooled frequency converter (6-pulse), CH72






Figure 13. Vacon Liquid-Cooled frequency converter (6-pulse) with internal brake chopper



*Figure 14. Vacon Liquid-Cooled frequency converter (12-pulse), CH72*

#### ***5.1.2.2 Drives consisting of several modules***

Vacon NX Liquid-Cooled drives consisting of several modules are mounted in a mounting bracket as presented in Figure 17.



*Table 2. Several-module drive dimensions  
(mounting bracket incl.)*

Chassis	Width	Height	Depth	Weight
CH63	505	924	375	120
CH64	746	924	375	180
CH74	746	1175	385	280

*Figure 15. Drive mounted inside mounting bracket*




Figure 16. Vacon Liquid-Cooled frequency converter with mounting bracket, CH63




Figure 17. Vacon Liquid-Cooled inverter with mounting bracket, CH63




Figure 18. Vacon NX Liquid-Cooled inverter dimensions, CH64, IP00






Figure 19. Vacon NX Liquid-Cooled frequency converter (6-pulse) dimensions, CH74, IP00



*Figure 20. Vacon NX Liquid-Cooled frequency converter (6-pulse) with internal brake chopper dimensions, CH74, IP00*



*Figure 21. Vacon NX Liquid-Cooled frequency converter (12-pulse) with internal brake chopper dimensions, CH74, IP00*

## 5.2 COOLING

Instead of using air for cooling, Vacon NX Liquid-Cooled drives are cooled with liquid. The liquid circulation of the drive is usually connected to a heat-exchanger (liquid-liquid/liquid-air) which cools down the liquid circulating in the cooling elements of the drive. Because the cooling elements are made of aluminium, the cooling agents allowed to be used are drinking water, demineralized water or a mixture of water and glycol.

There are two types of circulation system: open systems and closed systems.

An open system has no pressure, and allows free contact with air.

In a closed system, the piping is completely air-tight and there is pressure inside the pipes. The pipes must be made of metal, or specific plastic or rubber that includes an oxygen barrier. Preventing of oxygen diffusion in the coolant diminishes the risk of electrochemical corrosion of the metal parts, and generation of rust deposits. Always use a closed system with Vacon NX Liquid Cooled drives.

In case there is no other option than using an open system, you must take several precautions.

1. Use glycol or inhibitor in the coolant.
2. Examine the water quality regularly, and add inhibitor accordingly.
3. Yearly check that the properties of the cooling liquid are in accordance with the specification in this manual.

In a closed circulation system, the following figures are recommended reference values. To avoid electrochemical corrosion, it is necessary to add an inhibitor (e.g. Cortec VpCI-649) in the cooling agent.

The heat-exchanger delivered by Vacon (HX) consists of stainless steel materials. The good corrosion performance of stainless steel in district water systems is utilized and no disadvantage of divergent metal filler is included. Nevertheless, some precautions must be taken to reduce the corrosion risk on the stainless steel in high chloride waters, see Table 14. We recommend to use a Vacon HX heat exchanger whenever possible.

**NOTE:** If no heat-exchanger is used, actions must be taken to avoid electrochemical corrosion. Specifically no brass or copper elements may be used in the liquid circulation of the drive.

Copper and brass may be used in the liquid circulation in case the liquid-cooled drive is equipped with a nickel coated aluminum heatsink.

### Specification: Drinking water

The attached table gives the chemical requirements for drinking water provided for by the Finnish Ministry of Social Affairs and Health. These values are indicative.

*Table 3. Drinking water chemical specification*

Quality	Unit	Value
Acrylamide	µg/l	0.10
Antimony	µg/l	5.0
Arsenic	µg/l	10
Benzene	µg/l	1.0
Benzopyrene	µg/l	0.010
Boron	mg/l	1.0
Bromate	µg/l	10
Cadmium	µg/l	5.0
Chromium	µg/l	50

*Table 3. Drinking water chemical specification*

<b>Quality</b>	<b>Unit</b>	<b>Value</b>
Copper	mg/l	2.0
Cyanides	µg/l	50
1,2-Dichloroethane	µg/l	3.0
Epichlorohydrin	µg/l	0.10
Fluoride	mg/l	1.5
Lead	µg/l	10
Mercury	µg/l	1.0
Nickel	µg/l	20
Nitrate ( $\text{NO}_3^-$ )	mg/l	50
Nitrate-Nitrogen ( $\text{NO}_3\text{-N}$ )	mg/l	11.0
Nitrite ( $\text{NO}_2^-$ )	mg/l	0.5
Nitrite-Nitrogen ( $\text{NO}_2\text{-N}$ )	mg/l	0.15
Bactericides	µg/l	0.10
Bactericides, total	µg/l	0.50
Polynuclear aromatic hydrocarbons	µg/l	0.10
Selenium	µg/l	10
Tetrachloroethylene and trichloroethylene tot.	µg/l	10
Trihalomethanes tot.	µg/l	100
Vinyl chloride	µg/l	0.50
Chlorophenols total	µg/l	10

Table 4. Drinking water quality recommendations

Quality	Unit	Max. value
Aluminium	µg/l	200
Ammonium ( $\text{NH}_4^+$ )	mg/l	0.50
Ammonium ( $\text{NH}_4\text{-N}$ )	mg/l	0.40
Chloride <sup>1]</sup>	mg/l	<100
Manganese	µg/l	50
Iron	µg/l	<0.5
Sulphate <sup>1] 2]</sup>	mg/l	250
Sodium	mg/l	200
Oxidizability ( $\text{COD}_{\text{Mn}}\text{-O}_2$ )	mg/l	5,0
Quality	Unit	Desired value
<i>Clostridium perfringens</i> (including spores)	pmy/100 ml	0
Coliform bacteria	pmy/100 ml	0
Bacterial count (22°C)		No unusual changes
pH <sup>1]</sup>	pH	6...8
Electrical conductivity <sup>1]</sup>	µS/cm	<100
Turbidity		To be approved by user and no unusual changes
Colour		No unusual changes
Smell and taste		No unusual changes
Total organic carbon (TOC)		No unusual changes
Tritium	beq/l	100
Indicative total dose	mSv/year	0.10
Water hardness	°dH	3...10
Max. particle size in coolant	µm	300

Notes:

- 1) No aggressive water allowed  
 2) To avoid corrosion of piping, the sulphate content must not exceed 150 mg/l.

The cleanliness of the heat exchanger, and therefore the heat exchanging capacity, depend on the purity of the process water. The more impure the water, the more frequently the heat exchanger needs cleaning. The following figures are reference values required of cooling circuit process water:

**Specification: Process water***Table 5. Process water specification*

Quality	Unit	Value
pH		6...9
Water hardness	°dH	<20
Electrical conductivity	µS/cm	<100
Chlorides (Cl) *	mg/l	<100
Iron (Fe)	mg/l	<0.5

- \*. The allowed concentration of chloride ions (Cl-): <1000 ppm at 20°C, <300 ppm at 50°C and <100 ppm at 80°C; the values are given as guidance to reduce the corrosion risk on stainless steel. The values are valid for pH=7. Lower pH value increases the risk.

The design temperature of the cooling agent entering the drive module(s) is 35°C. While circulating inside the cooling element, the liquid transfers the heat produced by the power semiconductors (and the capacitors). The design temperature rise of the cooling agent during the circulation is less than 5°C. Typically, 95% of the power losses is dissipated in the liquid. We advise you to equip the cooling agent circulation with temperature supervision.

The heat exchanging equipment can be located outside the electrical room in which the frequency converters are. The connections between these two are made on site. In order to minimize the pressure drops, the pipings shall be made as straight as possible. We further recommend that a regulating valve equipped with a measurement point is mounted. This makes the measurement and regulation of liquid circulation possible in the commissioning phase.

In order to prevent dirt particles from accumulating in the connections and thus gradually weakening the cooling effect, installation of filters is also recommended.

The highest point of the piping must be equipped with either an automatic or a manual venting device. The material of the piping must comply with at least AISI 304 (AISI 316 is recommended).

Prior to the actual connection of the pipes, the bores shall be cleaned thoroughly. If cleaning with water is not possible, although recommended, pressured air must be used to remove all loose particles and dust.

To facilitate the cleaning and venting of the coolant circulation, we recommend you to install a bypass valve in the main line and valves at each frequency converter inlet. Open the bypass valve and shut the valves to the frequency converter when cleaning and airing the system. On commissioning the system, the bypass valve shall be closed and the valves to the converters opened.

Below you will find a simplified example of the cooling system as well as an example of the connections between the frequency converters and the cooling system.




Figure 22. Example of cooling system

Vacon recommends to equip the cooling system with pressure and flow supervision (FE). The flow supervision can be connected to digital input function *External fault*. If the coolant flow is found too low, the frequency converter will be stopped.

The flow supervision and other actuators, e.g. a constant flow valve, are available as options. The options shall be mounted at the junction of the main line and the branching line to the element, indicated with an asterisk (\*) in the figure above.




Figure 23. Example: PI-diagram of the cooling system and the connections

In tables below you will find the specifications related to the cooling agent and its circulation. See also Table 9 on page 26.

*Table 6. Information about cooling agent and its circulation*

Chassis	Min. liquid flow per element (drive) [dm <sup>3</sup> /min]	Nom. liquid flow per element (drive) [dm <sup>3</sup> /min]			Max. liquid flow per element (drive) [dm <sup>3</sup> /min]	Liquid volume/element [l]
		A	B	C		
CH3	3 (3)	5 (5)	5,4 (5,4)	5,8 (5,8)	20 (20)	0.11
CH4	8 (8)	10 (10)	11 (11)	12 (12)	20 (20)	0.15
CH5	10 (10)	15 (15)	16 (16)	17 (17)	40 (40)	0.22
CH61	15 (15)	25 (25)	27 (27)	29 (29)	40 (40)	0.38
CH62	15 (15)	25 (25)	27 (27)	29 (29)	40 (40)	0.38
CH63	15 (30)	25 (50)	27 (54)	29 (58)	40 (80)	0.38
CH64	15 (45)	25 (75)	27 (80)	29 (86)	40 (120)	0.38
CH72	20 (20)	35 (35)	37 (37)	40 (40)	40 (40)	1.58
CH74	20 (60)	35 (105)	37 (112)	40 (121)	40 (120)	1.58

A = 100% water; B = Water/Glycol mixture 80:20; C = Water/Glycol mixture (60:40)

Definitions:

Min liquid flow = Minimum flow rate to ensure of total venting of the cooling element

Nom liquid flow = Flow rate that allows running the drive at lth

Max liquid flow = If flow rate exceeds max liquid flow, risk of cooling element erosion increases

Liquid ref temperature, input: 30°C

Max temperature rise during circulation: 5°C

**NOTE:** Unless minimum liquid flow rate is ensured, air pockets may develop in the cooling elements. Automatic or manual de-airing of the cooling system must also be ensured.

The following table will help you to determine the appropriate flows of cooling agent (l/min) with given power losses (see chapter 4.2).

*Figure 24. Cooling agent flow rates (l/min) in relation to power loss at certain glycol/water mixture*

Power loss [kW]	Glycol/Water ratio					
	100/0	80/20	60/40	40/60	20/80	0/100
1	4,41	3,94	3,58	3,29	3,06	2,87
2	8,82	7,88	7,15	6,58	6,12	5,74
3	13,23	11,82	10,73	9,87	9,18	8,61
4	17,64	15,75	14,31	13,16	12,24	11,48
5	22,05	19,69	17,88	16,45	15,30	14,35
6	26,46	23,63	21,46	19,74	18,36	17,22
7	30,86	27,57	25,03	23,03	21,42	20,10
8	35,27	31,51	28,61	26,32	24,48	22,97

Figure 24. Cooling agent flow rates (l/min) in relation to power loss at certain glycol/water mixture

Power loss [kW]	Glycol/Water ratio					
	100/0	80/20	60/40	40/60	20/80	0/100
9	39,68	35,45	32,19	29,61	27,54	25,84
10	44,09	39,38	35,76	32,90	30,60	28,71

### 5.2.1 CONDENSATION

Condensation on the cooling plate of the NX Liquid-Cooled drive must be avoided. Therefore, the temperature of the cooling liquid must be kept higher than the temperature of the electrical room. Use the graph below to determine if the drive operating conditions (combination of room temperature, humidity and cooling liquid temperature) are safe, or, to choose the allowed temperature for the cooling liquid.

The conditions are safe when the point is below the respective curve. If not, take adequate precautions by decreasing the room temperature and/or the relative humidity or increase the cooling liquid temperature. Note that increasing the temperature of the cooling liquid above figures in loadability charts decreases the nominal output current of the drive. The below curves are valid at sea level altitude (1013 mbar).




Figure 25. Safe operating conditions in relation to condensation

#### Example:

If the temperature of the electric room is 30°C, the relative humidity is 40% and the temperature of the cooling liquid is 20°C (the lowest curve in Figure 27), then the drive operating conditions are safe.

However, if the room temperature were to rise to 35°C and the relative humidity to 60%, then the operating conditions of the drive would no longer be safe. In this case, to reach safe operating con-

ditions, the air temperature should be cooled to 28°C or lower. If it is not possible to lower the room temperature, then the temperature of the cooling liquid should be raised to at least 25°C.

### 5.2.2 COOLING SYSTEM CONNECTIONS

The external cooling system shall be connected to each one of the cooling elements of the inverter or frequency converter.

**NOTE:** It is forbidden to connect the cooling elements in series.

The delivery comprises hoses (Technobel Noir Tricoflex, Art.no 135855) 1.5m in length and 16mm in diameter (CH5, CH6, CH7). The hoses are inserted in 1400-mm UL94V0 approved conduits (type HFX40). These hoses have screw type connectors with internal thread. The connection of the hoses is made on the aluminium adapter (external thread) of the cooling element. The customer end thread of the cooling hose is G1/2" male fixed including a Usit-R sealing. The connection of the line hose shall be made avoiding any twisting of the hose on the element.



Figure 26. Aluminium hose adapters



Figure 27. External thread of hose adapter

For all other chasses (CH3, CH4), the standard delivery includes fast connectors of type 'Tema', series 1300 or 1900. The fast connectors are available as option also for CH5, CH6, CH7.

*Table 7. Liquid connector types (all pressure values at nominal flow)*

<b>Chassis</b>	<b>Thread on element (internal) BSPP <sup>*)</sup></b>	<b>Connector type or hose type</b>	<b>Thread (cust.) BSPP <sup>**) .</sup></b>	<b>Max. pressure (entire system)</b>	<b>Pressure loss, (fast connector + element)</b>	<b>Pressure loss, (hoses + element)</b>
CH3	G3/8"	1300NE2 1/4"		6 bar	0.25 bar	
CH4	G3/8"	1300NE2 1/4"		6 bar	0.25 bar	
CH5	G3/4"	Technobel 16*23.5	G1/2"	6 bar		0.2 bar
CH6	G3/4"	Technobel 16*23.5	G1/2"	6 bar	See table below	See table below
CH7	G3/4"	Technobel 16*23.5	G1/2"	6 bar	See table below	See table below

\*) Use sealing (e.g. Usit-R Metal washer-rubber sealing) for this type of connection according to ISO standard 228-1

\*\*) Use sealant or sealing tape for this type of connection

### 5.2.2.1 Pressure losses

Table 8. Pressure losses; CH6x

CH6x with standard 1.5m hoses and optional fast connectors TEMA							
Volume flow rate (l/min)	Pressure loss; Tema, inflow (bar)	Pressure loss; inflow hose (bar)	Pressure loss; element (bar)	Pressure loss; outflow hose: (bar)	Pressure loss; Tema, outflow (bar)	Pressure loss total (inflow hose, element and outflow hose) (bar)	Pressure loss total (Tema, inflow and outflow hoses and element) (bar)
40,0	0,59	0,30	0,28	0,29	0,51	0,87	1,96
30,0	0,30	0,17	0,16	0,16	0,25	0,49	1,04
20,0	0,10	0,09	0,08	0,07	0,09	0,24	0,43
17,0	0,06	0,07	0,06	0,03	0,07	0,16	0,29




Figure 28. Pressure loss, CH6x

Table 9. Pressure losses; CH7x

CH7x (16) with standard 1.5m hoses and optional fast connectors TEMA							
Volume flow rate (l/min)	Pressure loss; Tema, inflow (bar)	Pressure loss; inflow hose (bar)	Pressure loss; element (bar)	Pressure loss; outflow hose: (bar)	Pressure loss; Tema, outflow (bar)	Pressure loss total (inflow hose, element and outflow hose) (bar)	Pressure loss total (Tema, inflow and outflow hoses and element) (bar)
40,0	0,61	0,30	0,28	0,28	0,50	0,87	1,97
30,0	0,31	0,17	0,17	0,16	0,26	0,50	1,07

Table 9. Pressure losses; CH7x

CH7x (16) with standard 1.5m hoses and optional fast connectors TEMA							
Volume flow rate (l/min)	Pressure loss; Tema, inflow (bar)	Pressure loss; inflow hose (bar)	Pressure loss; element (bar)	Pressure loss; outflow hose: (bar)	Pressure loss; Tema, outflow (bar)	Pressure loss total (inflow hose, element and outflow hose) (bar)	Pressure loss total (Tema, inflow and outflow hoses and element) (bar)
20,0	0,11	0,09	0,08	0,07	0,10	0,24	0,44




Figure 29. Pressure loss, CH7x

The liquid carrying hoses from the network to the cooling elements of the drive must not be electrically conductive. Risk of electrical shock and device damage! To avoid electrochemical corrosion, it is necessary to add an inhibitor (e.g. Cortec VpCI-649L in the cooling liquid).

The following main line hose materials are allowed for a liquid cooled drive including an aluminum heatsink:

- plastic (PVC)
- rubber (EPDM & NBR only)
- aluminium
- other stainless and acid-proof materials

The following main line hose materials are allowed for a liquid cooled drive including a nickel coated aluminum heatsink:

- plastic (PVC)
- rubber (EPDM & NBR only)
- copper
- aluminium
- brass
- other stainless and acid-proof material

The hoses must tolerate a peak pressure of 40 bar.

Connect the line hose to its counterpart (screw connector or fast connector) on the cooling element of the frequency converter/inverter. The coolant inlet connector is the one closer to the mounting plate and the outlet connector the one closer to the face of the drive, see Figure 33. Due to high pressure in the line hose, it is recommended to equip the liquid line with a shut-off valve, which makes the connection easier. In order to prevent water from spraying in the installation room we also recommend to wrap e.g. linters around the connection on installing.

Vacon furthermore recommends to equip the pipe branches to the cooling elements with valves.

### 5.2.2.2 Installation of flow switch

As stated on page 50, Vacon recommends the installation of flow supervision in the liquid cooling system. If requested, Vacon delivers the flow switch as option. The specification of the flow switch as well as notes as concerns its installation are given below.

#### About the installation

Vacon recommends to mount the flow switch on the inflow side of the system (see Figure 24). Pay attention to the direction of flow. The switch reaches the highest accuracy when it is mounted in horizontal position. If mounted vertically, the mechanical sensor is affected by the Earth's gravity which reduces the accuracy according to the data given in Table 19.




VANXPLC\_1030\_INS\_uk

*Figure 30. Flow switch: Hose connection, fast connector (electrical), fast connector lock screw, cable seal and clamp*

*Table 10. Flow switch data*

<b>Hose connection</b>	G1/2" female, internal thread ISO228-1
<b>Closing</b>	The switch closes if the flow exceeds 20 l/min.
<b>Switching accuracy:</b> <b>Horizontal installation</b>	-5...+15% (19...23 l/min)
<b>Vertical installation</b>	±5% (19...21 l/min)



*Figure 31. Direction of coolant circulation*

### 5.3 DRIVE DERATING

The tables below state the maximum coolant temperatures for Vacon liquid-cooled drives at given switching frequencies. Drive derating is required if the maximum temperatures are exceeded.

**NOTE:** If the heatsink is nickel-coated you must allow for a 2-degree C derating of values in the tables below.<sup>1)</sup> (Temperatures given in parenthesis). This applies only to the two biggest drive sizes of each chassis!

*Table 11. Max temperatures of coolant at switching frequency of 3.6 kHz*

Supply voltage 400-500 VAC, switching frequency 3,6 kHz			
Chassis	Type	Max coolant temperature [°C] Supply voltage 400V	Max coolant temperature [°C] Supply voltage 500V
CH 61	NXP0385_5	47 (45) <sup>1)</sup>	43 (41) <sup>1)</sup>
CH62	NXP0730_5	40 (38) <sup>1)</sup>	37 (35) <sup>1)</sup>
CH63	NXP1150_5	38 (36) <sup>1)</sup>	36 (34) <sup>1)</sup>
CH64	NXP2060_5	37 (35) <sup>1)</sup>	34 (32) <sup>1)</sup>
CH64	NXP2300_5	42 (40) <sup>1)</sup>	40 (38) <sup>1)</sup>
CH72	NXP0730_5	42 (40) <sup>1)</sup>	40 (38) <sup>1)</sup>
CH74	NXP2060_5	37 (35) <sup>1)</sup>	34 (32) <sup>1)</sup>
CH74	NXP2300_5	37 (35) <sup>1)</sup>	34 (32) <sup>1)</sup>

*Table 12. Max temperatures of coolant at switching frequency of 1.5 kHz*

Supply voltage 400-500 VAC, switching frequency 1,5 kHz			
Chassis	Type	Max coolant temperature [°C] Supply voltage 400V	Max coolant temperature [°C] Supply voltage 500V
CH61	NXP0385_5	52 (50) <sup>1)</sup>	49 (47) <sup>1)</sup>
CH62	NXP0730_5	47 (45) <sup>1)</sup>	45 (43) <sup>1)</sup>
CH63	NXP1150_5	44 (42) <sup>1)</sup>	42 (40) <sup>1)</sup>
CH64	NXP2060_5	49 (47) <sup>1)</sup>	47 (45) <sup>1)</sup>
CH64	NXP2300_5	44 (42) <sup>1)</sup>	42 (40) <sup>1)</sup>
CH72	NXP0730_5	45 (43) <sup>1)</sup>	43 (41) <sup>1)</sup>
CH74	NXP2060_5	49 (47) <sup>1)</sup>	47 (45) <sup>1)</sup>
CH74	NXP2300_5	44 (42) <sup>1)</sup>	43 (41) <sup>1)</sup>

*Table 13. Max temperatures of coolant at switching frequency of 3,6 kHz*

Supply voltage 525-690 VAC, switching frequency 3,6 kHz			
Chassis	Type	Max coolant temperature [°C] Supply voltage 525V	Max coolant temperature [°C] Supply voltage 690V
CH61	NXP0261_6	45 (43) <sup>1)</sup>	39 (37) <sup>1)</sup>
CH62	NXP0502_6	41 (39) <sup>1)</sup>	33 (31) <sup>1)</sup>
CH63	NXP0750_6	42 (40) <sup>1)</sup>	36 (34) <sup>1)</sup>
CH64	NXP1500_6	41 (39) <sup>1)</sup>	34 (32) <sup>1)</sup>
CH72	NXP0502_6	38 (36) <sup>1)</sup>	32 (30) <sup>1)</sup>
CH74	NXP1500_6	41 (39) <sup>1)</sup>	34 (32) <sup>1)</sup>

*Table 14. Max temperatures of coolant at switching frequency of 1,5 kHz*

Supply voltage 525-690 VAC, switching frequency 1,5 kHz			
Chassis	Type	Max coolant temperature [°C] Supply voltage 525V	Max coolant temperature [°C] Supply voltage 690V
CH61	NXP0261_6	54 (52) <sup>1)</sup>	51 (49) <sup>1)</sup>
CH62	NXP0502_6	52 (50) <sup>1)</sup>	47 (45) <sup>1)</sup>
CH63	NXP0750_6	53 (51) <sup>1)</sup>	50 (48) <sup>1)</sup>
CH64	NXP1500_6	52 (50) <sup>1)</sup>	47 (45) <sup>1)</sup>
CH72	NXP0502_6	51 (49) <sup>1)</sup>	46 (44) <sup>1)</sup>
CH74	NXP1500_6	52 (50) <sup>1)</sup>	48 (46) <sup>1)</sup>

#### 5.4 INPUT CHOKES

The input choke carries out several functions in the Vacon NX Liquid-Cooled frequency converter. Connection of the input choke is necessary except if you have a component in your system that performs the same tasks (e.g. a transformer). The input choke is needed as an essential component for motor control, to protect the input and DC-link components against abrupt changes of current and voltage as well as to function as a protection against harmonics. In chasses with multiple parallel line rectifiers (CH74) AC-chokes are required to balance the line current between the rectifiers.

The input chokes are included in the standard delivery of Vacon liquid-cooled frequency converters (not inverters). However, you can also order your frequency converter without the choke.

The Vacon chokes listed below are meant for supply voltages of 400-500 and 525-690V.

*Table 15. Input choke dimensioning, 6-pulse supply*

Converter types (400—500VAC)	Converter types (690VAC)	Choke type	Thermal current [A]	Nominal inductance [0H] A/B*	Calculated loss [W]
0016...0022	0012...0023	CHK0023N6A0	23	1900	145
0031...0038	0031...0038	CHK0038N6A0	38	1100	170

Table 15. Input choke dimensioning, 6-pulse supply

Converter types (400—500VAC)	Converter types (690VAC)	Choke type	Thermal current [A]	Nominal inductance [0H] A/B*	Calculated loss [W]
0045...0061	0046...0062	CHK0062N6A0	62	700	210
0072...0087	0072...0087	CHK0087N6A0	87	480	250
0105...0140	0105...0140	CHK0145N6A0	145	290	380
0168...0261	0170...0261	CHK0261N6A0	261	139/187	460
0300...0385 <i>0820...1180 1850...2340</i>	0325...0385 <i>0820...1180 1850...2340</i>	CHK0400N6A0	400	90/126	610
0460...0520 <i>1370 (CH74)</i>	0416...0502 <i>1300...1500 2700...3100</i>	CHK0520N6A0	520	65/95	810
0590...0650 <i>1640</i>	0590...0650 <i>1700...1900</i>	CHK0650N6A0	650	51/71	890
0730 <i>2060</i>	0750	CHK0750N6A0	750	45/61	970
0820 <i>2300</i>	-	CHK0820N6A0	820	39/53	1020
0920...1030	-	CHK1030N6A0	1030	30/41	1170
1150	-	CHK1150N6A0	1150	26/36	1420
<i>2470...2950</i>		CHK0520N6A0	520	65/95	810
<i>3710</i>		CHK0650N6A0	650	51/71	890
<i>4140</i>		CHK0750N6A0	750	45/61	970
<i>Converter types written bold italic require three (3) chokes of the designated kind per unit with 6-pulse supply</i>					

Table 16. Input choke dimensioning, 12-pulse supply

Converter types (400—500VAC)	Converter types (690VAC)	Choke type (2 chokes needed)	Thermal current [A]	Nominal inductance [0H] A/B*	Calculated loss [W]
0460...0520	0325...0502	CHK0261N6A0	261	139/187	460
0590...0730	0590...0750	CHK0400N6A0	400	90/120	610
0820...1030 <i>1850</i>	0820...1030 <i>1850</i>	CHK0520N6A0	520	65/95	810
1150 <i>2300 2470</i>	1180...1300 <i>2120...2340</i>	CHK0650N6A0	650	51/71	890
<i>1370 2950</i>	<i>1370 2700</i>	CHK0750N6A0	750	45/61	970
1640	<i>1500 3100</i>	CHK0820N6A0	820	39/53	1020
<i>2060 3710</i>	<i>1700...1900</i>	CHK1030N6A0	1030	30/41	1170

Table 16. Input choke dimensioning, 12-pulse supply

Converter types (400—500VAC)	Converter types (690VAC)	Choke type (2 chokes needed)	Thermal current [A]	Nominal inductance [0H] A/B*	Calculated loss [W]
4140	-	CHK1150N6A0	1150	26/36	NA

*Converter types written bold italic require two (2) chokes of the designated kind per unit (totally 4).*

\*Inductances for different supply voltages; A = 400...480Vac, B = 500...690Vac. See page 63.

#### 5.4.1 INSTALLATION OF INPUT CHOKES

There are two types of input choke connection in Vacon NX Liquid-Cooled drives. The two smallest sizes (CH31, CH32; up to 61A) have terminal block connection whereas bigger sizes use busbar connection. Examples of both connections and the choke dimensions below.




Figure 32. Example of input chokes for Vacon NX Liquid-Cooled. Sizes up to 62A




Figure 33. Example of input chokes for Vacon NX Liquid-Cooled. Sizes 87A...145A and 590A

Table 17. Choke dimensions; Sizes 23A...145A and 590A

Choke type	H1 [mm]	H2 [mm]	W1 [mm]	W2 [mm]	D1 [mm]	D2 [mm]	S1 [mm]	S2 [mm]	Weight [kg]
CHK0023N6A0	178	140	230	210	121	82	9*14 (4pcs)		10
CHK0038N6A0	209	163	270	250	NA	NA	9*14 (6pcs)		15
CHK0062N6A0	213	155	300	280	NA	NA	9*14 (4pcs)		20
CHK0087N6A0	232	174	300	280	170		9*14 (4pcs)	Ø9 (6 pcs)	26
CHK0145N6A0	292	234	300	280	185		9*14 (4pcs)	Ø9 (6 pcs)	37
CHK0590N6A0	519		394	316	272	165	10*35 (4pcs)	Ø11 (6 pcs)	125

Always connect the supply cables to the choke terminals marked with #1 (see Figure 36). Choose the converter connection according to the table below:




Table 18.

Supply voltage	Converter connection (terminal no.)
400-480Vac	2
500Vac	3
575-690Vac	3

Figure 34. Example of input chokes for Vacon NX Liquid-Cooled. Sizes 261A...1150A

Table 19. Choke dimensions; Sizes 261A...1150A

Choke type	H1 [mm]	H2 [mm]	W1 [mm]	W2 [mm]	W3 [mm]	W4 [mm]	D1 [mm]	D2 [mm]	D3 [mm]	S1	S2 Ø	Weight [kg]
CHK0261N6A0	319	357	354	150	275	120	230	206	108	9*14 (8pcs)	9*14 (9 pcs)	53
CHK0400N6A0	383	421	350	150	275	120	262	238	140	9*14 (8pcs)	11*15 (9 pcs)	84
CHK0520N6A0	399	446	497	200	400	165	244	204	145	Ø13 (8pcs)	11*15 (9 pcs)	115
CHK0650N6A0	449	496	497	200	400	165	244	206	145	Ø13 (8pcs)	11*15 (9 pcs)	130
CHK0750N6A0	489	527	497	200	400	165	273	231	170	Ø13 (8pcs)	13*18 (9 pcs)	170
CHK0820N6A0	491	529	497	200	400	165	273	231	170	Ø13 (8pcs)	13*18 (9 pcs)	170
CHK1030N6A0	630	677	497	200	400	165	307	241	170	Ø13 (8pcs)	13*18 (36pcs)	213

Table 19. Choke dimensions; Sizes 261A...1150A

Choke type	H1 [mm]	H2 [mm]	W1 [mm]	W2 [mm]	W3 [mm]	W4 [mm]	D1 [mm]	D2 [mm]	D3 [mm]	S1	S2 Ø	Weight [kg]
CHK1150N6A0	630	677	497	200	400	165	307	241	170	Ø13 (8pcs)	13*18 (36pcs)	213

If you have ordered the input chokes for Vacon NX Liquid-Cooled separately pay attention to the following instructions:

1. Protect the chokes from dripping water. You may even need to use plexiglass for protection because jets of water may occur when working with the connections.

2. Connection of cables:

Types *CHK0023N6A0, CHK0038N6A0, CHK0062N6A0 (chokes with terminal blocks)*

The terminals are marked with letters U,V,W and X,Y and Z in such an order, however, that terminals U and X, V and Y as well as W and Z form pairs of which one is an input and the other an output. Furthermore, terminals U,V and W must all be used as either input or output. The same applies to terminals X, Y and Z. See Figure 34.

Example: If you connect the mains cable of one phase to terminal X, the other two phases must be connected to Y and Z. Accordingly, the choke output cables are connected to their corresponding input pairs: phase 1 → U, phase 2 → V and phase 3 → W.

Other types (chokes with busbar connection)

Connect the mains cables to the upper busbar connectors (see Figure 35 and Figure 36) with bolts. The cables to the frequency converter are bolted to the lower connectors. See Table 26 and Table 28 for bolt sizes.

## 6. ELECTRICAL CABLING AND CONNECTIONS

### 6.1 POWER UNIT

How the power connections of Vacon NX Liquid-Cooled units are implemented depends on the size of the unit. The smallest NX Liquid-Cooled unit (CH3) has terminal blocks for the connections. In all other units, the connection is established using cables and cable clips or bolting the busbars together.

The main circuit diagrams of each NX Liquid-Cooled drive chassis you will find in Appendix 2.

#### 6.1.1 POWER CONNECTIONS

Use cables with heat resistance of at least +90°C. The cables and the fuses must be sized according to the drive nominal OUTPUT current that you can find on the rating plate. Sizing according to the output current is recommended because the drive input current never significantly exceeds the output current. Installation of cables according to UL regulations is presented in Chapter 6.1.6.

In chassis CH5 and greater, the field cables (both motor and mains) shall be connected to a specific cable connection block (optional equipment). However, inside a switchgear, the cable connection can be made directly to the drive.

Table 35 shows the minimum sizes of the Cu-cables and the corresponding aR fuse sizes.

If the motor temperature protection of the drive (see Vacon All in One Application Manual) is used as an overload protection, the cable shall be chosen accordingly. If three or more cables are used in parallel each cable requires a separate overload protection.

These instructions apply only to cases with one motor and one cable connection from the frequency converter or inverter to the motor. In any other case, ask the factory for more information.

#### 6.1.1.1 Mains cable

The mains cables of the size CH31 are connected to terminal blocks [see Figure 6] whereas busbar connection is used for greater sizes, see drawings on page 33 to page 44. Mains cable type for EMC level N in Table 29.

#### 6.1.1.2 Motor cable

In order to avoid current sharing disbalance it is imperative to use symmetrical motor cables. Vacon also recommends to always use shielded cable whenever possible.

The motor cables of the size CH31 are connected to terminal blocks [see Figure 6] whereas busbar connection is used for greater sizes, see drawings on page 33 to page 44. Motor cable type for EMC level N in Table 29. Ask factory for more information on the use of ferrite cores with the motor cable in order to protect the motor bearings against motor bearing currents.

For information on control cables see Chapter Table 6.2.2.1 and Table 29.

*Table 1. Cable types required to meet standards.*

Cable type	Level N/T
Mains cable	1
Motor cable	1
Control cable	4

1 = Power cable intended for fixed installation and the specific mains voltage. Symmetrical shielded cable recommended. (NKCABLES/MCMK or similar recommended)

4 = Screened cable equipped with compact low-impedance shield (NKCABLES /JAMAK, SAB/ÖZCuY-O or similar).

### 6.1.1.3 Motor cable data

Table 2. Motor cable sizes, 400–500V

Chassis	Type	I <sub>th</sub>	Motor cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size
				Main terminal [mm <sup>2</sup> ], max.	Earth terminal [mm <sup>2</sup> ]	
CH3	0016_5	16	3*2.5+2.5	50	1–10	(Terminal block)
CH3	0022_5	22	3*4+4	50	1–10	(Terminal block)
CH3	0031	31	3*6+6	50	1–10	(Terminal block)
CH3	0038_5 0045_5	38–45	3*10+10	50 Cu 50 Al	6–35	(Terminal block)
CH3	0061_5	61	3*16+16	50 Cu 50 Al	6–35	(Terminal block)
CH4	0072_5	72	3*25+16	50 Cu 50 Al	6–70	1/M8
CH4	0087_5	87	3*35+16	50 Cu 50 Al	6–70	1/M8
CH4	0105_5	105	3*50+25	50 Cu 50 Al	6–70	1/M8
CH4	0140_5	140	3*70+35	95 Cu/Al	25–95	1/M8
CH5	0168_5	168	3*95+50	185 Cu/Al	25–95	2/M10
CH5	0205_5	205	3*150+70	185 Cu/Al	25–95	2/M10
CH5	0261_5	261	3*185+95	185 Cu/Al	25–95	2/M10
CH61	0300_5	300	2*(3*120+70)	*	25–185	2/M12
CH61	0385_5	385	2*(3*120+70)	*	25–185	2/M12
CH62/72	0460_5	460	2*(3*150+70)	**	25–185	4/M12
CH62/72	0520_5	520	2*(3*185+95)	**	25–185	4/M12
CH62/72	0590_5 0650_5	590 650	3*(3*150+70)	**	25–185	4/M12
CH62/72	0730_5	730	3*(3*150+70)	**	25–185	4/M12
CH63	0820_5	820	3*(3*185+95)	**	****	8/M12
CH63	0920_5	920	4*(3*185+95)	**	****	8/M12
CH63	1030_5	1030	4*(3*185+95)	**	****	8/M12
CH63	1150_5	1150	5*(3*185+95)	**	***	8/M12
CH64	1370_5	1370	5*(3*185+95)	**	***	8/M12
CH64	1640_5	1640	6*(3*185+95)	**	***	8/M12
CH64	2060_5	2060	7*(3*185+95)	**	***	8/M12
CH64	2300_5	2300	8*(3*185+95)	**	***	8/M12
CH74 <sup>1)</sup>	1370_5	1370	5*(3*185+95)	**	***	4/M12
CH74 <sup>1)</sup>	1640_5	1640	6*(3*185+95)	**	***	4/M12

Table 2. Motor cable sizes, 400–500V

Chassis	Type	I <sub>th</sub>	Motor cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size
				Main terminal [mm <sup>2</sup> ], max.	Earth terminal [mm <sup>2</sup> ]	
CH74 <sup>1)</sup>	2060_5	2060	7*(3*185+95)	**	***	4/M12
CH74 <sup>1)</sup>	2300_5	2300	8*(3*185+95)	**	***	4/M12

<sup>1)</sup> Due to insufficient number of terminal bolt connections for required amount of cables, the cabinet must be equipped with an external flexible cable connection block at both mains and motor ends if stiff cable type is used.

### Units with 6-pulse supply

Note that all other sizes have 3 input terminals except for size CH74, which has 9 input terminals.

### Units with 12-pulse supply

12-pulse supply can be used with drives of sizes CH72 and CH74. The number of input terminals for both is 6.

If 12-pulse supply is used, pay also attention to the fuse selection, see page 71 and page 72.

See the tightening torques of bolts in Table 34.

Table 3. Motor cable sizes, 525–690V

Chassis	Type	I <sub>th</sub>	Motor cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size
				Main terminal [mm <sup>2</sup> ], max	Earth terminal [mm <sup>2</sup> ]	
CH61	0170_6	170	3*95+50	185 Cu/Al	25–95	2/M12
CH61	0208_6	208	3*150+70	185 Cu/Al	25–95	2/M12
CH61	0261_6	261	3*185+95	185 Cu/Al 2	25–95	2/M12
CH62/72	0325_6	325	2*(3*95+50)	**	25–185	4/M12
CH62/72	0385_6	385	2*(3*120+70)	**	25–185	4/M12
CH62/72	0416_6	416	2*(3*150+70)	**	25–185	4/M12
CH62/72	0460_6	460	2*(3*185+95)	**	25–185	4/M12
CH62/72	0502_6	502	2*(3*185+95)	**	25–185	4/M12
CH63	0590_6	590	3*(3*150+70)	**	***	8/M12
CH63	0650_6	650	3*(3*150+70)	**	***	8/M12
CH63	0750_6	750	3*(3*185+95)	**	***	8/M12
CH74 <sup>1)</sup>	0820_6	820	4*(3*150+70)	**	***	4/M12
CH74 <sup>1)</sup>	0920_6	920	4*(3*185+95)	**	***	4/M12
CH74 <sup>1)</sup>	1030_6	1030	4*(3*185+95)	**	***	4/M12
CH74 <sup>1)</sup>	1180_6	1180	5*(3*185+95)	**	***	4/M12
CH74 <sup>1)</sup>	1300_6	1300	5*(3*185+95)	**	***	4/M12
CH74 <sup>1)</sup>	1500_6	1500	6*(3*185+95)	**	***	4/M12

Table 3. Motor cable sizes, 525–690V

Chassis	Type	I <sub>th</sub>	Motor cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size	
				Main terminal [mm <sup>2</sup> ], max	Earth terminal [mm <sup>2</sup> ]		
CH74 <sup>1)</sup>	1700_6	1700		Contact factory			

<sup>1)</sup>Due to insufficient number of terminal bolt connections for required amount of cables, the cabinet must be equipped with an external flexible cable connection block at both mains and motor ends if stiff cable type is used.

\* = Number of bolt connections 2

\*\* = Number of bolt connections 4

\*\*\* = Three earthing terminals per mounting plate, see chapter 6.1.7.

\*\*\*\* = Two earthing terminals per mounting plate, see chapter 6.1.7.

See the tightening torques of bolts in Table 34.

#### 6.1.1.4 Mains cable data for frequency converters

Table 4. Mains cable sizes for frequency converters, 400–500V

Chassis	Type	I <sub>th</sub>	Mains cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size
				Main terminal [mm <sup>2</sup> ], max	Earth terminal [mm <sup>2</sup> ]	
CH3	0016_5	16	3*2.5+2.5	50	1–10	(Terminal block)
CH3	0022_5	22	3*4+4	50	1–10	(Terminal block)
CH3	0031	31	3*6+6	50	1–10	(Terminal block)
CH3	0038_5 0045_5	38–45	3*10+10	50 Cu 50 Al	6–35	(Terminal block)
CH3	0061_5	61	3*16+16	50 Cu 50 Al	6–35	(Terminal block)
CH4	0072_5	72	3*25+16	50 Cu 50 Al	6–70	1/M8
CH4	0087_5	87	3*35+16	50 Cu 50 Al	6–70	1/M8
CH4	0105_5	105	3*50+25	50 Cu 50 Al	6–70	1/M8
CH4	0140_5	140	3*70+35	95 Cu/Al	25–95	1/M8
CH5	0168_5	168	3*95+50	185 Cu/Al	25–95	2/M10
CH5	0205_5	205	3*150+70	185 Cu/Al	25–95	2/M10
CH5	0261_5	261	3*185+95	185 Cu/Al	25–95	2/M10
CH61	0300_5	300	2*(3*120+70)	300 Cu/Al	25–185	2/M12
CH61	0385_5	385	2*(3*120+70)	300 Cu/Al	25–185	2/M12
CH72/CH72	0460_5	460	2*(3*150+70)	300 Cu/Al	25–185	2 (or 4)/M12

Table 4. Mains cable sizes for frequency converters, 400–500V

Chassis	Type	$I_{th}$	Mains cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size
				Main terminal [mm <sup>2</sup> ], max	Earth terminal [mm <sup>2</sup> ]	
CH72/CH72	0520_5	520	2*(3*185+95)	300 Cu/Al	25–185	2 (or 4)/M12
CH72	0590_5 0650_5	590 650	2*(3*240+120)	300 Cu/Al	25–185	2/M12
CH72	0590_5 0650_5 0730_5	590 650 730	4*(3*95+50)	300 Cu/Al	25–185	4/M12
CH72 <sup>1)</sup>	0730_5	730	3*(3*150+70)	300 Cu/Al	25–185	2/M12
CH63 <sup>1)</sup>	0820_5	820	3*(3*185+95)	300 Cu/Al	***	2/M12
CH63 <sup>1)</sup>	0920_5 1030_5	920 1030	4*(3*185+95)	300 Cu/Al	***	2/M12
CH63 <sup>1)</sup>	1150_5	1150	4*(3*240+120)	300 Cu/Al	***	2/M12
CH74/ CH74 <sup>1)</sup>	1370_5	1370	6*(3*150+70)	300 Cu/Al	***	6 (or 4)/M12
CH74/ CH74 <sup>1)</sup>	1640_5	1640	6*(3*185+95)	300 Cu/Al	***	6 (or 4)/M12
CH74 <sup>1)</sup>	2060_5	2060	9*(3*150+70)	300 Cu/Al	***	6/M12
CH74 <sup>1)</sup>	2060_5	2060	8*(3*185+95)	300 Cu/Al	***	4/M12
CH74 <sup>1)</sup>	2300_5	2300	9*(3*185+95)	300 Cu/Al	***	6/M12

<sup>1)</sup>Due to insufficient number of terminal bolt connections for required amount of cables, the cabinet must be equipped with an external flexible cable connection block at both mains and motor ends if stiff cable type is used.

Data in *Italic* refer to drives with 12-pulse supply.

### Units with 6-pulse supply

Note that all other sizes have 3 input terminals except for size CH74, which has 9 input terminals. CH74 cables must be connected symmetrically between 3 parallel connected rectifiers in each phase.

### Units with 12-pulse supply

12-pulse supply can be used with drives of sizes CH72 and CH74. The number of input terminals for both is 6.

If 12-pulse supply is used, pay also attention to the fuse selection, see page 71 and page 72.

See the tightening torques of bolts in Table 34.

Table 5. Mains cable sizes, 525–690V

Chassis	Type	$I_{th}$	Mains cable Cu [mm <sup>2</sup> ]	Terminal cable size		Max. number of cables/ Bolt size
				Main terminal [mm <sup>2</sup> ], max.	Earth terminal [mm <sup>2</sup> ]	
CH61	0170_6	170	3*95+50	185 Cu/Al	25–95	2/M12
CH61	0208_6	208	3*150+70	185 Cu/Al	25–95	2/M12
CH61	0261_6	261	3*185+95	185 Cu/Al 2	25–95	2/M12
CH72/CH72	0325_6	325	2*[3*95+50]	300 Cu/Al	25–185	2 (or 4)/M12
CH72/CH72	0385_6	385	2*[3*120+70]	300 Cu/Al	25–185	2 (or 4)/M12
CH72/CH72	0416_6	416	2*[3*150+70]	300 Cu/Al	25–185	2 (or 4)/M12
CH72/CH72	0460_6	460	2*[3*185+95]	300 Cu/Al	25–185	2 (or 4)/M12
CH72/CH72	0502_6	502	2*[3*185+95]	300 Cu/Al	25–185	2 (or 4)/M12
CH63	0590_6 0650_6	590 650	2*[3*240+120]	300 Cu/Al	****	2/M12
CH63 <sup>1)</sup>	0750_6	750	3*[3*185+95]	300 Cu/Al	****	2/M12
CH74	0820_6	820	3*[3*185+95]	300 Cu/Al	***	6/M12
CH74	0820_6	820	4*[3*150+70]	300 Cu/Al	***	4/M12
CH74	0920_6	920	3*[3*240+120]	300 Cu/Al	***	6/M12
CH74	0920_6	920	4*[3*185+95]	300 Cu/Al	***	4/M12
CH74	1030_6	1030	6*[3*95+50]	300 Cu/Al	***	6/M12
CH74	1030_6	1030	4*[3*185+95]	300 Cu/Al	***	4/M12
CH74	1180_6	1180	6*[3*120+95]	300 Cu/Al	***	6/M12
CH74	1180_6 1300_6	1180 1300	4*[3*240+120]	300 Cu/Al	***	4/M12
CH74	1300_6	1300	6*[3*150+95]	300 Cu/Al	***	6/M12
CH74	1500_6	1500	6*[3*185+95]	300 Cu/Al	***	6/M12
CH74 <sup>1)</sup>	1500_6	1500	6*[3*185+95]	300 Cu/Al	***	4/M12
CH74 <sup>1)</sup>	1700_6	1700	Contact factory			

<sup>1)</sup>Due to insufficient number of terminal bolt connections for required amount of cables, the cabinet must be equipped with an external flexible cable connection block at both mains and motor ends if stiff cable type is used.

Data in Italic refer to drives with 12-pulse supply.

### Units with 6-pulse supply

Note that all other sizes have 3 input terminals except for size CH74, which has 9 input terminals.

### Units with 12-pulse supply

12-pulse supply can be used with drives of sizes CH72 and CH74. The number of input terminals for both is 6.

If 12-pulse supply is used, pay also attention to the fuse selection, see page 71 and page 72.

See the tightening torques of bolts in Table 34.

*Table 6. Tightening torques of bolts*

Bolt	Tightening torque [Nm]	Max. inward thread length [mm]
M8	20	10
M10	40	22
M12	70	22
Earthing bolt (see page page 80)	13.5	-

We recommend a low-impedance earthing of the motor cable shield for better performance.

Because of several possible cable installations and environmental conditions, it is very important to consider local regulations and the IEC/EN standards.

#### 6.1.2 DRIVE PROTECTION – FUSES

In order to protect the drive from short-circuits and excessive loads, input line fuses must be used. The warranty becomes void if the drive is not equipped with appropriate fuses.

Depending on the drive configuration, the following types of fuse protection are recommended:

##### Frequency converter with AC supply:

Always protect the drive with fast-acting input line fuses for short-circuit protection. Also pay attention to protection of cables!

##### Common DC bus:

- Inverter units: Choose fuse protection according to Table 37 and Table 38.
- Active Front End (AFE) units: Choose DC fuses according to Table 37 and Table 38; Appropriate fuses for the AC supply are listed in Table 39 and Table 40.
- Inverter units connected to AFE units: Choose fuses for AC supply according to Table 39 and Table 40; NOTE: Protect each inverter unit with fuses according to Table 37 and Table 38.

##### DC links interconnected (e.g. 2\*CH74)

In case interconnection of DC links is required please contact the manufacturer.

##### Brake chopper unit


See chapter 10.

#### 6.1.3 FUSE SIZES

The fuse sizing in the tables below is based on Ferraz aR fuses. We primarily recommend you to use these fuses or corresponding Bussman aR fuses (see Appendix 3 on page 174). Sufficient protection against short-circuit cannot be guaranteed if other fuse types are used. Furthermore, equation of the fuse values given in the tables below with those of other fuse manufacturers is not allowed. In case you wish to use fuses of other fuse manufacturers, contact Vacon.

Ferraz catalog number key:

PC31UD69V500TF



### 6.1.3.1 Frequency converters

Table 7. Fuse sizes for Vacon NX Liquid-Cooled (500V) frequency converters

Chass is	Type	I <sub>th</sub> [A]	Fuse size	DIN43620	DIN43653	TTF	Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses per drive 3~/6~
				aR fuse catalog nr.	aR fuse catalog nr.	aR fuse catalog nr.			
CH3	0016	16	DIN000	NH000UD69V40PV	DN00UB69V40L	PC30UD69V50TF	690	40/50 <sup>1</sup>	3
CH3	0022	22	DIN000	NH000UD69V40PV	DN00UB69V40L	PC30UD69V50TF	690	40/50 <sup>1</sup>	3
CH3	0031	31	DIN000	NH000UD69V63PV	DN00UB69V63L	PC30UD69V63TF	690	63	3
CH3	0038	38	DIN000	NH000UD69V100PV	DN00UB69V100L	PC30UD69V100TF	690	63	3
CH3	0045	45	DIN000	NH000UD69V100PV	DN00UB69V100L	PC30UD69V100TF	690	100	3
CH3	0061	61	DIN00	NH00UD69V125PV	DN00UB69V125L	PC30UD69V125TF	690	100	3
CH4	0072	72	DIN00	NH00UD69V200PV	DN00UB69V200L	PC30UD69V200TF	690	200	3
CH4	0087	87	DIN00	NH00UD69V200PV	DN00UB69V200L	PC30UD69V200TF	690	200	3
CH4	0105	105	DIN00	NH00UD69V200PV	DN00UB69V200L	PC30UD69V200TF	690	200	3
CH4	0140	140	DIN1	NH1UD69V315PV	PC30UD69V315A	PC30UD69V315TF	690	200	3
CH5	0168	168	DIN1	NH1UD69V315PV	PC30UD69V315A	PC30UD69V315TF	690	400	3
CH5	0205	205	DIN1	NH1UD69V400PV	PC30UD69V400A	PC30UD69V400TF	690	400	3
CH5	0261	261	DIN2	NH2UD69V500PV	PC31UD69V500A	PC31UD69V500TF	690	400	3
CH61	0300	300	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	3
CH61	0385	385	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	3
CH72	0460	460	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	3
CH72 <sup>2</sup>	0460	460	DIN2	NH2UD69V500PV	PC31UD69V500A	PC31UD69V500TF	690	700	6
CH72	0520	520	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	3
CH72 <sup>2</sup>	0520	520	DIN2	NH2UD69V500PV	PC31UD69V500A	PC31UD69V500TF	690	700	6
CH72	0590	590	DIN3	PC73UB69V1100PA	PC33UD69V1100A	PC33UD69V1100TF	690	1000	3
CH72 <sup>2</sup>	0590	590	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	6
CH72	0650	650	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	3
CH72 <sup>2</sup>	0650	650	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	6
CH72	0730	730	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	3
CH72 <sup>2</sup>	0730	730	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	6
CH63	0820	820	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	6
CH63	0920	920	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	800	6
CH63	1030	1030	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	6
CH63	1150	1150	DIN3	PC73UB69V1100PA	PC33UD69V1100A	PC33UD69V1100TF	690	1000	6
CH74	1370	1370	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	9
CH74 <sup>2</sup>	1370	1370	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC73UB69V13CTF	690	800	6
CH74	1640	1640	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	9
CH74 <sup>2</sup>	1640	1640	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	12
CH74	2060	2060	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	9
CH74 <sup>2</sup>	2060	2060	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	12
CH74	2300	2300	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	9
CH74 <sup>2</sup>	2300	2300	DIN3	PC73UB69V1100PA	PC33UD69V1100A	PC33UD69V1100TF	690	1000	12

<sup>1</sup> Fuse current (I<sub>n</sub>) 50A for TTF aR fuse.

<sup>2</sup> Data in Italic refer to drives with 12-pulse supply

Table 8. Fuse sizes for Vacon NX Liquid-Cooled (690V) frequency converters

Chassis	Type	I <sub>th</sub> [A]	Fuse size	DIN43620	DIN43653	TTF	Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses per drive 3~/6~
				aR fuse part nr.	aR fuse part nr.	aR fuse part nr.			
CH61	0170	170	DIN1	NH1UD69V315PV	PC30UD69V315A	PC30UD69V315TF	690	315	3
CH61	0208	208	DIN1	NH1UD69V400PV	PC30UD69V400A	PC30UD69V400TF	690	400	3
CH61	0261	261	DIN2	NH2UD69V500PV	PC31UD69V500A	PC31UD69V500TF	690	500	3
CH72	0325	325	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	3
CH72 <sup>1</sup>	0325	325	DIN1	NH1UD69V315PV	PC30UD69V315A	PC30UD69V315TF	690	315	6
CH72	0385	385	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	3
CH72 <sup>1</sup>	0385	385	DIN1	NH1UD69V400PV	PC30UD69V400A	PC30UD69V400TF	690	400	6
CH72	0416	416	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	3
CH72 <sup>1</sup>	0416	416	DIN1	NH1UD69V400PV	PC30UD69V400A	PC30UD69V400TF	690	400	6
CH72	0460	460	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	3
CH72 <sup>1</sup>	0460	460	DIN1	NH1UD69V400PV	PC30UD69V400A	PC30UD69V400TF	690	400	6
CH72	0502	502	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	3
CH72 <sup>1</sup>	0502	502	DIN2	NH2UD69V500PV	PC31UD69V500A	PC31UD69V500TF	690	500	6
CH63	0590	590	DIN3	PC73UB69V1100PA	PC33UD69V1100A	PC33UD69V1100TF	690	1100	3
CH63	0650	650	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	3
CH63	0750	750	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	3
CH74	0820	820	DIN2	NH2UD69V500PV	PC31UD69V500A	PC31UD69V500TF	690	500	9
CH74 <sup>1</sup>	0820	820	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	6
CH74	0920	920	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	9
CH74 <sup>1</sup>	0920	920	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	6
CH74	1030	1030	DIN2	NH2UD69V700PV	PC31UD69V700A	PC31UD69V700TF	690	700	9
CH74 <sup>1</sup>	1030	1030	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	6
CH74	1180	1180	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	9
CH74 <sup>1</sup>	1180	1180	DIN3	PC73UB69V1100PA	PC33UD69V1100A	PC33UD69V1100TF	690	1100	6
CH74	1300	1300	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	9
CH74 <sup>1</sup>	1300	1300	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	6
CH74	1500	1500	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	9
CH74 <sup>1</sup>	1500	1500	DIN3	PC73UB69V1250PA	PC33UD69V1250A	PC33UD69V1250TF	690	1250	6
CH74	1700	1700	DIN3	NH3UD69V1000PV	PC33UD69V1000A	PC33UD69V1000TF	690	1000	9
CH74 <sup>1</sup>	1700	1700	DIN3	NH3UD69V800PV	PC32UD69V800A	PC32UD69V800TF	690	800	12

<sup>1</sup> Data in Italic refer to drives with 12-pulse supply

### Fuse information

The values in tables are based on max ambient temperature of +50°C.

Fuse sizes can differ in the same chassis. Fuses can be chosen according to the biggest current rating of the chassis to minimize fuse variants. Make sure that the Isc of the supply transformer is high enough to burn fuses fast enough.

Check the current rating of the fuse bases according to the input current of the drive.

The physical size of the fuse is chosen on the basis of the fuse current: Current > 400 amps (size 2 fuse or smaller), current < 400 amps (size 3 fuse). The aR fuses are thermally rated into switch fuse in 50 degrees ambient temperature.

### 6.1.3.2 Fuse sizes, inverters

Each DC supply line must be equipped with an aR fuse according to the tables below.

*Table 9. Fuse sizes for Vacon NX Liquid-Cooled (450–800V) inverters*

Chassis	Type	I <sub>th</sub> [A]	DIN43620			"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts		Fuse I <sub>n</sub> [A]
			Fuse size	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	
CH3	0016	16	DINO	PC70UD13C50PA	2	PC70UD13C50TF	2	-	-	50
CH3	0022	22	DINO	PC70UD13C50PA	2	PC70UD13C50TF	2	-	-	50
CH3	0031	31	DINO	PC70UD13C80PA	2	PC70UD13C63TF	2	-	-	80/63
CH3	0038	38	DINO	PC70UD13C80PA	2	PC70UD13C80TF	2	-	-	125
CH3	0045	45	DINO	PC70UD13C125PA	2	PC70UD13C125TF	2	-	-	125
CH3	0061	61	DINO	PC70UD13C125PA	2	PC70UD13C125TF	2	-	-	125
CH4	72	72	DINO	PC70UD13C200PA	2	PC70UD13C200TF	2	-	-	200
CH4	0087	87	DINO	PC70UD13C200PA	2	PC70UD13C200TF	2	-	-	200
CH4	0105	105	DINO	PC70UD13C200PA	2	PC70UD13C200TF	2	-	-	200
CH4	0140	140	DIN1	PC71UD13C315PA	2	PC71UD13C315TF	2	-	-	315
CH5	0168	168	DIN1	PC71UD13C315PA	2	PC71UD13C315TF	2	-	-	315
CH5	0205	205	DIN1	PC71UD13C400PA	2	PC71UD13C400TF	2	-	-	400
CH5	0261	261	DIN3	PC73UD13C500PA	2	PC73UD13C500TF	2	-	-	500
CH61	0300	300	DIN3	PC73UD13C630PA	2	PC73UD13C630TF	2	-	-	630
CH61	0385	385	DIN3	PC73UD11C800PA	2	PC73UD13C800TF	2	-	-	800
CH62	460	460	DIN3	PC73UD90V11CPA	2	PC73UD95V11CTF	2	-	-	1100
CH62	520	520	DIN3	PC73UD90V11CPA	2	PC73UD95V11CTF	2	-	-	1100
CH62	590	590	DIN3	PC73UD13C630PA	4	PC73UD95V11CTF	2	-	-	630/ 1100
CH62	650	650	DIN3	PC73UD13C630PA	4	PC83UD11C13CTF	2	-	-	630/ 1300
CH62	730	730	DIN3	PC73UD11C800PA	4	PC83UD11C13CTF	2	-	-	800/ 1300
CH63	0820	820	DIN3	PC73UD11C800PA	4	PC73UD13C800TF	4	PC84UD13 C15CTQ	2	800/ 1500
CH63	0920	920	DIN3	PC73UD90V11CPA	4	PC73UD95V11CTF	4	PC84UD12 C18CTQ	2	1100/ 1800
CH63	1030	1030	DIN3	PC73UD90V11CPA	4	PC73UD13C800TF	4	PC84UD11 C20CTQ	2	1100/ 800/ 2000
CH63	1150	1150	-	-	-	PC83UD11C13CTF	4	PC84UD11 C22CTQ	2	1300/ 2200
CH64	1370	1370	-	-	-	PC83UD11C14CTF	4	PC84UD10 C27CTQ	2	1400/ 2700
CH64	1640	1640	-	-	-	PC73UD13C800TF	8	PC87UD12 C30CP50	2	800/ 3000

Table 9. Fuse sizes for Vacon NX Liquid-Cooled (450–800V) inverters

Chassis	Type	$I_{th}$ [A]	DIN43620			"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts		Fuse $I_n$ [A]
			Fuse size	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	
CH64	2060	2060	-	-	-	PC73UD95V11CTF	8	PC87UD11C38CP50	2	1100/ 3800
CH64	2300	2300	-	-	-	PC73UD95V11CTF	8	PC87UD10C44CP50	2	1100/ 4400

Table 10. Fuse sizes for Vacon NX Liquid-Cooled (640–1100V) inverters

Chassis	Type	$I_{th}$ [A]	DIN43620			"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts		Fuse $I_n$ [A]
			Fuse size	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	
CH61	0170	170	DIN1	PC71UD13C400PA	2	PC71UD13C400TF	2	-	-	400
CH61	0208	208	DIN1	PC71UD13C400PA	2	PC71UD13C400TF	2	-	-	400
CH61	0261	261	DIN1	PC73UD13C500PA	2	PC73UD13C500TF	2	-	-	500
CH62	0325	325	DIN3	PC73UD13C630PA	2	PC73UD13C630TF	2	-	-	630
CH62	0385	385	DIN3	PC73UD11C800PA	2	PC73UD13C800TF	2	-	-	800
CH62	0416	416	DIN3	PC73UD11C800PA	2	PC73UD13C800TF	2	-	-	800
CH62	0460	460	DIN3	PC73UD10C900PA	2	PC73UD12C900TF	2	-	-	900
CH62	0502	502	DIN3	PC73UD10C900PA	2	PC73UD12C900TF	2	-	-	900
CH63	0590	590	DIN3	PC73UD13C630PA	4	PC83UD12C11CTF	2	-	-	630/ 1100
CH63	0650	650	DIN3	PC73UD13C630PA	4	PC83UD11C13CTF	2	-	-	630/ 1300
CH63	0750	750	DIN3	PC73UD11C800PA	4	PC83UD11C14CTF	2	-	-	800/ 1400
CH64	0820	820	DIN3	PC73UD11C800PA	4	PC73UD13C800TF	4	PC84UD13C15CTQ	2	800/ 1500
CH64	0920	920	DIN3	PC73UD10C900PA	4	PC73UD12C900TF	4	PC84UD12C18CTQ	2	900/ 1800
CH64	1030	1030	-	-	-	PC83UD12C11CTF	4	PC84UD11C20CTQ	2	1100/ 2000
CH64	1180	1180	-	-	-	PC83UD12C11CTF	4	PC84UD11C22CTQ	2	1100/ 2200
CH64	1300	1300	-	-	-	PC83UD11C13CTF	4	PC84UD11C24CTQ	2	1300/ 2400

Table 10. Fuse sizes for Vacon NX Liquid-Cooled (640–1100V) inverters

Chassis	Type	I <sub>th</sub> [A]	DIN43620			"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts		Fuse I <sub>n</sub> [A]
			Fuse size	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	aR fuse part nr.	Fuses needed per drive	
CH64	1500	1500	-	-	-	PC83UD11C14CTF	4	PC87UD12C30CP50	2	1400/3000
CH64	1700	1700	-	-	-	PC73UD12C900TF	8	PC87UD11C34CP50	2	900/3400
CH64	1900	1900	-	-	-	PC73UD12C900TF	8	PC87UD11C34CP50	2	900/3400

**Fuse information**

The values in tables are based on max ambient temperature of +50°C.

Fuse sizes can differ in the same chassis. Fuses can be chosen according to the biggest current rating of the chassis to minimize fuse variants. Make sure that the I<sub>sc</sub> of the supply transformer is high enough to burn fuses fast enough.

Check the current rating of the fuse bases according to the input current of the drive.

The physical size of the fuse is chosen on the basis of the fuse current: Current < 250 amps (size 1 fuse), current > 250 amps (size 3 fuse).

The aR fuses are thermally rated into switch fuse in 50 degree ambient temperature.

**6.1.3.3    Fuse sizes, Active Front End units (AC supply)**

Table 11. Fuse sizes for Vacon NX AFE units (380–500V)

Chassis	Type	I <sub>th</sub> [A]	Fuse size	DIN43620		'TTF' threaded end		'TTF' threaded end		Qty. of fuses / drive 3~
				aR fuse part nr.	aR fuse part nr.	aR fuse part nr.	aR fuse part nr.	aR fuse part nr.	aR fuse part nr.	
CH3	0016	16	DIN000	NH000UD69V40PV	PC30UD69V50TF	-	-	-	-	3
CH3	0022	22	DIN000	NH000UD69V40PV	PC30UD69V50TF	-	-	-	-	3
CH3	0031	31	DIN000	NH000UD69V63PV	PC30UD69V63TF	-	-	-	-	3
CH3	0038	38	DIN000	NH000UD69V100PV	PC30UD69V100TF	-	-	-	-	3
CH3	0045	45	DIN000	NH000UD69V100PV	PC30UD69V100TF	-	-	-	-	3
CH3	0061	61	DIN00	NH00UD69V125PV	PC30UD69V125TF	-	-	-	-	3
CH4	0072	72	DIN00	NH00UD69V200PV	PC30UD69V200TF	-	-	-	-	3
CH4	0087	87	DIN00	NH00UD69V200PV	PC30UD69V200TF	-	-	-	-	3
CH4	0105	105	DIN00	NH00UD69V200PV	PC30UD69V200TF	-	-	-	-	3
CH4	0140	140	DIN1	NH1UD69V315PV	PC30UD69V315TF	-	-	-	-	3
CH5	0168	168	DIN1	NH1UD69V315PV	PC30UD69V315TF	-	-	-	-	3
CH5	0205	205	DIN1	NH1UD69V400PV	PC30UD69V400TF	-	-	-	-	3
CH5	0261	261	DIN2	NH2UD69V500PV	PC31UD69V500TF	-	-	-	-	3
CH61	0300	300	DIN3	NH3UD69V630PV	PC32UD69V630TF	-	-	-	-	3
CH61	0385	385	DIN3	NH3UD69V630PV	PC32UD69V630TF	-	-	-	-	3

Table 11. Fuse sizes for Vacon NX AFE units (380—500V)

Chassis	Type	I <sub>th</sub> [A]	Fuse size	DIN43620	'TTF' threaded end	'TTF' threaded end	Qty. of fuses / drive 3~
				aR fuse part nr.	aR fuse part nr.	aR fuse part nr.	
CH62	0460	460	DIN3	NH3UD69V1000PV	PC33UD69V1000TF	-	3
CH62	0520	520	DIN3	NH3UD69V1000PV	PC33UD69V1000TF	-	3
CH62	0590	590	DIN3	PC73UB69V1100PA	PC33UD69V1100TF	-	3
CH62	0650	650	DIN3	PC73UB69V1250PA	PC33UD69V1250TF	-	3
CH62	0730	730	DIN3	PC73UB69V1250PA	PC33UD69V1250TF	-	3
CH63	0820	820	DIN3	NH3UD69V800PV	PC32UD69V800TF	PC44UD75V16CTQ	6 {3}
CH63	0920	920	DIN3	NH3UD69V1000PV	PC33UD69V1000TF	PC44UD75V16CTQ	6 {3}
CH63	1030	1030	DIN3	NH3UD69V1000PV	PC33UD69V1000TF	PC44UD75V18CTQ	6 {3}
CH63	1150	1150	DIN3	PC73UB69V1100PA	PC33UD69V1100TF	PC44UD75V20CTQ	6 {3}
CH64	1370	1370	DIN3	NH3UD69V1000PV	PC33UD69V1000TF	PC44UD75V24CTQ	9 {3 <sup>1</sup> }
CH64	1640	1640	DIN3	NH3UD69V1000PV	PC33UD69V1000TF	PC44UD70V27CTQ	9 {3 <sup>1</sup> }
CH64	2060	2060	DIN3	PC73UB69V1250PA	PC33UD69V1250TF	PC44UD69V34CTQB	9 {3 <sup>1</sup> }
CH64	2300	2300	DIN3	PC73UB69V1250PA	PC33UD69V1250TF	PC47UD70V36CP50	9 {3 <sup>1</sup> }

Table 12. Fuse sizes for Vacon NX AFE units (525—690V)

Chassis	Type	I <sub>th</sub> [A]	DIN43620		TTF threaded end "7X" or size 83 with end contacts	TTF threaded end contacts in size 83 or size 84	Qty. of fuses / drive 3~
			Fuse size	aR fuse part nr.			
CH61	0170	170	DIN1	PC71UD13C315PA	PC71UD13C315TF	-	3
CH61	0208	208	DIN1	PC71UD13C400PA	PC71UD13C400TF	-	3
CH61	0261	261	DIN1	PC73UD13C500PA	PC73UD13C500TF	-	3
CH62	0325	325	DIN3	PC73UD13C630PA	PC73UD13C630TF	-	3
CH62	0385	385	DIN3	PC73UD13C630PA	PC73UD13C630TF	-	3
CH62	0416	416	DIN3	PC73UD11C800PA	PC73UD13C800TF	-	3
CH62	0460	460	DIN3	PC73UD11C800PA	PC73UD13C800TF	-	3
CH62	0502	502	DIN3	PC73UD10C900PA	PC73UD13C800TF	-	3
CH63	0590	590	DIN3	PC73UD90V11CPA	PC73UD95V11CTF	-	3
CH63	0650	650	DIN3	PC73UD90V11CPA	PC73UD95V11CTF	-	3
CH63	0750	750	DIN3	PC73UD13C630PA	PC73UD13C630TF	PC83UD11C13CTF	6{3} <sup>1</sup>
CH64	0820	820	DIN3	PC73UD11C800PA	PC73UD13C800TF	PC83UD11C14CTF	6{3} <sup>1</sup>
CH64	0920	920	DIN3	PC73UD11C800PA	PC73UD13C800TF	PC83UD95V16CTF	6{3} <sup>1</sup>
CH64	1030	1030	DIN3	PC73UD90V11CPA	PC73UD95V11CTF	PC84UD12C18CTQ	6{3} <sup>1</sup>
CH64	1180	1180	DIN3	PC73UD90V11CPA	PC73UD95V11CTF	PC84UD11C20CTQ	6{3} <sup>1</sup>
CH64	1300	1300	DIN3	PC73UD11C800PA	PC73UD13C800TF	PC84UD11C22CTQ	9{3} <sup>1</sup>
CH64	1500	1500	DIN3	PC73UD90V11CPA	PC73UD95V11CTF	PC84UD11C24CTQ	9{3} <sup>1</sup>
CH64	1700	1700	DIN3	PC73UD90V11CPA	PC73UD95V11CTF	PC84UD90V30CTQ	9{3} <sup>1</sup>

For DC fuse selection use table for liquid cooled inverters (page 73).

<sup>1</sup> Quantity of fuses needed of TTF types PC4\*\*\*\*\* and PC8\*\*\*\*\*.

#### 6.1.4 CABLE INSTALLATION INSTRUCTIONS

<b>1</b>	Before starting the installation, check that none of the components of the frequency converter is live.						
<b>2</b>	Vacon NX Liquid-Cooled drive must always be installed in an enclosure, a separate cubicle or an electrical room. Always use a jib crane or similar lifting device to lift the drive. For safe and appropriate lifting, see chapter 5.1.1.						
<b>3</b>	<p>Place the motor cables far enough from other cables:</p> <ul style="list-style-type: none"> <li>Avoid placing the motor cables in long parallel lines with other cables</li> <li>If the motor cables run in parallel with other cables, note the minimum distances between the motor cables and other cables given in table below.</li> <li>The given distances also apply between the motor cables and signal cables of other systems.</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center; background-color: black; color: white;">Distance between parallelly running cables [m]</th> <th style="text-align: center; background-color: black; color: white;">Shielded cable [m]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0.3</td> <td style="text-align: center;">≤50</td> </tr> <tr> <td style="text-align: center;">1.0</td> <td style="text-align: center;">≤200</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li>The maximum length of the motor cables is 300 m.</li> <li>The motor cables should cross other cables at an angle of 90 degrees.</li> </ul>	Distance between parallelly running cables [m]	Shielded cable [m]	0.3	≤50	1.0	≤200
Distance between parallelly running cables [m]	Shielded cable [m]						
0.3	≤50						
1.0	≤200						
<b>4</b>	If cable insulation checks are needed, see Chapter 6.1.10.						
<b>5</b>	<p>Connect the cables/busbars:</p> <ul style="list-style-type: none"> <li>For chassis CH5 and greater, an external flexible cable connection block must be used at both mains and motor ends if stiff cable type (EMCMK, MCMK) is used. See chapter 6.1.1.</li> <li>Strip the cables at a sufficient distance if needed</li> <li>Connect the mains, motor and control cables to their respective terminals (see chapter 5.1.2). If busbar connection is used, bolt the bars and the terminals together. See bolt sizes on page 32 to page 44.</li> <li>Take the maximum terminal stresses shown in Figure 38 into account</li> <li>For information on cable installation according to UL regulations see Chapter 6.1.9.</li> <li>Make sure that the control cable wires do not come in contact with the electronic components of the unit.</li> <li>If an external brake resistor (option) is used, connect its cable to the appropriate terminal.</li> <li>Check the connection of the earth cable to the motor and the frequency converter terminals marked with .</li> <li>Connect the separate shield of the power cable to the earth terminals of the frequency converter, motor and the supply centre.</li> <li>•</li> </ul>						
<b>6</b>	Clamp the motor cables to the cabinet frame as instructed in Figure 37.						


**7****Liquid cooling connection:**

The standard delivery of the Vacon NX Liquid-Cooled drive includes hoses on the cooling element 1.5m in length and 15mm in diameter. The hoses are inserted in 1400-mm UL94V0 approved conduits. Connect the line hose branch to its counterpart (screw or fast connector) on the of the Vacon Liquid-Cooled drive.

Due to high pressure in the line hose, it is recommended to equip the liquid line with a shut-off valve, which makes the connection easier. In order to prevent water from spraying in the installation room we also recommend to wrap e.g. linters around the connection on installing. For more information on the liquid connection, see chapter 5.2.2.


When the installation in the enclosure is completed the liquid pump can be started. See Commissioning of the frequency converter on page 137.

**NOTE:** Do not switch on the power before ensuring the proper functioning of the liquid cooling system.



*Figure 1. Clamping the motor cables to cabinet frame*


VANXPLC\_1035\_INS\_uk



*Figure 2. Maximum terminal stresses*

#### 6.1.5 SUPPLY BUSBARS FOR INVERTER UNITS

In order to avoid excessive terminal stresses on busbar terminals on inverter units with DC-supply on top (CH61...CH64), use flexible busbar connection. See figure below. The maximum terminal stresses are shown in Figure 38.



*Figure 3. Mounting of flexible busbar*


### 6.1.6 INSTALLATION SPACE

Enough free space shall be left above and below the frequency converter/inverter to ensure practical and appropriate electrical and cooling connections. The minimum dimensions are given in the table below. The space left and right to the drive may be 0 mm.

*Table 13. Installation space*

Chassis	A [mm]	B [mm]
CH3	100	150
CH4	100	200
CH5	100	200
CH61	100	300
CH62	100	400*
CH63	200	400*
CH64	200	500*
CH72	200	400*
CH74	200	500*

\*Distance to the cable connection block.  
Additional space must be reserved for possibly used ferrite rings. See chapter 6.1.1.2.




### 6.1.7 EARTHING OF POWER UNIT

The mains cables are connected to the protective earth of the switchgear enclosure.

We recommend to connect the motor cables to the common PE of the cabinet/cabinet system.

For earthing of the drive itself, use the earthing terminal on the drive mounting plate (see Figure 40) and tighten the earthing bolt to 13.5 Nm.




*Figure 4. Earthing terminal on mounting plate*

### 6.1.8 INSTALLATION OF FERRITE RINGS (OPTION) ON THE MOTOR CABLE

Slip only the phase conductors through the window; leave the cable screen below and outside the rings, see Figure 41. Separate the PE conductor. In case of parallel motor cables, reserve an equal amount of ferrite rings for each cable and feed all the phase conductors of one cable through one set of rings. The Vacon delivery includes fixed sets of ferrite rings.

When ferrite rings are used to attenuate the risk of bearing damages, the number of ferrites has to be 6...10 for a single motor cable and 10 per cable when the motor is supplied with parallel cables.

**NOTE!** The ferrite rings are only additional protection. The basic protection against bearing currents is an insulated bearing.



VANXPLC\_1040\_INS\_uk

Figure 5. Installation of ferrite rings

### 6.1.9 CABLE INSTALLATION AND THE UL STANDARDS

To meet the UL (Underwriters Laboratories) regulations, a UL-approved copper cable with a minimum heat-resistance of 90°C must be used.

Use Class 1 wire only.

The units are suitable for use on a circuit capable of delivering not more than 100,000 rms symmetrical amperes, 600V maximum.

The tightening torques of the terminals are given in Table 34.

**6.1.10 CABLE AND MOTOR INSULATION CHECKS****1. Motor cable insulation checks**

Disconnect the motor cable from terminals U, V and W of the frequency converter and from the motor. Measure the insulation resistance of the motor cable between each phase conductor as well as between each phase conductor and the protective ground conductor.

**2. Mains cable insulation checks**

Disconnect the mains cable from terminals L1, L2 and L3 of the frequency converter and from the mains. Measure the insulation resistance of the mains cable between each phase conductor as well as between each phase conductor and the protective ground conductor.

The insulation resistance must be at least  $1\dots2\text{M}\Omega$ .

**3. Motor insulation checks**

Disconnect the motor cable from the motor and open the bridging connections in the motor connection box. Measure the insulation resistance of each motor winding. The measurement voltage must equal at least the motor nominal voltage but not exceed 1000V. The insulation resistance must be at least  $1\dots2\text{M}\Omega$ .

## 6.2 CONTROL UNIT

The control unit of Vacon NX Liquid-Cooled frequency converter/inverter is installed into a mounting box. It contains the control board and additional boards (see Figure 42 and Figure 43) connected to the five *slot connectors* (A to E) of the control board. The control unit and the ASIC of the power unit are connected through cables (and an adapter board). For more information, see page 96.

The mounting box with the control unit is mounted inside an enclosure. See the mounting instructions on page 92.




Figure 6. NX control board





Figure 7. Basic and option board connections on the control board

Usually, when the frequency converter is delivered from the factory, the control unit includes at least the standard compilation of two basic boards (I/O board and relay board) which are normally installed in slots A and B. On the next pages you will find the arrangement of the control I/O and the relay terminals of the two basic boards, the general wiring diagram and the control signal descriptions. The I/O boards mounted at the factory are indicated in the type code.

The control board can be powered externally (+24V, ±10%) by connecting the external power source to either of the bidirectional terminal #6 or #12, see page 88. This voltage is sufficient for parameter setting and for keeping the fieldbus active.

**NOTE!** If the 24V inputs of several frequency converters are parallelly connected we recommend to use a diode in terminal #6 (or #12) in order to avoid the current to flow in opposite direction. This might damage the control board. See picture below.




VANXPLC\_1043\_INS\_uk

### 6.2.1 CONTROL BOARD POWER-UP


The control board can be powered (+24V) in two different ways: either 1) directly from the power board ASIC, terminal X10 or/and 2) externally using the customer's own power source. The two ways of supplying the board can be used simultaneously. This voltage is sufficient for parameter setting and for keeping the fieldbus active.

By factory default, the control unit is powered using the terminal X10 on the power board. However, if an external supply is used to power up the control unit, a load resistor must be connected to terminal X10 on the power board. This applies to all chassis  $\geq$  CH61.

**IMPORTANT NOTE FOR CHASSIS CH3, CH4 and CH5:** If you power the control board from the power board be sure to connect the cable to the correct terminal. Terminal J2 on the power board is reserved for this purpose. Do not connect the cable to terminal J1. See pictures below.



VANXPLC\_1044\_INS\_uk



VANXPLC\_1045\_INS\_uk

Figure 8. Connection of control board power cable from the power board. WRONG: terminal J1 (upper); CORRECT: terminal J2 (lower)

### 6.2.2 CONTROL CONNECTIONS

The basic control connections for boards A1 and A2 are shown in Chapter 6.2.3.

The signal descriptions are presented in the All in One Application Manual.




Figure 9. The I/O terminals of the two basic boards





Figure 10. General wiring diagram of the basic I/O board (OPT-A1)



*Figure 11. General wiring diagram of the basic relay board (OPT-A2)*


### 6.2.2.1 Control cables

The control cables shall be at least 0.5 mm<sup>2</sup> screened multicore cables, see Table 29. The maximum terminal wire size is 2.5 mm<sup>2</sup> for the relay terminals and 1.5 mm<sup>2</sup> for other terminals.

### 6.2.2.2 Galvanic isolation barriers

The control connections are isolated from the mains potential and the GND terminals are permanently connected to ground. See Figure 48.

The digital inputs are galvanically isolated from the I/O ground. The relay outputs are additionally double-isolated from each other at 300VAC (EN-50178).



*Figure 12. Galvanic isolation barriers*

## 6.2.3 CONTROL TERMINAL SIGNALS

Table 14. Control I/O terminal signals

Terminal	Signal	Technical information
<b>OPT-A1</b>		
1	+10 Vref	Reference voltage Maximum current 10 mA
2	AI1+	Analogue input, voltage or current Selection V or mA with jumper block X1 (see page 91): Default:0– +10V ( $R_i = 200 \text{ k}\Omega$ ) (-10V.....+10V Joy-stick control, selected with a jumper) 0– 20mA ( $R_i = 250 \Omega$ )
3	GND/AI1-	Analogue input common Differential input if not connected to ground; Allows ±20V differential mode voltage to GND
4	AI2+	Analogue input, voltage or current Selection V or mA with jumper block X2 (see page 91): Default:0– 20mA ( $R_i = 250 \Omega$ ) 0– +10V ( $R_i = 200 \text{ k}\Omega$ ) (-10V.....+10V Joy-stick control, selected with a jumper)
5	GND/AI2-	Analogue input common Differential input if not connected to ground; Allows ±20V differential mode voltage to GND
6	24 Vout (bidirec-tional)	±15%, maximum current 250 mA Can also be used as external power backup for the control unit (and fieldbus)
7	GND	I/O ground Ground for reference and controls
8	DIN1	Digital input 1 $R_i = \text{min. } 5\text{k}\Omega$ 18...30V = "1"
9	DIN2	Digital input 2
10	DIN3	Digital input 3
11	CMA	Digital input common A for DIN1, DIN2 and DIN3. Must be connected to GND or 24V of I/O terminal or to external 24V or GND Selection with jumper block X3 (see page 91):
12	24 Vout (bidirec-tional)	Same as terminal #6
13	GND	I/O ground Same as terminal #7
14	DIB4	Digital input 4 $R_i = \text{min. } 5\text{k}\Omega$
15	DIB5	Digital input 5
16	DIB6	Digital input 6
17	CMB	Digital input common B for DIB4, DIB5 and DIB6 Must be connected to GND or 24V of I/O terminal or to external 24V or GND Selection with jumper block X3 (see page 91):
18	A01+	Analogue signal (+output) Output signal range: Current 0(4)–20mA, $R_L$ max 500Ω or Voltage 0–10V, $R_L > 1\text{k}\Omega$
19	A01-	Analogue output com-mon Selection with jumper block X6 (see page 91):
20	D01	Open collector output Maximum $U_{in} = 48\text{VDC}$ Maximum current = 50 mA

Table 14. Control I/O terminal signals

Terminal	Signal	Technical information		
OPT-A2				
21	R01/1	Relay output 1	Max. switching voltage	250VAC, 125VDC
22	R01/2		Max. switching current	8A/24VDC, 0.4A/250VDC
23	R01/3		Min. switching load	5V/10mA
24	R02/1	Relay output 2	Max. switching voltage	250VAC, 125VDC
25	R02/2		Max. switching current	8A/24VDC, 0.4A/250VDC
26	R02/3		Min. switching load	5V/10mA

#### 6.2.3.1 Digital input signal inversions

The active signal level depends on which potential the common inputs CMA and CMB (terminals 11 and 17) are connected to. The alternatives are either +24V or ground (0 V). See Figure 49.

The 24-volt control voltage and the ground for the digital inputs and the common inputs (CMA, CMB) can be either internal or external.





Figure 13. Positive/Negative logic

### 6.2.3.2 Jumper selections on the OPT-A1 basic board


The user is able to customise the functions of the frequency converter to better suit his needs by selecting certain positions for the jumpers on the OPT-A1 board. The positions of the jumpers determine the signal type of analogue and digital inputs.

On the A1 basic board, there are four jumper blocks X1, X2, X3 and X6 each containing eight pins and two jumpers. The selectable positions of the jumpers are shown in Figure 51.



VANXPLC\_1051\_INS\_uk

Figure 14. Jumper blocks on OPT-A1




VANXPLC\_1052\_INS\_uk

Figure 15. Jumper selection for OPT-A1



If you change the AI/AO signal content also remember to change the corresponding board parameter in menu M7.

### 6.2.4 CONTROL UNIT MOUNTING BOX



*Figure 16. Control unit mounting box dimensions*

#### 6.2.4.1 Installing the control unit mounting box

The control unit of Vacon NX Liquid-Cooled drive is mounted into a metal box which then can be placed inside the enclosure. Vacon alpha-numeric or graphical keypad can be used to control the drive. The keypad is connected to the control unit with an RS232 cable and mounted on the enclosure door. Pay special attention to the earthing of the cable, see instructions below.



*Figure 17. Control unit installed into the mounting box; Left: front; Right: back*

1. If the keypad sits in its place on the control unit, remove the keypad.
2. Connect the male end of the keypad cable to the D-connector of the control unit. Use Vacon RS232 cable included in the delivery. Figure 1.
3. Run the cable over the top of the box and secure with plastic band on the backside. Figure 2.
4. Earthing of keypad cable: Earth the keypad cable in the mounting box frame by fixing the branch cable with a screw underneath the control unit. See figures 3 and 4.

5. Mount the control unit mounting box in the front-left corner of the enclosure using two screws as shown in Figure 5. Note: Do not install the mounting box floating (with e.g. plastic screws). To ensure a proper grounding of the control unit box assembly, Vacon recommends that an additional grounding cable be drawn from the mounting box and connected to the cabinet frame. Use a braided copper cable designed for high-frequency signals. Remember to remove the paint from the enclosure grounding point to ensure proper connection for the grounding cable.
6. Connect the optical cables (or the flat cable) to the power unit. See chapter 6.3.2 and figures 6 and 7.
7. Connect the female end of the keypad cable to keypad on the enclosure door, figure 8. Use a cable channel for the cable run, figure 9.



Figure. 1



Figure. 2



Figure. 3



VANXPLC\_1057\_INS\_uk

Figure. 4



VANXPLC\_1058\_INS\_uk

Figure. 5



VANXPLC\_1059\_INS\_uk

Figure. 6



VANXPLC\_1061\_INS\_uk

Figure. 7



VANXPLC\_1062\_INS\_uk

Figure. 8



VANXPLC\_1063\_INS\_uk

Figure. 9


### 6.3 INTERNAL CONNECTIONS

As a general rule, all internal electrical and communications connections are made at the factory. However, if modules have to be moved, for example, and the connections therefore removed, you will have to re-establish the connections between 1) *the Power Unit ASIC* and *the Driver Board(s)* on the one hand and 2) the Power Unit ASIC and the *Optical Cable Adapter Board* on the other.

#### 6.3.1 CONNECTIONS BETWEEN POWER UNIT ASIC AND DRIVER BOARDS

See the figures and tables on the following pages for the correct connection of internal electrical and communications connections.

**NOTE:** The minimum optical cable bending radius is 50 mm.



VANXPLC\_1064\_INS\_uk

Figure 18. Terminals and connections between ASIC and driver board (CH61, CH62 and CH72)

Terminals on ASIC board		Gate driver signals from ASIC to driver board	
X9	Charge feedback	UH	Connect to UH on driver board
X15	Charging relay output	UL	Connect to UL on driver board
X6	Connect to DC-link on freq. converter	VH	Connect to VH on driver board
X29	Flow supervision input	VL	Connect to VL on driver board
X26	Star Coupler terminal for drives greater than CH61	WH	Connect to WH on driver board
X10	+24V supply voltage to control board	WL	Connect to WL on driver board
X3	Connect to terminal X13 on driver board	<b>Terminal X1 on driver board</b>	
X4	Connect to terminal X14 on driver board	X1	Connect to DC-link on freq. converter
X5	Connect to terminal X15 on driver board		
X1	Driver board fan power connection		

**NOTE:** Terminals X9 and X15 are connected by default. The cable can be removed if the signal is received from other source.




Figure 19. Terminals and connections between ASIC and driver boards (CH63)

Terminals on ASIC board		Gate driver signals from ASIC to driver board	
X9	Charge feedback	UH	Connect to UH on Phase U driver board
X15	Charging relay output	UL	Connect to UL on Phase U driver board
X6	Connect to DC-link on freq. converter	VH	Connect to VH on Phase V/W driver board
X29	Flow supervision input	VL	Connect to VL on Phase V/W driver board
X26	Star Coupler terminal for drives greater than CH61	WH	Connect to WH on Phase V/W driver board
X10	+24V supply voltage to control board	WL	Connect to WL on Phase V/W driver board
X3	Connect to terminal X6 on phase U driver board	Terminal X2 on Phase U driver board	
X4	Connect to terminal X2 on phase V/W driver board	X2	Internal fan power connection for Mod. 1
X5	Connect to terminal X6 on phase V/W driver board		
X1	Internal fan power connection for Mod. 2		

**NOTE:** Terminals X9 and X15 are connected by default. The cable can be removed if the signal is received from other source.




Figure 20. Terminals and connections between ASIC and driver boards (CH64 and CH74)

Terminals on ASIC board		Gate driver signals from ASIC to driver board	
X9	Charge feedback	UH	Connect to UH on Phase U driver board
X15	Charging relay output	UL	Connect to UL on Phase U driver board
X6	Connect to DC-link on freq. converter	VH	Connect to VH on Phase V driver board
X29	Flow supervision input	VL	Connect to VL on Phase V driver board
X26	Star Coupler terminal for drives greater than CH61	WH	Connect to WH on Phase W driver board
X10	+24V supply voltage to control board	WL	Connect to WL on Phase W driver board
Terminal X2 on Phase driver board			
X2	Internal fan power connection		

**NOTE:** Terminals X9 and X15 are connected by default. The cable can be removed if the signal is received from other source.




Figure 21.Terminals and connections between the star-coupler board, ASIC boards and feedback boards (CH64 and CH74)

### 6.3.2 CONNECTIONS BETWEEN POWER UNIT ASIC AND THE CONTROL UNIT

The communication connections between the NX Liquid-Cooled drive power unit and the *control unit* (see chapter 6.2) can be established using either the conventional round cable (standard in chassis CH3, CH4 and CH5) or optical cable (all chassis). Note that for chassis CH61 and greater, only optical cables can be used.

#### 6.3.2.1 Connections with round cable

The communication connection between the drive power unit and the control unit in chassis CH3, CH4 and CH5 are primarily made with conventional round cable and D-connectors at both ends.

Remove the protective cover to reveal the D-connector on the power unit. Connect the one end of the communication cable to the D-connector of the power unit and the other end to the control unit. If the Optical Cable Adapter Board (see below) sits on the D-connector of the control unit you have to remove it first. See Figure 58 below.

#### 6.3.2.2 Connections with optical cable

If optical cables are used to link the power unit and the control board, a special Optical Cable Adapter Board connected to the control board D-connector must be used. To connect the optical cables to the power unit, you will have to remove the protective cover first. See Figure 58. Connect the optical cables as shown in Figure 59. See also chapter 6.2.4, Control unit mounting box.

The maximum length of the optical cable is 10 m.




Figure 22.




Figure 23. Optical cable adapter board

Optical terminals on Optical cable adapter board:

<b>H1</b>	Gate control enable
<b>H2</b>	Phase U control
<b>H3</b>	Phase V control
<b>H4</b>	Phase W control
<b>H5</b>	ADC synchronization
<b>H6</b>	VaconBus data from control board to ASIC
<b>H7</b>	VaconBus data from ASIC to control board

Other terminals on adapter board:

<b>X1</b>	Control board connection
<b>X2</b>	Supply voltage 24Vin (from power unit ASIC)
<b>X3</b>	Supply voltage 24Vin (customer); - Max. current 1A - Terminal #1: + - Terminal #2: -

**NOTE:** The minimum optical cable bending radius is 50 mm.

**NOTE:** Terminals *X2* and *X3* can be in use simultaneously. However, if the +24V supply from the control I/O terminals (e.g. from board OPT-A1) is used, this terminal must be protected with a diode.

### 6.3.3 CONNECTIONS BETWEEN MAINS DEVICE AND INVERTER POWER MODULE

The dimensions in the table below shall be taken into account if some kind of mains device (e.g. fuse, switch fuse, contactor) is used in the input line between the mains and the Vacon Liquid-Cooled inverter.

*Table 15. Connections from mains device to drive*

<b>Chassis</b>	<b>Type</b>	<b>Connection</b>		
		<b>Conductor cross section [mm<sup>2</sup>]</b>	<b>Busbar size (flexible connection)</b>	<b>Busbar size (bare Cu)</b>
CH3	0016_5	6		
	0022_5			
	0031_5			
CH3	0038_5	10		
	0045_5			
	0061_5			

Table 15. Connections from mains device to drive

Chassis	Type	Connection		
		Conductor cross section [mm <sup>2</sup> ]	Busbar size (flexible connection)	Busbar size (bare Cu)
CH4	0072_5	25	2*24*1	1*50*5
	0087_5			
	0105_5			
CH4	0140_5	50	5*32*1	1*80*5
CH5	0168_5	70		
CH5	0205_5	95		
CH5	0261_5	120		
CH61	0300_5	2*70	2*(6*40*1)	1*100*5
CH61	0385_5			
CH72	0460_5			
CH72	0520_5			
CH72	0590_5			
CH72	0650_5			
CH72	0730_5			
CH63	0820_5			
CH63	0920_5			
CH63	1030_5			
CH63	1150_5			
CH74	1370_5	2*100*5	3*100*5	1*50*5
CH74	1640_5			
CH74	2060_5			
CH74	2300_5			

Table 16. Connections from mains device to drive

Chassis	Type	Connection		
		Conductor cross section [mm <sup>2</sup> ]	Busbar size (flexible connection)	Busbar size (bare Cu)
CH61	0170_6	70	2*24*1	1*50*5
	0208_6			
	0261_6			
CH62	0325_6	2*70	5*32*1	1*80*5
	0385_6			
	0416_6			
	0460_6			
	0502_6			

Table 16. Connections from mains device to drive

Chassis	Type	Connection		
		Conductor cross section [mm <sup>2</sup> ]	Busbar size (flexible connection)	Busbar size (bare Cu)
CH63	0590_6	2*150	2*(6*40*1)	1*80*5
	0650_6			
	0750_6			
CH64	0820_6		1*100*5	
	0920_6			
	1030_6			
	1180_6		2*100*5	
	1300_6			
	1500_6			

## 7. CONTROL KEYPAD

The control keypad is the link between the Vacon frequency converter and the user. The Vacon NX control keypad features an alphanumeric display with seven indicators for the Run status (RUN,  $\odot\odot$ , READY, STOP, ALARM, FAULT) and three indicators for the control place (I/O term/ Keypad/ BusComm). There are also three Status Indicator LEDs (green - green - red), see below.

The control information, i.e. the number of menu, description of menu or the displayed value and the numeric information are presented on three text lines.

The frequency converter is operable through the nine push-buttons of the control keypad. Furthermore, the buttons serve the purposes of parameter setting and value monitoring.

The keypad is detachable and isolated from the input line potential.

### 7.1 INDICATIONS ON THE KEYPAD DISPLAY




Figure 1. Vacon control keypad and drive status indications

#### 7.1.1 DRIVE STATUS INDICATIONS

The drive status indications tell the user what the status of the motor and the drive is and whether the motor control software has detected irregularities in motor or frequency converter functions.

- 1 RUN = Motor is running; Blinks when the stop command has been given but the frequency is still ramping down.
- 2  $\odot\odot$  = Indicates the direction of motor rotation.
- 3 STOP = Indicates that the drive is not running.
- 4 READY = Lights when AC power is on. In case of a trip, the symbol will not light up.
- 5 ALARM = Indicates that the drive is running outside a certain limit and a warning is given.
- 6 FAULT = Indicates that unsafe operating conditions were encountered due to which the drive was stopped.

### 7.1.2 CONTROL PLACE INDICATIONS

The symbols *I/O term*, *Keypad* and *Bus/Comm* (see Figure 60) indicate the choice of control place made in the (see chapter 7.3.3).

- a** *I/O term* = I/O terminals are the selected control place; i.e. START/STOP commands or reference values etc. are given through the I/O terminals
- b** *Keypad* = Control keypad is the selected control place; i.e. the motor can be started or stopped, or its reference values etc. altered from the keypad.
- c** *Bus/Comm* = The frequency converter is controlled through a fieldbus.

### 7.1.3 STATUS LEDs (GREEN – GREEN – RED)

The status LEDs light up in connection with the READY, RUN and FAULT drive status indicators.

- I** ● = Illuminates with the AC power connected to the drive and no faults are active. Simultaneously, the drive status indicator READY is lit up.
- II** ● = Illuminates when the drive is running. Blinks when the STOP button has been pushed and the drive is ramping down.
- III** ● = Blinks when unsafe operating conditions were encountered due to which the drive was stopped (Fault Trip). Simultaneously, the drive status indicator FAULT blinks on the display and the fault description can be seen, see chapter 7.3.4, Active Faults.


### 7.1.4 TEXT LINES

The three text lines (●, ●●, ●●●) provide the user with information on his present location in the keypad menu structure as well as with information related to the operation of the drive.

- = Location indication; displays the symbol and number of menu, parameter etc.  
Example: M2 = Menu 2 (Parameters); P2.1.3 = Acceleration time
- = Description line; Displays the description of menu, value or fault.
- = Value line; Displays the numerical and textual values of references, parameters etc. and the number of submenus available in each menu.

## 7.2 KEYPAD PUSH-BUTTONS


The Vacon alphanumeric control keypad features 9 push-buttons that are used for the control of the frequency converter (and motor), parameter setting and value monitoring.



3063.emf


*Figure 2. Keypad push-buttons*

### 7.2.1 BUTTON DESCRIPTIONS

-  = This button is used to reset active faults (see Chapter 7.3.4).
-  = This button is used to switch between two latest displays. May be useful when you want to see how the changed new value influences some other value.
-  = The Enter button serves for:
  - 1) confirmation of selections
  - 2) fault history reset (2...3 seconds)
-  = The Enter button serves for:
  - 1) confirmation of selections
  - 2) fault history reset (2...3 seconds)
-  = Browser button down
  - Browse the main menu and the pages of different submenus.
  - Edit values.
-  = Menu button left
  - Move backward in menu.
  - Move cursor left (in parameter menu).
  - Exit edit mode.
  - Hold down for 3 seconds to return to main menu.
-  = Menu button right
  - Move forward in menu.
  - Move cursor right (in parameter menu).
  - Enter edit mode.
-  = Start button
  - Pressing this button starts the motor if the keypad is the active control place.
  - See Chapter 7.3.3.
-  = Stop button. Pressing this button stops the motor (unless disabled by parameter R3.4/R3.6). See Chapter 7.3.3.

### 7.3 NAVIGATION ON THE CONTROL KEYPAD

The data on the control keypad are arranged in menus and submenus. The menus are used for example for the display and editing of measurement and control signals, parameter settings (chapter 7.3.2), reference values and fault displays (chapter 7.3.4). Through the menus, you can also adjust the contrast of the display (page 130).



VANXPLC\_1072\_INS\_uk

The first menu level consists of menus M1 to M7 and is called the *Main menu*. The user can navigate in the main menu using the *Browser buttons* up and down. The desired submenu can be entered from the main menu using the *Menu buttons*. When there still are pages to enter under the currently displayed menu or page, you can see an arrow (★) in the lower right corner of the display and by pressing the *Menu button right*, you can reach the next menu level.

The control keypad navigation chart is shown on the next page. Please note that the menu *M1* is located in the lower left corner. From there you will be able to navigate your way up to the desired menu using the menu and browser buttons.

More detailed descriptions of the menus you will find later in this Chapter.




Figure 3. Keypad navigation chart

### 7.3.1 MONITORING MENU (M1)

You can enter the Monitoring menu from the Main menu by pushing the *Menu button right* when the location indication M1 is visible on the first line of the display. How to browse through the monitored values is presented in Figure 63.

The monitored signals carry the indication V#.# and they are listed in Table 45. The values are updated once every 0.3 seconds.

This menu is meant only for signal checking. The values cannot be altered here. For changing values of parameters see Chapter 7.3.2.




Figure 4. Monitoring menu

Table 1. Monitored signals

Code	Signal name	Unit	Description
V1.1	Output frequency	Hz	Frequency to the motor
V1.2	Frequency reference	Hz	
V1.3	Motor speed	rpm	Calculated motor speed
V1.4	Motor current	A	Measured motor current
V1.5	Motor torque	%	Calculated motor shaft torque
V1.6	Motor power	%	Calculated motor shaft power
V1.7	Motor voltage	V	Calculated motor voltage
V1.8	DC-link voltage	V	Measured DC-link voltage
V1.9	Unit temperature	°C	Heat sink temperature
V1.10	Motor temperature	%	Calculated motor temperature. See All in One application manual.
V1.11	Voltage input	V	AI1
V1.12	Current input	mA	AI2
V1.13	DIN1, DIN2, DIN3		Digital input statuses
V1.14	DIN4, DIN5, DIN6		Digital input statuses
V1.15	D01, R01, R02		Digital and relay output statuses
V1.16	Analogue output current	mA	AO1
V1.17	Multimonitoring items		Displays three selectable monitoring values. See chapter 7.3.6.5.

**NOTE:** The All in One applications embody more monitoring values.

### 7.3.2 PARAMETER MENU (M2)

Parameters are the way of conveying the commands of the user to the frequency converter. The parameter values can be edited by entering the *Parameter Menu* from the *Main Menu* when the location indication M2 is visible on the first line of the display. The value editing procedure is presented in Figure 64.

Push the *Menu button right* once to move into the *Parameter Group Menu (G#)*. Locate the parameter group desired by using the *Browser buttons* and push the *Menu button right* again to enter the group and its parameters. Use again the *Browser buttons* to find the parameter (*P#*) you want to edit. From here you can proceed in two different ways: Pushing the *Menu button right* takes you to the edit mode. As a sign of this, the parameter value starts to blink. You can now change the value in two different manners:

1. Just set the new desired value with the *Browser buttons* and confirm the change with the *Enter button*. Consequently, the blinking stops and the new value is visible in the value field.
2. Push the *Menu button right* once again. Now you will be able to edit the value digit by digit. This editing manner may come in handy, when a relatively greater or smaller value than that on the display is desired. Confirm the change with the *Enter button*.

The value will not change unless the *Enter button* is pushed. Pressing the *Menu button left* takes you back to the previous menu.

Several parameters are locked, i.e. uneditable, when the drive is in RUN status. If you try to change the value of such a parameter the text *\*Locked\** will appear on the display. The frequency converter must be stopped in order to edit these parameters.

The parameters values can also be locked using the function in menu M6 (see Chapter Parameter lock (P6.5.2)).

You can return to the *Main menu* anytime by pressing the *Menu button left* for 3 seconds.

The basic application package "All in One+" includes seven applications with different sets of parameters.

Once in the last parameter of a parameter group, you can move directly to the first parameter of that group by pushing the *Browser button up*.

See the diagram for parameter value change procedure on page page 110.




Figure 5. Parameter value change procedure

### 7.3.3 KEYPAD CONTROL MENU (M3)

In the *Keypad Controls Menu*, you can choose the control place, edit the frequency reference and change the direction of the motor. Enter the submenu level with the *Menu button right*.

Table 2. Keypad control parameters, M3

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P3.1	Control place	1	3		1		125	<b>1</b> = I/O terminal <b>2</b> = Keypad <b>3</b> = Fieldbus
R3.2	Keypad reference	Par. 2.1.1	Par. 2.1.2	Hz				
P3.3	Direction (on keypad)	0	1		0		123	<b>0</b> = Forward <b>1</b> = Reverse
R3.4	Stop button	0	1		1		114	<b>0</b> = Limited function of Stop button <b>1</b> = Stop button always enabled

### 7.3.3.1 Selection of control place

There are three different places (sources) which the frequency converter can be controlled from. For each control place, a different symbol will appear on the alphanumeric display:

Control place	symbol
I/O terminals	I/O term
Keypad (panel)	Keypad
Fieldbus	Bus/Comm

Change the control place by entering the edit mode with the *Menu button right*. The options can then be browsed through with the *Browser buttons*. Select the desired control place with the *Enter button*. See the diagram on the next page.




Figure 6. Selection of control place

### 7.3.3.2 Keypad reference

The keypad reference submenu (P3.2) displays and allows the operator to edit the frequency reference. The changes will take place immediately. This reference value will not, however, influence the rotation speed of the motor unless the keypad has been selected as source of reference.

**NOTE:** The maximum difference in RUN mode between the output frequency and the keypad reference is 6 Hz. See also 7.3.3.4 below.

See Figure 64 for how to edit the reference value (pressing the *Enter button* is not, however, necessary).

### 7.3.3.3 Keypad direction

The keypad direction submenu displays and allows the operator to change the rotating direction of the motor. This setting will not, however, influence the rotation direction of the motor unless the keypad has been selected as the active control place.

See also 7.3.3.4 below.

See Figure 65 for how to change the rotation direction.

**NOTE:** Additional Information on controlling the motor with the keypad is given in Chapters 7.2.1 and 8.2.

### 7.3.3.4 Stop button activated

By default, pushing the STOP button will always stop the motor regardless of the selected control place. You can disable this function by giving parameter 3.4 the value 0. If the value of this parameter is 0, the STOP button will stop the motor only when the keypad has been selected as the active control place.

**NOTE!** There are some special functions that can be performed when in the *M3* menu:

Select the keypad as the active control place by keeping the Start button pushed down for 3 seconds when the motor is running. The keypad will become the active control place and the current frequency reference and direction will be copied to the keypad.

Select the keypad as the active control place by keeping the Stop button pushed down for 3 seconds when the motor is stopped. The keypad will become the active control place and the current frequency reference and direction will be copied to the keypad.

Copy the frequency reference set elsewhere (I/O, fieldbus) to the panel by keeping the

 pushed down for 3 seconds.

Note that if you are in any other than *M3* menu these functions will not work.

If you are in some other than *M3* menu and try to start the motor by pressing the START button when the keypad is not selected as the active control place you will get an error message *Keypad Control NOT ACTIVE*.

### 7.3.4 ACTIVE FAULTS MENU (M4)

The *Active faults* menu can be entered from the *Main menu* by pushing the *Menu button right* when the location indication M4 is visible on the first line of the keypad display.

When a fault brings the frequency converter to a stop, the location indication F1, the fault code, a short description of the fault and the fault type symbol (see Chapter 7.3.4.1) will appear on the display. In addition, the indication FAULT or ALARM (see Figure 60 or Chapter 7.1.1) is displayed and, in case of a FAULT, the red led on the keypad starts to blink. If several faults occur simultaneously, the list of active faults can be browsed with the *Browser buttons*.

The memory of active faults can store the maximum of 10 faults in the order of appearance. The display can be cleared with the *Reset button* and the read-out will return to the same state it was before the fault trip. The fault remains active until it is cleared with the *Reset button* or with a reset signal from the I/O terminal or fieldbus.

**Note!** Remove external Start signal before resetting the fault to prevent unintentional restart of the drive.

Normal state,  
no faults:



VANXPLC\_1077\_INS\_uk

### 7.3.4.1 Fault types

In the NX frequency converter, there are four different types of faults. These types differ from each other on the basis of the subsequent behaviour of the drive. See Table 47.




Figure 7. Fault display

Table 3. Fault types

Fault type symbol	Meaning
A (Alarm)	This type of fault is a sign of an unusual operating condition. It does not cause the drive to stop, nor does it require any special actions. The 'A fault' remains in the display for about 30 seconds.
F (Fault)	An 'F fault' is a kind of fault that makes the drive stop. Actions need to be taken in order to restart the drive.
AR (Fault Autoreset)	If an 'AR fault' occurs the drive will also stop immediately. The fault is reset automatically and the drive tries to restart the motor. Finally, if the restart is not successful, a fault trip (FT, see below) occurs.
FT (Fault Trip)	If the drive is unable to restart the motor after an AR fault an FT fault occurs. The effect of the 'FT fault' is basically the same as that of the F fault: the drive is stopped.

### 7.3.4.2 Fault codes

The fault codes, their causes and correcting actions are presented in the table below. The shadowed faults are A faults only. The items written in white on black background present faults for which you can program different responses in the application. See parameter group Protections.

**NOTE:** When contacting distributor or factory because of a fault condition, always write down all texts and codes on the keypad display.

Fault code	Fault	Possible cause	Correcting measures
1	Overcurrent	Frequency converter has detected too high a current ( $>4*I_H$ ) in the motor cable: - sudden heavy load increase - short circuit in motor cables unsuitable motor Subcode in T.14: S1 = Hardware trip S3 = Current controller supervision	Check loading. Check motor. Check cables.
2	Overvoltage	The DC-link voltage has exceeded the limits defined in Table 9. - too short a deceleration time - high overvoltage spikes in supply Subcode in T.14: S1 = Hardware trip S2 = Overvoltage control supervision	Make the deceleration time longer. Use brake chopper or brake resistor (available for most chassis as options)
3	Earth fault	Current measurement has detected that the sum of motor phase current is not zero. - insulation failure in cables or motor	Check motor cables and motor.
5	Charging switch	The charging switch is open, when the START command has been given. - faulty operation - component failure	Reset the fault and restart. Should the fault re-occur, contact your local distributor.
6	Emergency stop	Stop signal has been given from the option board.	Check emergency stop circuit
7	Saturation trip	Various causes: - defective component - brake resistor short-circuit or over load	Cannot be reset from the keypad. Switch off power. <b>DO NOT RE-CONNECT POWER!</b> Contact your local distributor. If this fault appears simultaneously with Fault 1, check motor cables and motor

Fault code	Fault	Possible cause	Correcting measures
8	System fault	<ul style="list-style-type: none"> <li>- component failure</li> <li>- faulty operation</li> </ul> Note exceptional fault data record. Subcode in T.14: S1 = Feedback of motor voltage S2 = Reserved S3 = Reserved S4 = ASIC trip S5 = Disturbance in VaconBus S6 = Feedback of charging switch S7 = Charging switch S8 = No power to driver card S9 = Power unit communication (TX) S10 = Power unit communication (Trip) S11 = Power unit comm. (Measurement) S12 = Expander board (slot D or E) S30-S48 = OPT-AF board (slot B)	Reset the fault and restart. Should the fault re-occur, contact your local distributor.
9	Undervoltage	DC-link voltage is under the voltage limits defined in Table 9. <ul style="list-style-type: none"> <li>• most probable cause: too low a supply voltage</li> <li>• frequency converter internal fault</li> </ul> Subcode in T.14: S1 = DC-link too low during run S2 = No data from power unit S3 = Undervoltage control supervision	In case of temporary supply voltage break reset the fault and restart frequency converter. Check the supply voltage. If it is adequate, an internal failure has occurred. Contact your local distributor.
10	Input line supervision	Input line phase is missing. Subcode in T.14: S1 = Phase supervision diode supply S2 = Phase supervision active front end	Check supply voltage, fuses and cable.
12	Brake chopper supervision	<ul style="list-style-type: none"> <li>- no brake resistor installed</li> <li>- brake resistor is broken</li> <li>- brake chopper failure</li> </ul>	Check brake resistor and cabling. If ok, the chopper is faulty. Contact your local distributor.
13	Frequency converter undertemperature	Heatsink temperature is under -10°C	
14	Frequency converter overtemperature	1] Heatsink temperature is over 70°C. Overtemperature warning is issued when the heatsink temperature exceeds 65°C. 2] Circuit board temperature is over 85°C. Overtemperature warning is issued when the board temperature exceeds 70°C. Subcodes: S1 = Overtemperature warning in unit, board or phases S2 = Overtemperature in power board S3 = Liquid flow S4 = Overtemperature on ASIC board or driver boards	<u>Cause 1]:</u> Check that values for $I_{th}$ (chapter 4.2) are not exceeded Check the correct coolant flow and temperature. Also check the circulation for possible leaks. Check the ambient temperature. Make sure that the switching frequency is not too high in relation to ambient temperature and motor load. <u>Cause 2]:</u> Circulation of air in the drive is blocked. The cooling fans are defect.
15	Motor stalled	Motor stall protection has tripped.	Check motor and load.

Fault code	Fault	Possible cause	Correcting measures
16	Motor over-temperature	Motor overheating has been detected by frequency converter motor temperature model. Motor is overloaded.	Decrease the motor load. If no motor overload exists, check the temperature model parameters.
17	Motor underload	Motor underload protection has tripped.	Check load.
18	Unbalance (Warning only)	Unbalance between power modules in paralleled units. Subcode in T.14: S1 = Current unbalance S2 = DC-Voltage unbalance	Should the fault re-occur, contact your local distributor.
22	EEPROM checksum fault	Subcodes: S1 = Firmware interface power down variable checksum error. S2 = Firmware interface variable checksum error. S3 = System power down variable checksum error S4 = System parameter checksum error S5 = Application-defined powerdown, variable checksum error. S6 = Application-defined powerdown, variable checksum. S10 = System parameter checksum error (fault history entries, device valid, system menu parameters).	Should the fault re-occur, contact your local distributor.
24	Counter fault	Values displayed on counters are incorrect	Take a critical attitude towards values shown on counters.
25	Microprocessor watchdog fault	- faulty operation - component failure Subcodes: S1 = CPU watchdog timer S2 = ASIC reset	Reset the fault and restart. Should the fault re-occur, contact your distributor.
26	Startup prevented	Start-up of the drive has been prevented. Subcodes: S1 = Prevention of accidental start-up S2 = Appears if START command is ON, when returning to READY STATE after Safe Disable has been active S30 = Appears if START command is ON after system software has been downloaded, after application has been downloaded or application has been changed	Cancel prevention of start-up if this can be done safely.
29	Thermistor fault	The thermistor input of option board has detected increase of the motor temperature Subcodes: S1 = Thermistor input activated on OPTAF board S2 = Special application	Check motor cooling and loading Check thermistor connection (If thermistor input of the option board is not in use it has to be short circuited)

Fault code	Fault	Possible cause	Correcting measures
30	Safe Disable warning	Safe disable inputs SD1 and SD2 are activated through the option board OPT-AF.	Contact your distributor.
31	IGBT temperature (hardware)	IGBT Inverter Bridge overtemperature protection has detected too high a shortterm overload current	Check loading. Check motor size.
34	CAN bus communication	Sent message not acknowledged.	Ensure that there is another device on the bus with the same configuration.
35	Application	Problem in application software	Contact your distributor. If you are application programmer check the application program.
36	Control unit	NXS Control Unit can not control NXP Power Unit and vice versa	Change control unit
37	Device changed (same type)	Option board or power unit changed. New device of same type and rating. Subcodes: S1 = Control board S2 = Control unit S3 = Power board S4 = Power unit S5 = Adapter board and slot	Reset. Device is ready for use. Old parameter settings will be used.
38	Device added (same type)	Option board added. Subcodes: S1 = Control board S4 = Control unit S5 = Adapter board and slot	Reset. Device is ready for use. Old board settings will be used.
39	Device removed	Option board removed.	Reset. Device no longer available.
40	Device unknown	Unknown option board or drive. Subcode in T.14: S1 = Unknown device S2 = Power1 not same type as Power2 S3 = NXS or NXP1 and star coupler S4 = Software and ctrl unit incompatible S5 = Old control board version	Contact your local distributor.
41	IGBT temperature	IGBT Inverter Bridge overtemperature protection has detected too high a short term overload current	Check loading. Check motor size.
42	Brake resistor over-temperature	Subcodes: S1 = Internal brake chopper overtemp. S2 = Brake resistance too high (BCU) S3 = Brake resistance too low (BCU) S4 = Brake resistance not detected (BCU) S5 = Brake resistance leakage (earth fault) (BCU)	Reset unit. SetReset unit. Set the deceleration time longer restart. Dimensioning of the brake chopper not correct. Use external brake resistor. the deceleration time longer and restart. Dimensioning of the brake chopper is not correct. Use external brake resistor.

Fault code	Fault	Possible cause	Correcting measures
43	Encoder fault	Problem detected in encoder signals. Sub code in T.14: S1 = Encoder 1 channel A is missing S2 = Encoder 1 channel B is missing S3 = Both enc. 1 channels are missing S4 = Encoder reversed S5 = Encoder board missing S6 = Serial communication fault S7 = Channel A/Channel B mismatch S8 = Resolver/Motor pole pair mismatch S9 = Missed start angle	Check encoder channel connections. Check the encoder board.
44	Device changed (different type)	Option board or power unit changed. New device of different type or different rating than the previous one. Subcodes: S1 = Control board S2 = Control unit S3 = Power board S4 = Power unit S5 = Adapter board and slot	Reset Set the option board parameters again if option board changed. Set converter parameters again if power unit changed.
45	Device added (different type)	Option board of different type added. Subcodes: S1 = Control board S2 = Control unit S3 = Power board S4 = Power unit S5 = Adapter board and slot	Reset Set the option board parameters again.
49	Div by zero in application	A division by zero has occurred in the application program.	Contact your distributor. If you are application programmer check the application program.
50	Analogue input $I_{in} < 4mA$ (sel. signal range 4 to 20 mA)	Current at the analogue input is < 4mA. - control cable is broken or loose - signal source has failed	Check the current loop circuitry.
51	External fault	Digital input fault.	
52	Keypad communication fault	The connection between the control keypad and the frequency converter is broken.	Check keypad connection and possible keypad cable.
53	Fieldbus fault	The data connection between the fieldbus Master and the fieldbus board is broken	Check installation. If installation is correct contact the nearest Vacon distributor.
54	Slot fault	Defective option board or slot	Check board and slot. Contact the nearest Vacon distributor.
55	Actual value supervision		
56	PT100 board temp. fault	Temperature limit values set for the PT100 board parameters have been exceeded	Find the cause of temperature rise,

Fault code	Fault	Possible cause	Correcting measures
57	Identification	Identification run has failed.	Run command was removed before completion of identification run. Motor is not connected to frequency converter. There is load on motor shaft.
58	Brake	Actual status of the brake is different from the control signal.	Check mechanical brake state and connections.
59	Follower communication	SystemBus or CAN communication is broken between Master and Follower	Check option board parameters. Check optical fibre cable or CAN cable.
60	Cooling	Coolant circulation on liquid-cooled drive has failed.	Check reason for the failure on external system.
61	Speed error	Motor speed is unequal to reference	Check encoder connection. PMS motor has exceeded the pull out torque.
62	Run disable	Run enable signal is low	Check reason for Run enable signal.
63	Emergency stop	Command for emergency stop received from digital input or fieldbus	New run command is accepted after reset.
64	Input switch open	Drive input switch is open	Check the main power switch of the drive.

Table 4. Fault codes

### 7.3.4.3 Fault time data record

When a fault occurs the information described above is displayed. By pushing the *Menu button right* here you will enter the *Fault time data record menu* indicated by T.1→T.13. In this menu, some selected important data valid at the time of the fault are recorded. This feature is intended to help the user or the service person to determine the cause of fault.

The data available are:

Table 5. Fault time recorded data

T.1	Counted operation days (Fault 43: Additional code)	d
T.2	Counted operation hours (Fault 43: Counted operation days)	hh:mm:ss (d)
T.3	Output frequency (Fault 43: Counted operation hours)	Hz (hh:mm:ss)
T.4	Motor current	A
T.5	Motor voltage	V
T.6	Motor power	%
T.7	Motor torque	%
T.8	DC voltage	V
T.9	Unit temperature	°C
T.10	Run status	

Table 5. Fault time recorded data

T.11	Direction	
T.12	Warnings	
T.13	0-speed*	

\* Tells the user if the drive was at zero speed (< 0.01 Hz) when the fault occurred

**Real time record**

If real time is set to run on the frequency converter the data items T1 and T2 will appear as follows:

T.1	Counted operation days	yyyy-mm-dd
T.2	Counted operation hours	hh:mm:ss,sss

**7.3.5 FAULT HISTORY MENU (M5)**

The *Fault history menu* can be entered from the *Main menu* by pushing the *Menu button right* when the location indication M5 is visible on the first line of the keypad display. Find the fault codes in Table 9.

All faults are stored in the *Fault history menu* in which you can browse through them using the *Browser buttons*. Additionally, the *Fault time data record* pages are accessible at each fault. You can return to the previous menu anytime by pushing the *Menu button left*.

The memory of the frequency converter can store a maximum of 30 faults in the order of appearance. The number of faults currently in the fault history is shown on the value line of the main page (H1→H#). The order of the faults is indicated by the location indication in the upper left corner of the display. The latest fault carries the indication F5.1, the second latest F5.2 etc. If there are 30 uncleared faults in the memory the next occurring fault will erase the oldest from the memory.

Pressing the *Enter button* for about 2 to 3 seconds resets the whole fault history. Then, the symbol H# will change to 0.




Figure 8. Fault history menu

### 7.3.6 SYSTEM MENU (M6)

The *System menu* can be entered from the main menu by pushing the *Menu button right* when the location indication M6 is visible on the display.

The controls associated with the general use of the frequency converter, such as application selection, customised parameter sets or information about the hardware and software are located under the *System menu*. The number of submenus and subpages is shown with the symbol S (or P) on the value line.

On page 121 you will find a list of the functions available in the System menu.

#### Functions in the System menu

*Table 6. System menu functions*

Code	Function	Min	Max	Unit	Default	Cust	Selections
S6.1	Language selection				English		Available selections depend on the language package.
S6.2	Application selection				Basic Application		Standard Application Local/Remote control Appl. Multi-Step Application PID Control Application Multi-Purpose Control Appl. Pump and Fan Control Appl.
S6.3	Copy parameters						
S6.3.1	Parameter sets						Store set 1 Load set 1 Store set 2 Load set 2 Load factory defaults
S6.3.2	Load up to keypad						All parameters
S6.3.3	Load down from keypad						All parameters All but motor parameters Application parameters
P6.3.4	Parameter backup				Yes		Yes No
S6.4	Compare parameters						
S6.4.1	Set1				Not used		
S6.4.2	Set2				Not used		
S6.4.3	Factory settings						
S6.4.4	Keypad set						
S6.5	Security						
S6.5.1	Password				Not used		0 = Not used
P6.5.2	Parameter lock				Change Enabled		Change Enabled Change Disabled
S6.5.3	Start-up wizard						No Yes
S6.5.4	Multimonitoring items						Change Enabled Change Disabled
S6.6	Keypad settings						
P6.6.1	Default page						

Table 6. System menu functions

<b>Code</b>	<b>Function</b>	<b>Min</b>	<b>Max</b>	<b>Unit</b>	<b>Default</b>	<b>Cust</b>	<b>Selections</b>
P6.6.2	Default page/ Operating menu						
P6.6.3	Timeout time	0	65535	s	30		
P6.6.4	Contrast	0	31		18		
P6.6.5	Backlight time	Always	65535	min	10		
S6.7	Hardware settings						
P6.7.3	HMI acknowledg. timeout		200			5000	
P6.7.4	HMI number of retries		1			10	
S6.8	System information						
S6.8.1	Total counters						
C6.8.1.1	MWh counter						
C6.8.1.2	Power On day counter						
C6.8.1.3	Power On hours counter						
S6.8.2	Trip counters						
T6.8.2.1	MWh counter			kWh			
T6.8.2.2	Clear MWh trip counter						
T6.8.2.3	Operating days trip counter						
T6.8.2.4	Operating hours trip counter			hh:mm:ss			
T6.8.2.5	Clear operating time counter						
S6.8.3	Software info						
S6.8.3.1	Software package						
S6.8.3.2	System software version						
S6.8.3.3	Firmware interface						
S6.8.3.4	System load						
S6.8.4	Applications						
S6.8.4.#	Name of application						
D6.8.4.#.1	Application ID						
D6.8.4.#.2	Applications: Version						
D6.8.4.#.3	Applications: Firmware interface						
S6.8.5	Hardware						
I6.8.5.1	Info: Power unit type code						
I6.8.5.2	Info: Unit voltage			V			
I6.8.5.3	Info: Brake chopper						
I6.8.5.4	Info: Brake resistor						
S6.8.6	Expander boards						
S6.8.7	Debug menu						For Application program- ming only. Contact factory for more details

### 7.3.6.1 Language selection

The Vacon control keypad offers you the possibility to control the frequency converter through the keypad in the language of your choice.

Locate the language selection page under the *System menu*. Its location indication is S6.1. Press the *Menu button right* once to enter the edit mode. As the name of the language starts to blink you are able to choose another language for the keypad texts. Confirm the selection by pushing the *Enter button*. The blinking stops and all textual information on the keypad is presented in the language you chose.

You can return to the previous menu anytime by pushing the *Menu button left*.




Figure 9. Selection of language

### 7.3.6.2 Application selection

The user can select the application desired by entering the *Application selection page* (S6.2). This is done by pushing the *Menu button right* when on the first page of the *System menu*. Change then the application by pushing the *Menu button right* once again. The name of the application starts to blink. Now you can browse through the applications with the *Browser buttons* and select another application with the *Enter button*.

Changing application will reset all parameters. After application change, you will be asked if you want the parameters of the new application to be uploaded to the keypad. If you wish this to happen push the *Enter button*. Pushing any other button leaves the parameters of the previously used application saved in the keypad. For more information, see Chapter 7.3.6.3.

For more information about the Application Package, see Vacon NX Application Manual.




Figure 10. Change of application

### 7.3.6.3 Copy parameters

The parameter copy function is used when the operator wants to copy one or all parameter groups from one drive to another or to store parameter sets in the internal memory of the converter. All the parameter groups are first *uploaded* to the keypad, then the keypad is connected to another drive and then the parameter groups are *downloaded* to it (or possibly back to the same drive).

Before any parameters can successfully be copied from one drive to another the drive has to be stopped when the parameters are downloaded to it:

The parameter copy menu (S6.3) embodies four functions:

#### Parameter sets (S6.3.1)

The Vacon NX frequency converter features a possibility for the user to load back the factory default parameter values and to store and load two customised parameter sets (all parameters included in the application).

On *Parameter sets* page (S6.3.1), push the *Menu button right* to enter the *Edit menu*. The text *Load-FactDef* begins to blink and you can confirm the loading of factory defaults by pushing the *Enter button*. The drive resets automatically.

Alternatively you can choose any other of the storing or loading functions with the *Browser buttons*. Confirm with the *Enter button*. Wait until 'OK' appears on the display.




Figure 11. Storing and loading of parameter sets

#### Upload parameters to keypad (To keypad, S6.3.2)

This function uploads all existing parameter groups to the keypad provided that the drive is stopped.

Enter the *To keypad* page (S6.3.2) from the *Parameter copy menu*. Push the *Menu button right* to enter the edit mode. Use the *Browser buttons* to select the option *All parameters* and press the *Enter button*. Wait until 'OK' appears on the display.




Figure 12. Parameter copy to keypad

#### Download parameters to drive (From keypad, S6.3.3)

This function downloads one or all parameter groups uploaded to the keypad to a drive provided that the drive is in STOP status.

Enter the *From keypad* page (S6.3.3) from the *Parameter copy menu*. Push the *Menu button right* to enter the edit mode. Use the *Browser buttons* to select either the option *All parameters* or *Application parameters* and press the *Enter button*. Wait until 'OK' appears on the display.

The procedure to download the parameters from keypad to drive is similar to that of from drive to keypad. See above.

### Automatic parameter backup (P6.3.4)

On this page you can activate or deactivate the parameter backup function. Enter the edit mode by pressing the *Menu button right*. Choose *Yes* or *No* with the *Browser buttons*.

When the Parameter backup function is activated Vacon NX control keypad makes a copy of the parameters of the presently used application. Every time a parameter is changed the keypad backup is automatically updated.

When applications are changed, you will be asked if you wish the parameters of the new application to be uploaded to the keypad. For this to happen, push the *Enter button*. If you wish to keep the copy of the parameters of the previously used application saved in the keypad push any other button. Now you will be able to download these parameters to the drive following the instructions given in chapter 7.3.6.3.

If you want the parameters of the new application to be automatically uploaded to the keypad you have to do this for the parameters of the new application once on page 6.3.2 as instructed. Otherwise the panel will always ask for the permission to upload the parameters.

**NOTE:** Parameters saved in the parameter settings on page S6.3.1 will be deleted when applications are changed. If you want to transfer the parameters from one application to another you have to upload them first to the keypad.

#### 7.3.6.4 Parameter comparison

In the *Parameter comparison* submenu (S6.4), you can compare the actual parameter values to the values of your customised parameter sets and those loaded to the control keypad.

The comparison is performed by pushing the *Menu button right* when in the *Compare parameters submenu*. The actual parameter values are first compared to those of the customised parameter Set1. If no differences are detected a '0' is displayed on the lowermost line. But if any of the parameter values differ from those of the Set1 the number of the deviations is displayed together with symbol P (e.g. P1→P5 = five deviating values). By pressing the *Menu button right* once again you can still enter the pages where you can see both the actual value and the value it was compared to. In this display, the value on the Description line (in the middle) is the default value and the one on the value line (lowermost) is the edited value. Furthermore, you can also edit the actual value with the *Browser buttons* in the *edit mode* that you can reach by pushing the *Menu button right* once again.

In the same way, you can perform the comparison of the actual values to *Set2*, *Factory Settings* and *Keypad Set*.




Figure 13. Parameter comparison

### 7.3.6.5 Security

**NOTE:** The *Security submenu* is protected with a password. Store the password in a safe place!

#### Password (S6.5.1)

The application selection can be protected against unauthorised changes with the Password function (S6.5.1).

By default, the password function is not in use. If you want to activate the function, enter the edit mode by pushing the *Menu button right*. A blinking zero appears in the display and now you can set a password with the *Browser buttons*. The password can be any number between 1 and 65535.

**Note!** that you can also set the password by digits. In the edit mode, push the *Menu button right* once again and another zero appears on the display. Now set first the units. Then push the *Menu button left* and you can set the tens etc. Finally, confirm the password setting with the *Enter button*. After this, you have to wait until the *Timeout time (P6.6.3)* (see page page 130) has expired before the password function is activated.

If you now try to change applications or the password itself you will be prompted for the current password. The password will be entered with the *Browser buttons*.

Deactivate the password function by entering the value **0**.




Figure 14. Password setting

**Note!** Store the password in a secure location! No changes can be made unless a valid password is entered!

#### Parameter lock (P6.5.2)

This function allows the user to prohibit changes to the parameters.

If the parameter lock is activated the text *\*locked\** will appear on the display if you try to edit a parameter value.

**NOTE: This function does not prevent unauthorised editing of parameter values.**

Enter the edit mode by pushing the *Menu button right*. Use the *Browser buttons* to change the parameter lock status. Accept the change with the *Enter button* or return to the previous level with the *Menu button left*.




Figure 15. Parameter locking

### Start-up Wizard (P6.5.3)

The Start-up Wizard is a feature on the control keypad to facilitate the commissioning of the frequency converter. If selected active (default), the Start-up Wizard prompts the operator for the language and application of his/her choice plus for the values for a set of parameters common to all applications as well as for a set of application-dependent parameters.

Always accept the value with the *Enter button*, scroll options or change values with the *Browser buttons* (up and down arrows).

Set the Start-up Wizard active in the following way: In the System Menu, find page P6.5.3. Press the *Menu button right* once to reach the edit mode. Use the *Browser buttons* to set value *Yes* and confirm the selection with the *Enter button*. If you want to deactivate the function follow the same procedure and give the parameter value *No*.



Figure 16. Activation of Start-up wizard

### Multimonitoring items (P6.5.4)

Vacon alpha-numeric keypad features a display where you can monitor even three actual values at the same time (see chapter 7.3.1 and chapter *Monitoring values* in the manual of the application you are using). On page P6.5.4 of the System Menu you can define if it is possible for the operator to replace the values monitored with other values. See below.




Figure 17. Enabling the change of multimonitoring items

### 7.3.6.6 Keypad settings

In the Keypad settings submenu under the *System menu* you can further customise your frequency converter operator interface.

Locate the Keypad settings submenu (S6.6). Under the submenu, there are four pages (P#) associated with the keypad operation:




Figure 18. Keypad settings submenu

### Default page (P6.6.1)

Here you can set the location (page) to which the display automatically moves as the *Timeout time* (see below) has expired or as the power is switched on to the keypad.

If the *Default Page* value is 0 the function is not activated, i.e. the last displayed page remains on the keypad display. Press the *Menu button right* once to enter the edit mode. Change the number of the Main menu with the *Browser buttons*. Pressing the *Menu button right* once again makes you able to edit the number of the submenu/page. If the page you want to move to by default is at the third level repeat the procedure. Confirm the new default page value with the *Enter button*. You can return to the previous step anytime by pushing the *Menu button left*.




Figure 19. Default page function

### Default page in the operating menu (P6.6.2)

Here you can set the location (page) in the *Operating menu* (in special applications only) to which the display automatically moves as the set *Timeout time* (see below) has expired or as the power is switched on to the keypad. See setting of Default page above.

### Timeout time (P6.6.3)

The Timeout time setting defines the time after which the keypad display returns to the Default page (P6.6.1) see above.

Move to the Edit menu by pressing the *Menu button right*. Set the timeout time you want and confirm the change with the *Enter button*. You can return to the previous step anytime by pushing the *Menu button left*.




Figure 20. Timeout time setting

**Note:** If the *Default page* value is 0 the *Timeout time* setting has no effect.

### Contrast adjustment (P6.6.4)

In case the display is unclear you can adjust its contrast through the same procedure as that for the timeout time setting (see above).

### Backlight time (P6.6.5)

Giving a value for the *Backlight time*, you can determine how long the backlight stays on before going out. You can select here any time between 1 and 65535 minutes or '*Forever*'. For the value setting procedure see Timeout time (P6.6.3).

#### 7.3.6.7 *Hardware settings*

**NOTE:** The *Hardware settings submenu* is protected with a password (see chapter Password (S6.5.1)). Store the password in a safe place!

In the *Hardware settings submenu* (S6.7) under the *System menu* you can further control some functions of the hardware in your frequency converter. The functions available in this menu are *HMI acknowledge timeout* and *HMI retry*.

### HMI acknowledge timeout (P6.7.3)

This function allows the user to change the timeout of the HMI acknowledgement time in cases where there is an additional delay in the RS-232 transmission due to use of modems for communication over longer distances, for example.

**NOTE!** If the frequency converter has been connected to the PC with a normal cable, the default values of parametres 6.7.3 and 6.7.4 (200 and 5) must not be changed.

If the frequency converter has been connected to the PC via a modem and there is delay in transferring messages, the value of par. 6.7.3 must be set according to the delay as follows:

Example:

- Transfer delay between the frequency converter and the PC = 600 ms
- The value of par. 6.7.3 is set to 1200 ms (2 x 600, sending delay + receiving delay)
- The corresponding setting shall be entered in the [Misc]-part of the file NCDrive.ini:  
Retries = 5  
AckTimeOut = 1200  
TimeOut = 6000

It must also be considered that intervals shorter than the AckTimeOut-time cannot be used in NC-Drive monitoring.

Enter the edit mode by pushing the *Menu button right*. Use the *Browser buttons* to change the acknowledgement time. Accept the change with the *Enter button* or return to the previous level with the *Menu button left*.




Figure 21. HMI acknowledge timeout

#### **Number of retries to receive HMI acknowledgement (P6.7.4)**

With this parameter you can set the number of times the drive will try receive acknowledgement if this does not succeed within the acknowledgement time (P6.7.3) or if the received acknowledgement is faulty.

Enter the edit mode by pushing the *Menu button right*. The present value shown starts to blink. Use the *Browser buttons* to change the amount of retries. Accept the change with the *Enter button* or return to the previous level with the *Menu button left*.

See Figure 80 for the procedure of changing the value.

#### 7.3.6.8 System info

In the *System info submenu* (S6.8) you can find frequency converter-related hardware and software information as well as operation-related information.

## Total counters (S6.8.1)

In the *Total counters* page (S6.8.1) you can find information related to the frequency converter operation times, i.e. the total numbers of MWh, operation days and operation hours passed so far. Unlike the counters in the Trip counters, these counters cannot be reset.

**Note!** The Power On time counter (days and hours) runs always, when the power is on.

Table 7. Counter pages

Page	Counter	Example
C6.8.1.1.	MWh counter	
C6.8.1.2.	Power On day counter	Value on display is 1.013. The drive has operated for 1 year and 13 days.
C6.8.1.3.	Power On hour counter	Value on display is 7:05:16. The drive has operated for 7 hours 5 minutes and 16 seconds.

## Trip counters (S6.8.)

*Trip counters* (menu S6.8.2) are counters the values of which can be reset i.e. restored to zero. You have the following resettable counters at your disposal. See Table 51 for examples.


**Note!** The trip counters run only when the motor is running.

Table 8. Resettable counters

Page	Counter
T6.8.2.1	MWh counter
T6.8.2.3	Operation day counter
T6.8.2.4	Operation hour counter

The counters can be reset on pages 6.8.2.2 (*Clear MWh counter*) and 6.8.2.5 (*Clear Operation time counter*).

Example: When you want to reset the operation counters you should do the following:



VANXPLC\_1093\_INS\_uk

Figure 22. Counter reset

**Software (S6.8.3)**

The *Software* information page includes information on the following frequency converter software related topics:

Table 9. Software information pages

Page	Content
6.8.3.1	Software package
6.8.3.2	System software version
6.8.3.3	Firmware interface
6.8.3.4	System load

**Applications (S6.8.4)**

At location S6.8.4 you can find the *Applications submenu* containing information about not only the application currently in use but also all other applications loaded into the frequency converter. The information available is:

Table 10. Applications information pages

Page	Content
6.8.4.#	Name of application
6.8.4.#.1	Application ID
6.8.4.#.2	Version
6.8.4.#.3	Firmware interface




Figure 23. Applications info page

In the *Applications* information page, push the *Menu button right* to enter the Application pages of which there are as many as there are applications loaded into the frequency converter. Locate the application you want information about with the *Browser buttons* and then enter the *Information pages* with the *Menu button right*. Use again the *Browser buttons* to see the different pages.

## Hardware (S6.8.5)

The *Hardware* information page provides information on the following hardware-related topics:

*Table 11. Hardware information pages*

Page	Content
6.8.5.1	Power unit type code
6.8.5.2	Nominal voltage of the unit
6.8.5.3	Brake chopper
6.8.5.4	Brake resistor


## Expander boards (S6.8.6)

In the *Expander boards* pages you find information about the basic and option boards connected to the control board (see Chapter 6.1.2).

You can check the status of each board slot by entering the *Expander boards* page with the *Menu button right* and using the *Browser buttons* to choose the board whose status you wish to check. Push the *Menu button right* again to display the status of the board. The keypad will also display the program version of the respective board when you push either one of the *Browser buttons*.

If no board is connected to the slot the text '*no board*' will be shown. If a board is connected to a slot but the connection is somehow lost the text '*no conn.*' is displayed. See Chapter 6.2 and Figure 42 and Figure 52 for more information.

For more information on the expander board-related parameters, see Chapter 7.3.7.



*Figure 24. Expander board information menus*

## Debug menu (S6.8.7)

This menu is meant for advanced users and application designers. Contact factory for any assistance needed.

### 7.3.7 EXPANDER BOARD MENU (M7)

The *Expander board menu* makes it possible for the user 1) to see what expander boards are connected to the control board and 2) to reach and edit the parameters associated with the expander board.

Enter the following menu level (G#) with the *Menu button right*. At this level, you can browse through slots (see page 83) A to E with the *Browser buttons* to see what expander boards are connected. On the lowermost line of the display you also see the number of parameters associated with the board. You can view and edit the parameter values in the same way as described in chapter 7.3.2. See Table 56 and Figure 84.

### Expander board parameters

Table 12. Expander board parameters (board OPT-A1)

Code	Parameter	Min	Max	Default	Cust	Selections
P7.1.1.1	AI1 mode	1	5	3		<b>1</b> = 0...20 mA <b>2</b> = 4...20 mA <b>3</b> = 0...10 V <b>4</b> = 2...10 V <b>5</b> = -10...+10 V
P7.1.1.2	AI2 mode	1	5	1		See P7.1.1.1
P7.1.1.3	A01 mode	1	4	1		<b>1</b> = 0...20 mA <b>2</b> = 4...20 mA <b>3</b> = 0...10 V <b>4</b> = 2...10 V




Figure 25. Expander board information menu

### 7.4 FURTHER KEYPAD FUNCTIONS

The Vacon NX control keypad embodies additional application-related functions. See Vacon NX Application Package for more information.

## 8. COMMISSIONING

### 8.1 SAFETY

*Before commissioning, note the following directions and warnings:*



Internal components and circuit boards of the frequency converter are live when Vacon NX Liquid-Cooled drive is connected to mains potential. Coming into contact with this voltage is extremely dangerous and may cause death or severe injury.



The motor terminals U, V, W and the DC-link/brake resistor terminals B-, B+/R+, R- are live when Vacon NX Liquid-Cooled drive is connected to mains, even if the motor is not running.



The control I/O-terminals are isolated from the mains potential. However, the relay outputs and other I/O-terminals may have a dangerous control voltage present even when Vacon NX Liquid-Cooled drive is disconnected from mains.



Do not make any connections with the frequency converter connected to the mains.



After having disconnected the frequency converter from the mains, wait until the indicators on the keypad go out (if no keypad is attached see the indicator through the keypad base). Wait 5 more minutes before doing any work on Vacon NX Liquid-Cooled drive connections. Do not even open the cover before this time has expired.



Before connecting the NX Liquid-Cooled drive to mains, ensure the functionality of the coolant circulation and check the circulation for possible leaks.



Before connecting the drive to mains make sure that the switchgear enclosure door is closed.

## 8.2 COMMISSIONING OF THE FREQUENCY CONVERTER

1. Read carefully the safety instructions in Chapter 1 and follow them.
2. After the installation, pay attention:
  - that both the frequency converter and the motor are grounded.
  - that the mains and motor cables comply with the requirements given in Chapter 6.1.1.
  - that the control cables are located as far as possible from the power cables and the shields of the shielded cables are connected to protective earth . The wires may not touch the electrical components of the frequency converter.
  - that the common inputs of digital input groups are connected to +24V or ground of the I/O terminal or the external supply.
3. Check liquid cooling connections and system operation.
  - open the shut-off valves
  - check the quality and quantity of the cooling liquid (chapter 5.2)
  - ensure the proper operation of liquid circulation system
4. Perform the cable and motor insulation checks, see chapter 6.1.10
5. Check the frequency converter for condensation.
6. Check that all Start/Stop switches connected to the I/O terminals are in Stop-position.
7. Connect the frequency converter to mains.
8. Set the parameters of group 1 (See Vacon All in One Application Manual) according to the requirements of your application. At least the following parameters should be set:
  - motor nominal voltage
  - motor nominal frequency
  - motor nominal speed
  - motor nominal current

You will find the values needed for the parameters on the motor rating plate.
9. Perform run test without motor  
Perform either Test A or Test B:

*A Controls from the I/O terminals:*

- a) Turn the Start/Stop switch to ON position.
- b) Change the frequency reference (potentiometer)
- c) Check in the *Monitoring menu (M1)* that the value of Output frequency changes according to the change of frequency reference.
- d) Turn the Start/Stop switch to OFF position.

*B Control from the control keypad:*

- a) Change the control from the I/O terminals to the keypad as advised in Chapter 7.3.3.1.
- b) Push the Start button on the keypad.
- c) Move over to the *Keypad control menu (M3)* and Keypad Reference submenu (Chapter 7.3.3.2) and change the frequency reference using the Browser buttons 

- d) Check in the *Monitoring menu (M1)* that the value of Output frequency changes according to the change of frequency reference.
  - e) Push the Stop button on the keypad.
10. Run the start-up tests without the motor being connected to the process, if possible. If this is not possible, secure the safety of each test prior to running it. Inform your co-workers of the tests.
- a) Switch off the supply voltage and wait up until the drive has stopped as advised at Chapter 8.1, step 5.
  - b) Connect the motor cable to the motor and to the motor cable terminals of the frequency converter.
  - c) See to that all Start/Stop switches are in Stop positions.
  - d) Switch the mains ON
  - e) Repeat test 9A or 9B.
11. Connect the motor to the process (if the startup test was run without the motor being connected)
- a) Before running the tests, make sure that this can be done safely.
  - b) Inform your co-workers of the tests.
  - c) Repeat test 9A or 9B.

## 9. FAULT TRACING

### 9.1 FAULT CODES

When a fault is detected by the frequency converter control electronics, the drive is stopped and the symbol F together with the ordinal number of the fault, the fault code and a short fault description appear on the display. The fault can be reset with the *Reset button* on the control keypad or via the I/O terminal. The faults are stored in the Fault history menu (M5) which can be browsed. The different fault codes you will find in the table below.

The fault codes, their causes and correcting actions are presented in the table below. The shadowed faults are A faults only. The faults written in white on black background may appear as both A and F fault.

*Table 1. Fault codes*

Fault code	Fault	Possible cause	Correcting measures
1	Overcurrent	Frequency converter has detected too high a current ( $>4 \cdot IH$ ) in the motor cable: - sudden heavy load increase - short circuit in motor cables - unsuitable motor Subcode in T.14: S1 = Hardware trip S3 = Current controller supervision	Check loading. Check motor. Check cables.
2	Ovvoltige	The DC-link voltage has exceeded the limits defined in Table 9. - too short a deceleration time - high overvoltage spikes in supply Subcode in T.14: S1 = Hardware trip S2 = Overvoltage control supervision	Make the deceleration time longer. Use brake chopper or brake resistor (available for most chassis as options)
3	Earth fault	Current measurement has detected that the sum of motor phase current is not zero. - insulation failure in cables or motor	Check motor cables and motor.
5	Charging switch	The charging switch is open, when the START command has been given. - faulty operation - component failure	Reset the fault and restart. Should the fault re-occur, contact your local distributor.
6	Emergency stop	Stop signal has been given from the option board.	Check emergency stop circuit
7	Saturation trip	Various causes: - defective component - brake resistor short-circuit or overload	Cannot be reset from the keypad. Switch off power. DO NOT RE-CONNECT POWER! Contact your local distributor. If this fault appears simultaneously with Fault 1, check motor cables and motor

Table 1. Fault codes

Fault code	Fault	Possible cause	Correcting measures
8	System fault	<ul style="list-style-type: none"> <li>- component failure</li> <li>- faulty operation</li> </ul> Note exceptional fault data record. Subcode in T.14: S1 = Feedback of motor voltage S2 = Reserved S3 = Reserved S4 = ASIC trip S5 = Disturbance in VaconBus S6 = Feedback of charging switch S7 = Charging switch S8 = No power to driver card S9 = Power unit communication (TX) S10 = Power unit communication (Trip) S11 = Power unit comm. (Measurement) S12 = Expander board (slot D or E) S30-S48 = OPT-AF board (slot B)	Reset the fault and restart. Should the fault re-occur, contact your local distributor.
9	Undervoltage	DC-link voltage is under the voltage limits defined in Table 9 <ul style="list-style-type: none"> <li>- most probable cause: too low a supply voltage</li> <li>- frequency converter internal fault</li> </ul> Subcode in T.14: S1 = DC-link too low during run S2 = No data from power unit S3 = Undervoltage control supervision	In case of temporary supply voltage break reset the fault and restart the frequency converter. Check the supply voltage. If it is adequate, an internal failure has occurred. Contact your local distributor.
10	Input line supervision	Input line phase is missing. Subcode in T.14: S1 = Phase supervision diode supply S2 = Phase supervision active front end	Check supply voltage, fuses and cable.
12	Brake chopper supervision	<ul style="list-style-type: none"> <li>- no brake resistor installed</li> <li>- brake resistor is broken</li> <li>- brake chopper failure</li> </ul>	Check brake resistor and cabling. If ok, the chopper is faulty. Contact your local distributor.
13	Frequency converter undetemperature	Heatsink temperature is under -10°C	

Table 1. Fault codes

Fault code	Fault	Possible cause	Correcting measures
14	Frequency converter overtemperature	3) Heatsink temperature is over 70°C. Overtemperature warning is issued when the heatsink temperature exceeds 65°C. 4) Circuit board temperature is over 85°C. Overtemperature warning is issued when the board temperature exceeds 70°C.  Subcodes: S1 = Overtemperature warning in unit, board or phases S2 = Overtemperature in power board S3 = Liquid flow S4 = Overtemperature on ASIC board or driver boards	<u>Cause 1):</u> Check that values for $I_{th}$ (chapter 4.2 ) are not exceeded  <u>Cause 2):</u> Check the correct coolant flow and temperature. Also check the circulation for possible leaks. Check the ambient temperature. Make sure that the switching frequency is not too high in relation to ambient temperature and motor load. Circulation of air in the drive is blocked. The cooling fans are defect.
15	Motor stalled	Motor stall protection has tripped.	Check motor and load.
16	Motor overtemperature	Motor overheating has been detected by frequency converter motor temperature model. Motor is overloaded.	Decrease the motor load. If no motor overload exists, check the temperature model parameters.
17	Motor underload	Motor underload protection has tripped.	Check load.
18	Unbalance (Warning only)	Unbalance between power modules in paralleled units.  Subcode in T.14: S1 = Current unbalance S2 = DC-Voltage unbalance	Should the fault re-occur, contact your local distributor.
22	EEPROM checksum fault	Subcodes: S1 = Firmware interface power down variable checksum error. S2 = Firmware interface variable checksum error. S3 = System power down variable checksum error S4 = System parameter checksum error S5 = Application-defined powerdown, variable checksum error. S6 = Application-defined powerdown, variable checksum. S10 = System parameter checksum error (fault history entries, device valid, system menu parameters).	Should the fault re-occur, contact your local distributor.
24	Counter fault	Values displayed on counters are incorrect	Take a critical attitude towards values shown on counters.

Table 1. Fault codes

Fault code	Fault	Possible cause	Correcting measures
25	Microprocessor watchdog fault	- faulty operation - component failure Subcodes: S1 = CPU watchdog timer S2 = ASIC reset	Reset the fault and restart. Should the fault re-occur, contact your distributor.
26	Startup prevented	Start-up of the drive has been prevented. Subcodes: S1 = Prevention of accidental start-up S2 = Appears if START command is ON, when returning to READY STATE after Safe Disable has been active S30 = Appears if START command is ON after system software has been downloaded, after application has been downloaded or application has been changed	Cancel prevention of start-up if this can be done safely.
29	Thermistor fault	The thermistor input of option board has detected increase of the motor temperature Subcodes: S1 = Thermistor input activated on OPT-AF board S2 = Special application	Check motor cooling and loading Check thermistor connection (If thermistor input of the option board is not in use it has to be short circuited)
30	Safe Disable warning	Safe disable inputs SD1 and SD2 are activated through the option board OPT-AF.	Contact your distributor.
31	IGBT temperature (hardware)	IGBT Inverter Bridge overtemperature protection has detected too high a short-term overload current	Check loading. Check motor size.
34	CAN bus communication	Sent message not acknowledged.	Ensure that there is another device on the bus with the same configuration.
35	Application	Problem in application software	Contact your distributor. If you are application programmer check the application program.
36	Control unit	NXS Control Unit can not control NXP Power Unit and vice versa	Change control unit
37	Device changed (same type)	Option board or power unit changed. New device of same type and rating. Subcodes: S1 = Control board S2 = Control unit S3 = Power board S4 = Power unit S5 = Adapter board and slot	Reset. Device is ready for use. Old parameter settings will be used.

Table 1. Fault codes

Fault code	Fault	Possible cause	Correcting measures
38	Device added (same type)	Option board added. Subcodes: S1 = Control board S4 = Control unit S5 = Adapter board and slot	Reset. Device is ready for use. Old board settings will be used.
39	Device removed	Option board removed.	Reset. Device no longer available.
40	Device unknown Unknown option board or drive.	Subcode in T.14: S1 = Unknown device S2 = Power1 not same type as Power2 S3 = NXS or NXP1 and star coupler S4 = Software and ctrl unit incompatible S5 = Old control board version	Contact your local distributor.
41	IGBT temperature	IGBT Inverter Bridge overtemperature protection has detected too high a short term overload current	Check loading. Check motor size.
42	Brake resistor overtemperature	Subcodes: S1 = Internal brake chopper overtemp. S2 = Brake resistance too high (BCU) S3 = Brake resistance too low (BCU) S4 = Brake resistance not detected (BCU) S5 = Brake resistance leakage (earth fault) (BCU)	Reset unit. Set the deceleration time longer and restart. Dimensioning of the brake chopper is not correct. Use external brake resistor.
43	Encoder fault	Problem detected in encoder signals. Sub code in T.14: S1 = Encoder 1 channel A is missing S2 = Encoder 1 channel B is missing S3 = Both enc. 1 channels are missing S4 = Encoder reversed S5 = Encoder board missing S6 = Serial communication fault S7 = Channel A/Channel B mismatch S8 = Resolver/Motor pole pair mismatch S9 = Missed start angle	Check encoder channel connections. Check the encoder board.
44	Device changed (different type)	Option board or power unit changed. New device of different type or different rating than the previous one. Subcodes: S1 = Control board S2 = Control unit S3 = Power board S4 = Power unit S5 = Adapter board and slot	Reset Set the option board parameters again if option board changed. Set converter parameters again if power unit changed.

Table 1. Fault codes

Fault code	Fault	Possible cause	Correcting measures
45	Device added (different type)	Option board of different type added. Subcodes: S1 = Control board S2 = Control unit S3 = Power board S4 = Power unit S5 = Adapter board and slot	Reset Set the option board parameters again.
49	Div by zero in application	A division by zero has occurred in the application program.	Contact your distributor. If you are application programmer check the application program.
50	Analogue input lin < 4mA (sel. signal range 4 to 20 mA)	Current at the analogue input is < 4mA. - control cable is broken or loose - signal source has failed	Check the current loop circuitry.
51	External fault	Digital input fault.	
52	Keypad communication fault	Keypad communication fault The connection between the control keypad and the frequency converter is broken.	Check keypad connection and possible keypad cable.
53	Fieldbus fault	The data connection between the fieldbus Master and the fieldbus board is broken	Check installation. If installation is correct contact the nearest Vacon distributor.
54	Slot fault	Defective option board or slot	Check board and slot. Contact the nearest Vacon distributor.
55	Actual value supervision		
56	PT100 board temp. fault	Temperature limit values set for the PT100 board parameters have been exceeded	Find the cause of temperature rise
57	Identification	Identification run has failed.	Run command was removed before completion of identification run. Motor is not connected to frequency converter. There is load on motor shaft.
58	Brake	Actual status of the brake is different from the control signal.	Check mechanical brake state and connections.
59	Follower communication	SystemBus or CAN communication is broken between Master and Follower	Check option board parameters. Check optical fibre cable or CAN cable.
60	Cooling	Coolant circulation on liquid-cooled drive has failed.	Check reason for the failure on external system.

*Table 1. Fault codes*

Fault code	Fault	Possible cause	Correcting measures
61	Speed error	Motor speed is unequal to reference	Check encoder connection. PMS motor has exceeded the pull out torque.
62	Run disable	Run enable signal is low	Check reason for Run enable signal.
63	Emergency stop	Command for emergency stop received from digital input or fieldbus	New run command is accepted after reset.
64	Input switch open	Drive input switch is open	Check the main power switch of the drive.

## 9.2 LOAD TEST WITH MOTOR

1. Connect the motor cables and check the right phase order. Also check that the motor rotates freely.
2. Check liquid cooling system operation.
3. Turn on the supply voltage and ensure that all input phases are connected to the unit.
4. Check DC link voltage by measuring with multimeter and compare the value to the one on monitoring page *V1.8*.
5. Select the application of your choice and set the needed parameters (see Start-up Quick Guide, step 8 on page 5).
6. Start the operation with lower Current Limit value and long Acceleration/Deceleration times.
7. If Closed Loop control mode is used, check direction of encoder and make necessary Closed Loop parameter settings. Check the correct operation of the encoder by running the system in open loop and check the signals in the expander board menu.
8. Run the motor without load between minimum and maximum frequencies and check the unit output current with a current clamp. Compare the value to the one on monitoring page *V1.4*.
9. Load the motor to nominal value if possible and repeat the current measurement. Follow the Unit Temperature value on page *V1.9*.

### 9.3 DC LINK TEST (WITHOUT MOTOR)

**NOTE:** There will be dangerous voltages present during this test!

1. Read carefully the safety instructions in Chapter 1 and follow them.
2. Connect a variable DC power supply to DC+ and DC- terminals. Make sure that all polarities are correct.
3. Slowly charge up the DC link to nominal voltage. Allow the system to remain at this level for at least one minute and check current.
4. If possible, continue increasing the DC link voltage up to the trip limit. Fault F2 (see chapter 9) should occur at 911 VDC (400...500-volt units) and at 1200 VDC (525...690-volt units). Do not increase the voltage over the trip limit.
5. Bring the power supply voltage back to zero. Allow sufficient time for the capacitors to discharge.
6. Check the DC bus voltage with a multimeter. When you read zero volts disconnect the power supply and reconnect all wires to the phase module.
7. If the phase module has been de-energized for an extended period of time (six months or longer) allow this voltage to remain for a minimum of 30 minutes – even 4 hours if time permits.

Through the above test procedure, two things are achieved: 1) It allows the caps to partially reform due to storage and shipping; 2) It allows any device failures to evidence themselves with a low power failure.

## 10. BRAKE CHOPPER UNIT (NXB)

### 10.1 INTRODUCTION

The Vacon NXB (Brake chopper unit) is a unidirectional power converter for the supply of excessive energy from a common DC bus drive line-up to resistors where the energy is dissipated as heat. External resistors are needed. The NXB improves the DC-link voltage controllability as well as enhances the motor drives performance in dynamic applications.

Mechanically, the NXB module is based on inverter unit construction. The dynamic DC energy brake function is achieved through a specific NXB system software. Several NXB modules can be installed parallelly in order to increase the braking capacity, however, the modules require mutual synchronization.

### 10.2 TYPE DESIGNATION CODE

In Vacon type designation code, the Brake Chopper Unit is characterized by number 8, for example:

NXB	0300	5	A	0	T	0	8WF	A1A2000000
-----	------	---	---	---	---	---	-----	------------

### 10.3 DIAGRAMS

#### 10.3.1 NXB BRAKE CHOPPER UNIT BLOCK DIAGRAM




Figure 1. BCU block diagram

### 10.3.2 NXB TOPOLOGIES AND CONNECTION




Figure 2. Brake chopper unit topology




Figure 3. Vacon Brake Chopper Unit connections

## 10.4 BRAKE CHOPPER UNIT TECHNICAL DATA

Table 1. Technical specification for Vacon NXB liquid-cooled brake chopper unit

<b>Supply connection</b>	Input voltage $U_{in}$	465...800Vdc (380...500Vac); (-0%...+0%) 640...1100Vdc (525...690Vdc); (-0%...+0%)
	Input current	DC $I_{in} \sim I_{out}$
	DC bank capacitance	Voltage class 500V: Ch3 [16-31A units]: 600 $\mu F$ Ch3 [38-61A units]: 2400 $\mu F$ CH4: 2400 $\mu F$ CH5: 7200 $\mu F$ CH61: 10800 $\mu F$ CH62/CH72: 10800 $\mu F$ CH63: 21600 $\mu F$ CH64/CH74: 32400 $\mu F$ 2*CH64/2*CH74: 64800 $\mu F$ Voltage class 690V: CH61: 4800 $\mu F$ CH62/CH72: 4800 $\mu F$ CH63: 9600 $\mu F$ CH64/CH74: 14400 $\mu F$ 2*CH64/2*CH74: 28800 $\mu F$
	Starting delay	2...5 s
<b>Resistor connection</b>	Output voltage	$U_{in} \sim U_{out}$
	Continuous output current	$I_{br}$ : Max ambient temperature +50°C
	Connection order	R1 U – DC+ R2 W – DC-
<b>Control characteristics</b>	Control method	Voltage level control, default $U_n+18\%$
	Parallel BCU	Requires synchronization
<b>Ambient conditions</b>	Ambient operating temperature	-10°C (no frost)...+50°C (at $I_{th}$ ) The NX liquid cooled drives must be used in a heated indoor controlled environment
	Installation temperature	0...+70°C
	Storage temperature	-40°C...+70°C; No liquid in heatsink under 0°C
	Relative humidity	5 to 96% RH, non-condensing, no dripping water
	Air quality: - chemical vapours - mechanical particles	IEC 721-3-3, unit in operation, class 3C2 IEC 721-3-3, unit in operation, class 3S2 <ul style="list-style-type: none"><li>• No conductive dust allowed</li><li>• No corrosive gases</li></ul>
	Altitude	NX_5 (380...500 V): max. 3000 m (in case network is not corner grounded) NX_6: max. 2000 m. For further requirements, contact factory 100-% load capacity (no derating) up to 1,000 m; above 1,000 m derating of maximum ambient operating temperature by 0,5°C per each 100 m is required

Table 1. Technical specification for Vacon NXB liquid-cooled brake chopper unit

	Vibration EN50178/EN60068-2-6	5...150Hz Displacement amplitude 0.25 mm (peak) at 3...31 Hz Max acceleration amplitude 1 G at 31...150 Hz
	Shock EN50178, EN60068-2-27	UPS Drop Test (for applicable UPS weights) Storage and shipping: max 15 G, 11 ms (in package)
	Cooling capacity required	See Table 15
	Unit enclosure class	IP00/Open Frame standard in entire kW/HP range
<b>EMC</b>	Immunity	Fulfils all EMC immunity requirements
<b>Safety</b>		CE, UL, EN61800-5-1 (2007) (see unit nameplate for more detailed approvals)
<b>Control connections</b>	Analogue input voltage	0...+10V, $R_i = 200\text{kW}$ , (-10V...+10V joystick control) Resolution 0.1%, accuracy $\pm 1\%$
	Analogue input current	0(4)...20 mA, $R_i = 250\text{W}$ differential
	Digital inputs (6)	Positive or negative logic; 18...30VDC
	Auxiliary voltage	+24V, $\pm 10\%$ , max. 250mA
	Output reference voltage	+10V, +3%, max. load 10mA
	Analogue output	0(4)...20mA; RL max. 500W; Resolution 10 bit; Accuracy $\pm 2\%$
	Digital outputs	Open collector output, 50mA/48V
	Relay outputs	2 programmable change-over relay outputs Switching capacity: 24VDC/8A, 250VAC/8A, 125VDC/ 0.4A Min. switching load: 5V/10mA
<b>Protections</b>	Oversupply trip limit	NX_5: 911V; NX_6 (CH62, CH63 & CH64): 1258V; NX_6 (Other chassis): 1200V (all VDC)
	Undervoltage trip limit	NX_5: 333VDC; NX_6: 461V (all VDC)
	Overcurrent protection	Yes
	Unit overtemperature protection	Yes
	Resistor overtemperature protection	Yes
	Wrong connection protection	Yes
	Short-circuit protection of +24V and +10V reference voltages	Yes
<b>Liquid cooling</b>	Allowed cooling agents	Drinking water (see specification on page 46) Water-glycol mixture See derating specifications, chapter 5.3

*Table 1. Technical specification for Vacon NXB liquid-cooled brake chopper unit*

Volume	See page 51.
Temperature of cooling agent	0...35°C (lbr)(input); 35...55°C: derating required, see Chapter 5.3 . Max. temperature rise during circulation 5°C No condensation allowed. See Chapter 5.2.1.
Cooling agent flow rates	See Table 15.
System max. working pressure	6 bar
System max. peak pressure	40 bar
Pressure loss (at nominal flow)	Varies according to size. See Table 16 .

## 10.5 BCU POWER RATINGS

### 10.5.1 VACON NXB; DC VOLTAGE 460–800V

*Table 2. Power ratings of Vacon NXB, supply voltage 460–800Vdc*

NXB type	Braking voltage 460–800 Vdc						Chassis
	Loadability				Braking capacity		
	BCU rated cont. braking current, $I_{br}$ [A]	Rated min resistance @800VDC [ $\Omega$ ]	Rated min resistance @600VDC [ $\Omega$ ]	Rated max input current [Adc]	Rated cont. braking power $2 \cdot R \cdot 800VDC$ [kW] <sup>*</sup>	Rated cont. braking power $2 \cdot R \cdot 600VDC$ [kW] <sup>**</sup>	
NXB_0031 5	2*31	25.7	19.5	62	49	37	CH3
NXB_0061 5	2*61	13.1	9.9	122	97	73	CH3
NXB_0087 5	2*87	9.2	7.0	174	138	105	CH4
NXB_0105 5	2*105	7.6	5.8	210	167	127	CH4
NXB_0140 5	2*140	5.7	4.3	280	223	169	CH4
NXB_0168 5	2*168	4.7	3.6	336	267	203	CH5
NXB_0205 5	2*205	3.9	3.0	410	326	248	CH5
NXB_0261 5	2*261	3.1	2.3	522	415	316	CH5
NXB_0300 5	2*300	2.7	2.0	600	477	363	CH61
NXB_0385 5	2*385	2.1	1.6	770	613	466	CH61
NXB_0460 5	2*460	1.7	1.3	920	732	556	CH62
NXB_0520 5	2*520	1.5	1.2	1040	828	629	CH62
NXB_0590 5	2*590	1.4	1.1	1180	939	714	CH62
NXB_0650 5	2*650	1.2	1.0	1300	1035	786	CH62
NXB_0730 5	2*730	1.1	0.9	1460	1162	833	CH62

\*. 800 VDC equals  $U_{brake}$  at 500 VAC

\*\*. 600 VDC equals  $U_{brake}$  at 380 VAC

For dimensions of BCU units, see Table 10.

**NOTE:** The rated currents in given ambient (+50°C) and coolant (+30°) temperatures are achieved only when the switching frequency is equal to or less than the factory default.

**NOTE:** Braking power:  $P_{brake} = 2 \cdot U_{brake}^2 / R_{brake}$

**NOTE:** Max input DC current:  $I_{in\_max} = P_{brake\_max} / U_{brake}$

## 10.5.2 VACON NXB; DC VOLTAGE 640-1100V

Table 3. Power ratings of Vacon NXB, supply voltage 640-1100Vdc

Braking voltage 640-1100 VdcNXB_0170 CH61							
NXB type	Loadability				Braking capacity		Chassis
	BCU rated cont. braking current, $I_{br}$ [A]	Rated min resistance @1100VDC [ $\Omega$ ]	Rated min resistance @840VDC [ $\Omega$ ]	Rated max input current [Adc]	Rated cont. braking power $2*R@1100VDC$ [kW] <sup>*</sup>	Rated cont. braking power $2*R@840VDC$ [kW] <sup>**</sup>	
NXB_0170 6	2*170	6,5	4,9	340	372	282	CH61
NXB_0208 6	2*208	5,3	4,0	416	456	346	CH61
NXB_0261 6	2*261	4,2	3,2	522	572	435	CH61
NXB_0325 6	2*325	3,4	2,6	650	713	542	CH62
NXB_0385 6	2*385	2,9	2,2	770	845	643	CH62
NXB_0416 6	2*416	2,6	2,0	832	913	693	CH62
NXB_0460 6	2*460	2,4	1,8	920	1010	767	CH62
NXB_0502 6	2*502	2,2	1,7	1004	1100	838	CH62

\*. 1100 VDC equals  $U_{brake}$  at 690 VAC

\*\*. 840 VDC equals  $U_{brake}$  at 525 VAC

For dimensions of BCU units, see Table 10.

**NOTE:** The rated currents in given ambient (+50°C) and coolant (+30°) temperatures are achieved only when the switching frequency is equal to or less than the factory default.

**NOTE:** Braking power:  $P_{brake} = 2*U_{brake}^2 / R_{resistor}$  when 2 resistors are used

**NOTE:** Max input DC current:  $I_{in\_max} = P_{brake\_max} / U_{brake}$

## 10.6 VACON BRAKE RESISTORS AND BRAKE CHOPPER DIMENSIONING

### 10.6.1 BRAKING ENERGY AND LOSSES

Table 4. Vacon standard brake resistors and NXB energy, mains voltage 465–800Vdc

Mains voltage 465-800 VDC							
BCU type	BCU output			BCU Power loss @ full braking	Chassis		
	Resistor	Brake energy					
	Resistor type & R[Ω]	Light duty 5 sec (kJ)	High Duty 10 sec (kJ)				
NXB 0031 5	BRR0031 / 63	82	220	0,7/0,2/0,9	CH3		
NXB 0061 5	BRR0061 / 14	254	660	1,3/0,3/1,5	CH3		
NXB 0087 5	BRR0061 / 14	254	660	1,5/0,3/1,8	CH4		
NXB 0105 5	BRR0105 / 6,5	546	1420	1,8/0,3/2,1	CH4		
NXB 0140 5	BRR0105 / 6,5	546	1420	2,3/0,3/2,6	CH4		
NXB 0168 5	BRR0105 / 6,5	546	1420	2,5/0,3/2,8	CH5		
NXB 0205 5	BRR0105 / 6,5	546	1420	3,0/0,4/3,4	CH5		
NXB 0261 5	BRR0105 / 6,5	546	1420	4,0/0,4/4,4	CH5		
NXB 0300 5	BRR0300 / 3,3	1094	2842	4,5/0,4/4,9	CH61		
NXB 0385 5	BRR0300 / 3,3	1094	2842	5,5/0,5/6,0	CH61		
NXB 0460 5	BRR0300 / 3,3	1094	2842	5,5/0,5/6,0	CH62		
NXB 0520 5	BRR0520 / 1,4	2520	6600	6,5/0,5/7,0	CH62		
NXB 0590 5	BRR0520 / 1,4	2520	6600	7,5/0,6/8,1	CH62		
NXB 0650 5	BRR0520 / 1,4	2520	6600	8,5/0,6/9,1	CH62		
NXB 0730 5	BRR0730 / 0,9	3950	10264	10,0/0,7/10,7	CH62		

Table 5. Vacon standard brake resistors and NXB energy, mains voltage 640–1100Vdc

Mains voltage 640-1100 VDC							
BCU type	BCU output			BCU Power loss @ full braking	Chassis		
	Resistor	Brake energy					
	Resistor type & R[Ω]	Light Duty 5 sec (kJ)	High Duty 10 sec (kJ)				
NXB 0170_6	BRR0208 / 7	968	2516	0,7/0,2/0,9	Ch61		
NXB 0208_6	BRR0208 / 7	968	2516	1,3/0,3/1,5	Ch61		
NXB 0261_6	BRR0208 / 7	968	2516	1,5/0,3/1,8	Ch61		
NXB 0325_6	BRR0208 / 7	968	2516	1,8/0,3/2,1	Ch62		
NXB 0385_6	BRR0208 / 7	968	2516	2,3/0,3/2,6	Ch62		
NXB 0416_6	BRR0416 / 2,5	2710	7046	2,5/0,3/2,8	Ch62		
NXB 0460_6	BRR0416 / 2,5	2710	7046	3,0/0,4/3,4	Ch62		

Table 5. Vacon standard brake resistors and NXB energy, mains voltage 640–1100Vdc

Mains voltage 640-1100 VDC					
NXB 0502_6	BRR0416 / 1,7	3986	10362	4,0/0,4/4,4	Ch62

\*. c = power loss into coolant; a = power loss into air; T = **total power loss**; power losses of input chokes not included. All power losses obtained using max. supply voltage and switching frequency of 3.6 kHz and Closed-Loop control mode. All power losses are worst case losses.

Heavy duty braking: 3 s 100%, followed by 7 s decreasing to zero

Light duty braking: 5 s 100%

**NOTE:** The rated currents in given ambient (+50°C) and coolant (+30°) temperatures are achieved only when the switching frequency is equal to or less than the factory default.

**NOTE:** Braking power:  $P_{brake} = 2*U_{brake}^2 / R_{resistor}$  when 2 resistors are used

**NOTE:** Max input DC current:  $I_{in\_max} = P_{brake\_max} / U_{brake}$

#### 10.6.2 BRAKING POWER AND RESISTANCE, MAINS VOLTAGE 380–500VAC/600–800VDC

Table 6. Voltage levels

Voltage	Default +18% DC-link voltage level for braking							
	Vac	380	400	420	440	460	480	500
	Vdc	513	540	567	594	621	648	675
U <sub>br</sub> +18%	605	637	669	701	733	765	797	

Table 7. Maximum braking power

Chas-sis	NXB unit	Thermal current [I <sub>th</sub> ]	Max braking power at DC-link voltages [kW]						
			605	637	669	701	733	765	797
Ch3	NXB 0031_5	31	37,5	39,5	41,5	43,5	45,4	47,4	49,4
Ch3	NXB 0061_5	61	73,9	77,7	81,6	85,5	89,4	93,3	97,2
Ch4	NXB 0087_5	87	105,3	110,9	116,4	122,0	127,5	133,0	138,6
Ch4	NXB 0105_5	105	127,1	133,8	140,5	147,2	153,9	160,6	167,3
Ch4	NXB 0140_5	140	169,5	178,4	187,3	196,3	205,2	214,1	223,0
Ch5	NXB 0168_5	168	203,4	214,1	224,8	235,5	246,2	256,9	267,6
Ch5	NXB 0205_5	205	248,2	261,3	274,3	287,4	300,4	313,5	326,6
Ch5	NXB 0261_5	261	316,0	332,6	349,2	365,9	382,5	399,1	415,8
Ch61	NXB 0300_5	300	363,2	382,3	401,4	420,6	439,7	458,8	477,9
Ch61	NXB 0385_5	385	466,1	490,6	515,2	539,7	564,2	588,8	613,3
Ch62	NXB 0460_5	460	556,9	586,2	615,5	644,8	674,2	703,5	732,8
Ch62	NXB 0520_5	520	629,6	662,7	695,8	729,0	762,1	795,2	828,4
Ch62	NXB 0590_5	590	714,3	751,9	789,5	827,1	864,7	902,3	939,9
Ch62	NXB 0650_5	650	786,9	828,4	869,8	911,2	952,6	994,0	1035,5
Ch62	NXB 0730_5	730	883,8	930,3	976,8	1023,3	1069,9	1116,4	1162,9

**NOTE:** The braking powers indicated in Table 64 can only be achieved with minimum resistance.

Table 8. Minimum resistance

Chassis	NXB unit	Thermal current [I <sub>th</sub> ]	Minimum resistance at DC-link voltages [ohm]						
			605	637	669	701	733	765	797
Ch3	NXB 0031_5	31	19,5	20,6	21,6	22,6	23,6	24,7	25,7
Ch3	NXB 0061_5	61	9,9	10,4	11,0	11,5	12,0	12,5	13,1
Ch4	NXB 0087_5	87	7,0	7,3	7,7	8,1	8,4	8,8	9,2
Ch4	NXB 0105_5	105	5,8	6,1	6,4	6,7	7,0	7,3	7,6
Ch4	NXB 0140_5	140	4,3	4,6	4,8	5,0	5,2	5,5	5,7
Ch5	NXB 0168_5	168	3,6	3,8	4,0	4,2	4,4	4,6	4,7
Ch5	NXB 0205_5	205	3,0	3,1	3,3	3,4	3,6	3,7	3,9
Ch5	NXB 0261_5	261	2,3	2,4	2,6	2,7	2,8	2,9	3,1
Ch61	NXB 0300_5	300	2,0	2,1	2,2	2,3	2,4	2,5	2,7
Ch61	NXB 0385_5	385	1,6	1,7	1,7	1,8	1,9	2,0	2,1
Ch62	NXB 0460_5	460	1,3	1,4	1,5	1,5	1,6	1,7	1,7
Ch62	NXB 0520_5	520	1,2	1,2	1,3	1,3	1,4	1,5	1,5
Ch62	NXB 0590_5	590	1,0	1,1	1,1	1,2	1,2	1,3	1,4
Ch62	NXB 0650_5	650	0,9	1,0	1,0	1,1	1,1	1,2	1,2
Ch62	NXB 0730_5	730	0,8	0,9	0,9	1,0	1,0	1,0	1,1

Table 9. Maximum resistance

Chassis	NXBunit	Thermal current [I <sub>th</sub> ]	Maximum resistance at DC-link voltages [ohm]						
			605	637	669	701	733	765	797
Ch3	NXB 0031_5	31	97,6	102,8	107,9	113,1	118,2	123,3	128,5
Ch3	NXB 0061_5	61	49,6	52,2	54,8	57,5	60,1	62,7	65,3
Ch4	NXB 0087_5	87	34,8	36,6	38,5	40,3	42,1	43,9	45,8
Ch4	NXB 0105_5	105	28,8	30,3	31,9	33,4	34,9	36,4	37,9
Ch4	NXB 0140_5	140	21,6	22,8	23,9	25,0	26,2	27,3	28,4
Ch5	NXB 0168_5	168	18,0	19,0	19,9	20,9	21,8	22,8	23,7
Ch5	NXB 0205_5	205	14,8	15,5	16,3	17,1	17,9	18,6	19,4
Ch5	NXB 0261_5	261	11,6	12,2	12,8	13,4	14,0	14,6	15,3
Ch61	NXB 0300_5	300	10,1	10,6	11,2	11,7	12,2	12,7	13,3
Ch61	NXB 0385_5	385	7,9	8,3	8,7	9,1	9,5	9,9	10,3
Ch62	NXB 0460_5	460	6,6	6,9	7,3	7,6	8,0	8,3	8,7
Ch62	NXB 0520_5	520	5,8	6,1	6,4	6,7	7,0	7,4	7,7
Ch62	NXB 0590_5	590	5,1	5,4	5,7	5,9	6,2	6,5	6,8
Ch62	NXB 0650_5	650	4,7	4,9	5,1	5,4	5,6	5,9	6,1
Ch62	NXB 0730_5	730	4,1	4,4	4,6	4,8	5,0	5,2	5,5

**10.6.3 BRAKING POWER AND RESISTANCE, MAINS VOLTAGE 525–690VAC/840–1100VDC**

*Table 10. Voltage levels*

Voltage	Default +18% DC-link voltage level for braking							
	Vac	525	550	575	600	630	660	690
	Vdc	708,8	742,5	776,3	810	850,5	891	931,5
U <sub>br</sub> +18%	836	876	916	956	1004	1051	1099	

*Table 11. Maximum braking power*

Chas-sis	NXB unit	Thermal current [Ith]	Max braking power at DC-link voltages [kW]						
			836	876	916	956	1004	1051	1099
Ch61	NXB 0170_6	170	284,4	297,9	311,4	325,0	341,2	357,5	373,7
Ch61	NXB 0208_6	208	347,9	364,5	381,0	397,6	417,5	437,4	457,3
Ch62	NXB 0261_6	261	436,6	457,4	478,1	498,9	523,9	548,8	573,8
Ch62	NXB 0325_6	325	543,6	569,5	595,4	621,3	652,3	683,4	714,5
Ch62	NXB 0385_6	385	644,0	674,6	705,3	736,0	772,8	809,6	846,4
Ch62	NXB 0416_6	416	695,8	729,0	762,1	795,2	835,0	874,7	914,5
Ch62	NXB 0460_6	460	769,4	806,1	842,7	879,3	923,3	967,3	1011,2
Ch62	NXB 0502_6	502	839,7	879,7	919,6	959,6	1007,6	1055,6	1103,6

**NOTE:** The braking powers indicated in Table 68 can only be achieved with minimum resistance.

*Table 12. Minimum resistance*

Chassis	NXB unit	Thermal current [Ith]	Minimum resistance at DC-link voltages [ohm]						
			836	876	916	956	1004	1051	1099
Ch61	NXB 0170_6	170	4,9	5,2	5,4	5,6	5,9	6,2	6,5
Ch61	NXB 0208_6	208	4,0	4,2	4,4	4,6	4,8	5,1	5,3
Ch62	NXB 0261_6	261	3,2	3,4	3,5	3,7	3,8	4,0	4,2
Ch62	NXB 0325_6	325	2,6	2,7	2,8	2,9	3,1	3,2	3,4
Ch62	NXB 0385_6	385	2,2	2,3	2,4	2,5	2,6	2,7	2,9
Ch62	NXB 0416_6	416	2,0	2,1	2,2	2,3	2,4	2,5	2,6
Ch62	NXB 0460_6	460	1,8	1,9	2,0	2,1	2,2	2,3	2,4
Ch62	NXB 0502_6	502	1,7	1,7	1,8	1,9	2,0	2,1	2,2

*Table 13. Maximum resistance*

Chassis	NXB unit	Thermal current [Ith]	Maximum resistance at DC-link voltages [ohm]						
			836	876	916	956	1004	1051	1099
Ch61	NXB 0170_6	170	24,6	25,8	26,9	28,1	29,5	30,9	32,3
Ch61	NXB 0208_6	208	20,1	21,1	22,0	23,0	24,1	25,3	26,4
Ch62	NXB 0261_6	261	16,0	16,8	17,5	18,3	19,2	20,1	21,1

Table 13. Maximum resistance

<b>Chassis</b>	<b>NXB unit</b>	<b>Thermal current [I<sub>th</sub>]</b>	<b>Maximum resistance at DC-link voltages [ohm]</b>						
			<b>836</b>	<b>876</b>	<b>916</b>	<b>956</b>	<b>1004</b>	<b>1051</b>	<b>1099</b>
Ch62	NXB 0325_6	325	12,9	13,5	14,1	14,7	15,4	16,2	16,9
Ch62	NXB 0385_6	385	10,9	11,4	11,9	12,4	13,0	13,7	14,3
Ch62	NXB 0416_6	416	10,1	10,5	11,0	11,5	12,1	12,6	13,2
Ch62	NXB 0460_6	460	9,1	9,5	10,0	10,4	10,9	11,4	11,9
Ch62	NXB 0502_6	502	8,3	8,7	9,1	9,5	10,0	10,5	10,9

## 10.7 BRAKE CHOPPER UNIT – FUSE SELECTION

Table 14. BCU fuse selection, mains voltage 465–800Vdc

Chassis	Type	Min res. value, 2* [ohm]	Brk curr ent	Fuse size*	DIN43620		"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts	
					aR fuse part nr.	Qty. of fuses /dr	aR fuse part nr.	Qty. of fuses/dr	aR fuse part nr.	Qty. of fuses/dr
CH3	0016	52,55	32	DIN0	PC70UD13C80PA	2	PC70UD13C63TF	2	-	-
CH3	0022	38,22	44	DIN0	PC70UD13C80PA	2	PC70UD13C80TF	2	-	-
CH3	0031	27,12	62	DIN0	PC70UD13C125PA	2	PC70UD13C125TF	2	-	-
CH3	0038	22,13	76	DIN0	PC70UD13C125PA	2	PC70UD13C125TF	2	-	-
CH3	0045	18,68	90	DIN0	PC70UD13C200PA	2	PC70UD13C200TF	2	-	-
CH3	0061	13,78	122	DIN0	PC70UD13C200PA	2	PC70UD13C200TF	2	-	-
CH4	0072	11,68	144	1	PC71UD13C315PA	2	PC71UD13C315TF	2	-	-
CH4	0087	9,66	174	1	PC71UD13C315PA	2	PC71UD13C315TF	2	-	-
CH4	0105	8,01	210	1	PC71UD13C400PA	2	PC71UD13C400TF	2	-	-
CH4	0140	6,01	280	3	PC73UD13C500PA	2	PC73UD13C500TF	2	-	-
CH5	0168	5,00	336	3	PC73UD13C630PA	2	PC73UD13C630TF	2	-	-
CH5	0205	4,10	410	3	PC73UD11C800PA	2	PC73UD13C800TF	2	-	-
CH5	0261	3,22	522	3	PC73UD90V11CPA	2	PC73UD95V11CTF	2	-	-
CH61	0300	2,80	600	3	PC73UD90V11CPA	2	PC73UD95V11CTF	2	-	-
CH61	0385	2,18	770	3	PC73UD11C800PA	4	PC83UD11C13CTF	2	-	-
CH62	0460	1,83	920	3	PC73UD11C800PA	4	PC73UD13C800TF	4	PC84UD13C15CTQ	2
CH62	0520	1,62	1040	3	PC73UD90V11CPA	4	PC73UD95V11CTF	4	PC84UD12C18CTQ	2
CH62	0590	1,43	1180	3	PC73UD90V11CPA	4	PC73UD95V11CTF	4	PC84UD11C20CTQ	2
CH62	0650	1,29	1300	3	PC73UD90V11CPA	4	PC73UD95V11CTF	4	PC84UD11C22CTQ	2
CH62	0730	1,15	1460		-		PC83UD11C13CTF	4	PC84UD11C24CTQ	2

Table 15. BCU fuse selection, mains voltage 640–1100Vdc

Chassis	Type	Min res. value, 2* [ohm]	Brk curr ent	Fuse size*	DIN43620		"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts	
					aR fuse part nr.	Qty. of fuses /dr	aR fuse part nr.	Qty. of fuses/dr	aR fuse part nr.	Qty. of fuses/dr
CH61	0170	6,51	340	DIN3	PC73UD13C630PA	2	PC73UD13C630TF	2	-	-
CH61	0208	5,32	416	DIN3	PC73UD11C800PA	2	PC73UD13C800TF	2	-	-
CH61	0261	4,24	522	DIN3	PC73UD11C800PA	2	PC73UD13C800TF	2	-	-
CH62	0310	3,41	650	DIN3	PC73UD13C630PA	4	PC83UD12C11CTF	2	-	-
CH62	0385	2,88	770	DIN3	PC73UD13C630PA	4	PC83UD11C13CTF	2	-	-
CH62	0416	2,66	832	DIN3	PC73UD11C800PA	4	PC83UD11C14CTF	2	PC84UD13C15CTQ	2

Table 15. BCU fuse selection, mains voltage 640–1100Vdc


Chassis	Type	Min res. value, 2* [ohm]	Brk curr ent	Fuse size*	DIN43620		"TTF" threaded end "7X" or size 83 with end contacts		"TTQF" threaded end size84 or "PLAF" 2x84 with end contacts	
					aR fuse part nr.	Qty. of fuses /dr	aR fuse part nr.	Qty. of fuses/ dr	aR fuse part nr.	Qty. of fuses/ dr
CH62	0460	2,41	920	DIN3	PC73UD11C800PA	4	PC73UD13C800TF	4	PC84UD13C15CTQ	2
CH62	0502	2,21	1004	DIN3	PC73UD11C800PA	4	PC73UD13C800TF	4	PC84UD13C15CTQ	2

# 11. APPENDICES


## Appendix 1

### Vacon NXW frequency converter and inverter main circuit and control diagrams


#### CH3, FC




#### CH4, FC





## CH5, FC




## CH61, FC







## CH61, INVERTER, CONTROL




## CH62, INVERTER







## CH62, INVERTER, CONTROL




## CH63, FC, MODULE 1








## **CH63, INVERTER, CONTROL**




VANXPLC\_1114\_INS\_uk

## **CH64, INVERTER, PHASE U**




VANXPLC\_1115\_INS\_uk


## **CH64, INVERTER, CONTROL**




CH72, FC




## CH72, FC, CONTROL




## CH74, FC, PHASE U







## Appendix 2

### OETL2500 + OFAX3 + Charging circuit for NX liquid-cooled inverters 1640\_5 to 2300\_5 (3 diagrams)







### Appendix 3

Fuse sizes, Bussman aR fuses

#### Fuse information

Max fuse ambient temperature +50°C.

Fuse sizes can differ in the same chassis. Fuses can be chosen according to the biggest current rating of the chassis to minimize fuse variants.

Check the current rating of the fuse bases according to the input current of the drive.

The physical size of the fuse is chosen on the basis of the fuse current: Current < 400 amps (size 2 fuse or smaller), current < 400 amps (size 3 fuse)

*Table 1. Fuse sizes (Bussman aR) for Vacon NX Liquid-Cooled (500V) frequency converters*

Chassis	Type	Ith [A]	DIN43620		DIN43653 (80mm)		DIN43653 (110mm)		Fuse Un [V]	Fuse In [A]	Qty. of fuses per phase 3~/6~
			aR fuse part nr.	Fuse size	aR fuse part nr.	Fuse size	aR fuse part nr.	Fuse size			
CH3	0016	16	170M1565	DIN000	170M1415	000T/80			690	63	1
CH3	0022	22	170M1565	DIN000	170M1415	000T/80			690	63	1
CH3	0031	31	170M1565	DIN000	170M1415	000T/80			690	63	1
CH3	0038	38	170M1565	DIN000	170M1415	000T/80			690	63	1
CH3	0045	45	170M1567	DIN000	170M1417	000T/80			690	100	1

Table 1. Fuse sizes (Bussman aR) for Vacon NX Liquid-Cooled (500V) frequency converters

Chassis	Type	Ith [A]	DIN43620		DIN43653 (80mm)		DIN43653 (110mm)		Fuse Un [V]	Fuse In [A]	Qty. of fuses per phase 3~/6~
			aR fuse part nr.	Fuse size	aR fuse part nr.	Fuse size	aR fuse part nr.	Fuse size			
CH3	0061	61	170M1567	DIN000	170M1417	000T/80			690	100	1
CH4	0072	72	170M3815	DIN1 <sup>1</sup>	170M3065	1*TN/80	170M3215	1*TN/110	690	200	1
CH4	0087	87	170M3815	DIN1 <sup>1</sup>	170M3065	1*TN/80	170M3215	1*TN/110	690	200	1
CH4	0105	105	170M3815	DIN1 <sup>1</sup>	170M3065	1*TN/80	170M3215	1*TN/110	690	200	1
CH4	0140	140	170M3815	DIN1 <sup>1</sup>	170M3065	1*TN/80	170M3215	1*TN/110	690	200	1
CH5	0168	168	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH5	0205	205	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH5	0261	261	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH61	0300	300	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH61	0385	385	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH72	0460	460	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH72 <sup>2</sup>	0460	460	170M6813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH72	0520	520	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH72 <sup>2</sup>	0520	520	170M6813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH72	0590	590	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH72 <sup>2</sup>	0590	590	170M6813	DIN2	170M5063	2TN/80	170M5213	32N/110	690	700	1
CH72	0650	650	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	1
CH72 <sup>2</sup>	0650	650	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH72	0730	730	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	1
CH72 <sup>2</sup>	0730	730	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH63	0820	820	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH63	0920	920	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH63	1030	1030	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	2
CH63	1150	1150	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	2
CH74	1370	1370	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	3
CH74 <sup>2</sup>	1370	1370	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH74	1640	1640	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	3
CH74 <sup>2</sup>	1640	1640	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH74	2060	2060	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	3
CH74 <sup>2</sup>	2060	2060	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	2
CH74	2300	2300	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	3
CH74 <sup>2</sup>	2300	2300	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	2

<sup>1</sup> T<sub>j</sub> = 25°C<sup>2</sup> Data in Italic refer to drives with 12-pulse supply<sup>3</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size

Table 2. Fuse sizes (Bussman aR) for Vacon NX Liquid-Cooled (690V) frequency converters

Chassis	Type	I <sub>th</sub> [A]	DIN43620		DIN43653 (80mm)		DIN43653 (110mm)		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses per phase 3~/6~
			aR fuse part nr.	Fuse size	aR fuse part nr.	Fuse size	aR fuse part nr.	Fuse size			
CH61	0170	170	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH61	0208	208	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH61	0261	261	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH72	0325	325	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH72 <sup>2</sup>	0325	325	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH72	0385	385	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	1
CH72 <sup>2</sup>	0385	385	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH72	0416	416	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH72 <sup>2</sup>	0416	416	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH72	0460	460	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH72 <sup>2</sup>	0460	460	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH72	0502	502	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH72 <sup>2</sup>	0502	502	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH63	0590	590	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1100	1
CH63	0650	650	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	1
CH63	0750	750	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	1
CH74	0820	820	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	3
CH74 <sup>2</sup>	0820	820	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH74	0920	920	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	3
CH74 <sup>2</sup>	0920	920	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH74	1030	1030	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	3
CH74 <sup>2</sup>	1030	1030	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH74	1180	1180	170M5813	DIN2	170M5063	2TN/80	170M5213	2TN/110	690	700	3
CH74 <sup>2</sup>	1180	1180	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH74	1300	1300	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	3
CH74 <sup>2</sup>	1300	1300	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	1
CH74	1500	1500	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	3
CH74 <sup>2</sup>	1500	1500	170M8547	3SHT <sup>3</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	1
CH74	1700	1700	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	3
CH74 <sup>2</sup>	1700	1700	170M6812	DIN3	170M6064	3TN/80	170M6212	3TN/110	690	800	1

<sup>1</sup> T<sub>j</sub> = 25°C<sup>2</sup> Data in Italic refer to drives with 12-pulse supply<sup>3</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size

Table 3. Fuse sizes (Bussman aR) for Vacon NX Liquid-Cooled (450–800V) inverters

Chassis	Type	I <sub>th</sub> [A]	DIN43620		DIN43653 (80mm)		DIN43653 (110mm)		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses/ pole
			aR fuse part nr.	Fuse size	aR fuse part nr	Fuse size	aR fuse part nr.	Fuse size			
CH3	0016	16	170M3810	DIN1 <sup>1</sup>	170M3060	1*TN/80	170M3210	1*TN/110	690	63	1
CH3	0022	22	170M3810	DIN1 <sup>1</sup>	170M3060	1*TN/80	170M3210	1*TN/110	690	63	1
CH3	0031	31	170M3810	DIN1 <sup>1</sup>	170M3060	1*TN/80	170M3210	1*TN/110	690	63	1
CH3	0038	38	170M3813	DIN1 <sup>1</sup>	170M3063	1*TN/80	170M3213	1*TN/110	690	125	1
CH3	0045	45	170M3813	DIN1 <sup>1</sup>	170M3063	1*TN/80	170M3213	1*TN/110	690	125	1
CH3	0061	61	170M3813	DIN1 <sup>1</sup>	170M3063	1*TN/80	170M3213	1*TN/110	690	125	1
CH4	0072	72	170M3815	DIN1 <sup>1</sup>	170M3063	1*TN/80	170M3213	1*TN/110	690	200	1
CH4	0087	87	170M3815	DIN1 <sup>1</sup>	170M3065	1*TN/80	170M3215	1*TN/110	690	200	1
CH4	0105	105	170M3815	DIN1 <sup>1</sup>	170M3065	1*TN/80	170M3215	1*TN/110	690	200	1
CH4	0140	140	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH5	0168	168	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH5	0205	205	170M3819	DIN1 <sup>1</sup>	170M3069	1*TN/80	170M3219	1*TN/110	690	400	1
CH5	0261	261	170M6808	DIN3	170M6058	3TN/80	170M6208	3TN/110	690	500	1
CH61	0300	300	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH61	0385	385	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	1
CH62	0460	460	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH62	0520	520	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	1
CH62	0590	590	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH62	0650	650	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH62	0730	730	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	2
CH63	0820	820	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	2
CH63	0920	920	170M6814	DIN3	170M6064	3TN/80	170M6214	3TN/110	690	1000	2
CH63	1030	1030	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	3
CH63	1150	1150	170M6812	DIN3	170M6062	3TN/80	170M6212	3TN/110	690	800	3
CH64	1370	1370	170M8547	3SHT <sup>2</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	3
CH64	1640	1640	170M8547	3SHT <sup>2</sup>	170M6066	3TN/80	170M6216	3TN/110	690	1250	3
CH64	2060	2060	170M8550	3SHT <sup>2</sup>	170M6069	3TN/80	170M6219	3TN/110	690	1600	3
CH64	2300	2300	170M8550	3SHT <sup>2</sup>	170M6069	3TN/80	170M6219	3TN/110	690	1600	3

<sup>1</sup> T<sub>j</sub> = 25°C<sup>2</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size

Table 4. Fuse sizes (Bussman aR) for Vacon NX Liquid-Cooled (640–1100V) inverters

Chassis	Type	I <sub>th</sub> [A]	DIN43620		DIN43653 (110mm)		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses/ pole
			aR fuse part nr.	Fuse size <sup>1</sup>	aR fuse part nr.	Fuse size			
CH61	0170	170	170M4199	1SHT	170M4985	1TN/110	1250	400	1
CH61	0208	208	170M4199	1SHT	170M4985	1TN/110	1250	400	1
CH61	0261	261	170M6202	3SHT	170M8633	3TN/110	1250	500	1
CH62	0325	325	170M6305	3SHT	170M8636	3TN/110	1250	700	1
CH62	0385	385	170M6305	3SHT	170M8636	3TN/110	1250	700	1
CH62	0416	416	170M6277	3SHT	170M8639	3TN/110	1100	1000	1
CH62	0460	460	170M6277	3SHT	170M8639	3TN/110	1100	1000	1
CH62	0502	502	170M6277	3SHT	170M8639	3TN/110	1100	1000	1
CH63	0590	590	170M6305	3SHT	170M8636	3TN/110	1250	700	2
CH63	0650	650	170M6305	3SHT	170M8636	3TN/110	1250	700	2
CH63	0750	750	170M6305	3SHT	170M8636	3TN/110	1250	700	2
CH64	0820	820	170M6277	3SHT	170M8639	3TN/110	1100	1000	2
CH64	0920	920	170M6277	3SHT	170M8639	3TN/110	1100	1000	2
CH64	1030	1030	170M6277	3SHT	170M8639	3TN/110	1250	700	3
CH64	1180	1180	170M6277	3SHT	170M8639	3TN/110	1100	1000	3
CH64	1300	1300	170M6277	3SHT	170M8639	3TN/110	1100	1000	3
CH64	1500	1500	170M6277	3SHT	170M8639	3TN/110	1100	1000	3
CH64	1700	1700	170M6277	3SHT	170M8639	3TN/110	1100	1000	3

<sup>1</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size

Table 5. Fuse sizes (Bussman aR) for Vacon NX AFE units (380–500V)

Chassis	Type	I <sub>th</sub> [A]	DIN43620		DIN43653 (80mm)		DIN43653 (110mm)		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses / phase 3~
			aR fuse part nr.	Fuse size <sup>1</sup>	aR fuse part nr.	Fuse size <sup>1</sup>	aR fuse part nr.	Fuse size <sup>1</sup>			
CH3	0016	16	170M2679	DIN00	170M4828	00TN/80			1000	63	1
CH3	0022	22	170M2679	DIN00	170M4828	00TN/80			1000	63	1
CH3	0031	31	170M2679	DIN00	170M4828	00TN/80			1000	63	1
CH3	0038	38	170M2679	DIN00	170M4828	00TN/80			1000	63	1
CH3	0045	45	170M2683	DIN00	170M4832	00TN/80			1000	160	1
CH3	0061	61	170M2683	DIN00	170M4832	00TN/80			1000	160	1
CH4	0072	72	170M2683	DIN00	170M4832	00TN/80			1000	160	1
CH4	0087	87	170M2683	DIN00	170M4832	00TN/80			1000	16	1
CH4	0105	105	170M2683	DIN00	170M4832	00TN/80			1000	160	1
CH4	0140	140	170M4199	1SHT			170M4985	1TN/110	1250	400	1
CH5	0168	168	170M4199	1SHT			170M4985	1TN/110	1250	400	1
CH5	0205	205	170M4199	1SHT			170M4985	1TN/110	1250	400	1
CH5	0261	261	170M4199	1SHT			170M4985	1TN/110	1250	400	1
CH61	0300	300	170M6202	3SHT			170M8633	3TN/110	1250	500	1
CH61	0385	385	170M6305	3SHT			170M8636	3TN/110	1250	700	1
CH62	0460	460	170M6277	3SHT			170M8639	3TN/110	1100	1000	1
CH62	0520	520	170M6277	3SHT			170M8639	3TN/110	1100	1000	1

Table 5. Fuse sizes (Bussman aR) for Vacon NX AFE units (380—500V)

Chassis	Type	I <sub>th</sub> [A]	DIN43620		DIN43653 (80mm)		DIN43653 (110mm)		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses / phase 3~
			aR fuse part nr.	Fuse size <sup>1</sup>	aR fuse part nr.	Fuse size <sup>1</sup>	aR fuse part nr.	Fuse size <sup>1</sup>			
CH62	0590	590	170M6277	3SHT			170M8639	3TN/110	1100	1000	1
CH62	0650	650	170M6305	3SHT			170M8636	3TN/110	1250	700	2
CH62	0730	730	170M6305	3SHT			170M8636	3TN/110	1250	700	2
CH63	0820	820	170M6305	3SHT			170M8636	3TN/110	1250	700	2
CH63	0920	920	170M6277	3SHT			170M8639	3TN/110	1100	1000	2
CH63	1030	1030	170M6277	3SHT			170M8639	3TN/110	1100	1000	2
CH63	1150	1150	170M6277	3SHT			170M8639	3TN/110	1100	1000	2
CH64	1370	1370	170M6277	3SHT			170M8639	3TN/110	1100	1000	3
CH64	1640	1640	170M6277	3SHT			170M8639	3TN/110	1100	1000	3
CH64	2060	2060	170M6277	3SHT			170M8639	3TN/110	1100	1000	4
CH64	2300	2300	170M6277	3SHT			170M8639	3TN/110	1100	1000	4

<sup>1</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size

Table 6. Fuse sizes (Bussman aR) for Vacon NX AFE units (525–690V)

Chassis	Type	I <sub>th</sub> [A]	DIN43620		DIN43653 (110mm)		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses / phase 3~
			aR fuse part nr.	Fuse size <sup>1</sup>	aR fuse part nr.	Fuse size <sup>1</sup>			
CH61	0170	170	170M4199	1SHT	170M4985	1TN/110	1250	400	1
CH61	0208	208	170M4199	1SHT	170M4985	1TN/110	1250	400	1
CH61	0261	261	170M4199	1SHT	170M4985	1TN/110	1250	400	1
CH62	0325	325	170M6305	3SHT	170M8636	3TN/110	1250	700	1
CH62	0385	385	170M6305	3SHT	170M8636	3TN/110	1250	700	1
CH62	0416	416	170M6305	3SHT	170M8636	3TN/110	1250	700	1
CH62	0460	460	170M6277	3SHT	170M8639	3TN/110	1100	1000	1
CH62	0502	502	170M6277	3SHT	170M8639	3TN/110	1100	1000	1
CH63	0590	590	170M6277	3SHT	170M8639	3TN/110	1100	1000	1
CH63	0650	650	170M6305	3SHT	170M8636	3TN/110	1250	700	2
CH63	0750	750	170M6305	3SHT	170M8636	3TN/110	1250	700	2
CH64	0820	820	170M6305	3SHT	170M8636	3TN/110	1250	700	2
CH64	0920	920	170M6277	3SHT	170M8639	3TN/110	1100	1000	2
CH64	1030	1030	170M6277	3SHT	170M8639	3TN/110	1100	1000	2
CH64	1180	1180	170M6277	3SHT	170M8639	3TN/110	1100	1000	2
CH64	1300	1300	170M6305	3SHT	170M8636	3TN/110	1250	700	3
CH64	1500	1500	170M6277	3SHT	170M8639	3TN/110	1100	1000	3

<sup>1</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size

Table 7. Brake chopper unit fuse selection (Bussman aR), mains voltage 465–800Vdc

Chassis	Type	Min resistor value, 2* [ohm]	Braking current	DIN43620		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses per pole
				aR fuse part nr.	Fuse size <sup>1</sup>			
CH3	0016	52,55	32	170M2679	DIN00	690	63	1
CH3	0022	38,22	44	170M2679	DIN00	690	63	1
CH3	0031	27,12	62	170M2679	DIN00	690	63	1
CH3	0038	22,13	76	170M2679	DIN00	690	63	1
CH3	0045	18,68	90	170M2683	DIN00	690	160	1
CH3	0061	13,78	122	170M2683	DIN00	690	160	1
CH4	0072	11,68	144	170M2683	DIN00	690	160	1
CH4	0087	9,66	174	170M2683	DIN00	690	160	1
CH4	0105	8,01	210	170M2683	DIN00	690	160	1
CH4	0140	6,01	280	170M4199	1SHT	690	400	1
CH5	0168	5,00	336	170M4199	1SHT	690	400	1
CH5	0205	4,10	410	170M4199	1SHT	690	400	1
CH5	0261	3,22	522	170M4199	1SHT	690	400	1
CH61	0300	2,80	600	170M6202	3SHT	690	500	1
CH61	0385	2,18	770	170M6305	3SHT	690	700	2
CH62	0460	1,83	920	170M6277	3SHT	690	1000	2
CH62	0520	1,62	1040	170M6277	3SHT	690	1000	2
CH62	0590	1,43	1180	170M6277	3SHT	690	1000	2
CH62	0650	1,29	1300	170M6305	3SHT	690	700	3
CH62	0730	1,15	1460	170M6305	3SHT	690	700	3

Table 8. Brake chopper unit fuse selection (Bussman aR), mains voltage 640–1100Vdc

Chassis	Type	Min resistor value, 2* [ohm]	Braking current	DIN43620		Fuse U <sub>n</sub> [V]	Fuse I <sub>n</sub> [A]	Qty. of fuses per pole
				aR fuse part nr.	Fuse size <sup>1</sup>			
CH61	0170	6,51	340	170M6305	3SHT	1250	700	1
CH61	0170*	80	27	170M2679	DIN00	1000	63	1
CH61	0208	5,32	416	170M6277	3SHT	1250	1000	1
CH61	0208*	30	73	170M2683	DIN00	1000	160	1
CH61	0261	4,24	522	170M6277	3SHT	1250	1000	1
CH61	0261*	12	183	170M4199	1SHT	1250	400	1
CH62	0310	3,41	650	170M6305	3SHT	1250	700	2
CH62	0385	2,88	770	170M6277	3SHT	1250	1000	2
CH62	0416	2,66	832	170M6277	3SHT	1250	1000	2
CH62	0460	2,41	920	170M6277	3SHT	1250	1000	2
CH62	0502	2,21	1004	170M6277	3SHT	1250	1000	2

<sup>1</sup> SHT fuses can be assembled into DIN fuse base of the corresponding size



# VACON

DRIVEN BY DRIVES

Find your nearest Vacon office  
on the Internet at:

[www.vacon.com](http://www.vacon.com)

Manual authoring:  
[documentation@vacon.com](mailto:documentation@vacon.com)

Vacon Plc.  
Runsortie 7  
65380 Vaasa  
Finland

Subject to change without prior notice  
© 2011 Vacon Plc.

Document ID:



Rev. A