



ULTRASONIC LEVEL METERS ULM-70

Firmware: v.2.0

TABLE OF CONTENTS

1. Measuring principle	3
2. Range of applications	3
3. Features of variants	3
4. Dimensional drawings	4
5. Installation instructions	5
6. Electrical connection	8
7. Set-up elements	9
8. Status signalization	9
9. Operation and setting	10
9.1. Basic configuration	10
9.2. Advanced settings	12
9.3. Additional functions	15
10. HART® communication protocol	18
11. Order code	18
12. Accessories	18
13. Safety, protection, compatibility and explosion proof	19
14. Use, manipulation and maintenance	19
15. Marking of labels	20
16. Menu structure	22
17. Specifications	23

SAFETY



All operations described in this instruction manual have to be carried out only by trained personnel or an accredited person. Warranty and post warranty service must be exclusively carried out by the manufacturer.

Improper use, installation or set-up of the level meter can result in crashes in the application (overflowing of the tank or damage of system components).

The manufacturer is not responsible for improper use, losses of work caused by either direct or indirect damage, and for expenses incurred during installation or use of the level meter.

1. MEASURING PRINCIPLE

Ultrasonic level meter ULM® is a compact measuring device consisting of two parts - main level meter (the body with measuring electronics) and display module. Using the electroacoustic converter, the level meters transmit the sequence of ultrasonic pulses that spread towards the surface level. The converter recuperates reflected acoustic waves that are subsequently processed in the electronic module. The intelligent evaluation block filters out interfering signals, compares the cleaned received signal with the false reflection map (e.g. from mixers, ladders, reinforcement etc.) and selects a suitable reflection (echo). Based on the period during which the individual pulses spread towards the surface level and back and based on the measured temperature in the tank, the instant distance to the surface level is calculated. According to the level height, the level meter output is set and the measured value is displayed on the display.

2. RANGE OF APPLICATIONS

For continuous non-contact level measurement of liquids (water solutions, sewerage water, etc.), mash and paste materials (sediments, sticks, resins etc.) in closed or open vessels, sumps, reservoirs and open channels. In case the level of bulk-solid materials is measured, the measurement range is reduced. The level meters can continuously measure levels of bulk-solid materials with a low concentration of dust particles. Consult the manufacturer on recommended use of the level meter for bulk-solid materials.

3. FEATURES OF VARIANTS

ULM-70_-02 **Measuring range from 0.15m to 2m**, plastic PVDF transmitter, mechanical connection with thread G 1".


ULM-70_-06 **Measuring range from 0.25m to 6m**, plastic PVDF transmitter, mechanical connection with thread G 1 ½".

ULM-70_-10 **Measuring range from 0.4m to 10m**, plastic PVDF transmitter, mechanical connection with HDPE polyethylene flange (version "N") or aluminium alloy flange (version "Xi").


ULM-70_-20 **Measuring range from 0.5m to 20m**, plastic PVDF transmitter, mechanical connection with aluminium alloy flange.

4. DIMENSIONAL DRAWINGS


ULM-70_02




ULM-70_06




ULM-70N-10



ULM-70Xi-10



ULM-70_20



5. INSTALLATION INSTRUCTIONS

- Install the level meter in the **vertical position** into the upper lid of the tank or reservoir using a welding flange, a fastening nut or a flange so that the level meter axis can be perpendicular to the surface level of the measured liquid (Fig. 1).
- The min. **dimensional parameters** to install the level meter into a lid or a ceiling of a tank are given in Fig. 3.
- When installing in an **open channel** (reservoir, drain etc.), install the level meter onto a bracket as close as possible to the expected max. level.
- In connection with the measurement principle, no signals **reflected** in the area immediately under the level meter can be evaluated. **The zone** (Fig. 2) determines the min. distance possible between the level meter and the highest surface level. The min. distances to the medium are given in the chapter "Specifications".
- It is necessary to install the level meter so that the bin level cannot **interfere** with the dead zone when filled up to the maximum. If the measured level interferes with the dead zone, the level meter will not work properly.




Fig. 1: Recommended installation in the tank

ULM-70-02; 10	$d > 1/12 c$ (min. 200 mm)
ULM-70-06	$d > 1/8 c$ (min. 200 mm)
ULM-70-20	$d > 1/10 c$ (min. 200 mm)




Fig. 2: Level meter dead zone




Fig. 3: Installation distance from the tank wall

- If the maximum surface level in the tank interferes with the dead zone, the level meter has to be mounted into a higher **installation neck**. In this way, the tank can be filled nearly up to the maximum volume. The inner neck surface has to be even and smooth (without edges and welded joints); the inner edge should be rounded where the ultrasonic wave leaves the pipe. The neck diameter should be as large as possible but the neck height should be as low as possible. Recommended dimensions of the input neck are given in Fig. 4.




Fig. 4: Possible installation of the installation neck

ULM-70-02; 06	$a < 3 b$ $b > 100 \text{ mm}$
ULM-70-10	$a < 1,5 b$ $b > 100 \text{ mm}$
ULM-70-20	$a < 1,5 b$ $b > 150 \text{ mm}$

- During filling, mixing and other processes, **foam** can arise on the surface level of the measured liquid. The thick foam considerably absorbs the ultrasonic signal which might cause malfunction of the level meter (Fig. 5). For such cases, it is necessary to set up "SENSITIVITY" mode to "high" or contact the manufacturer if need.
- If the emitted acoustic signal of the level meter is affected by near objects (roughness on walls of the tank, various partitions, mixers etc.), it is necessary to map false reflections by activating the mode "TEACHING". In case of installed mixers, it is necessary to put the mixers to position under the level meter (direct the mixer paddle to the ultrasonic signal beam).




Fig. 5: Thick foam on the surface




Fig. 6: False echo from obstacles in the tank




Fig. 7: False echo from the mixer paddle

- Do not install the level meter in or above the **filling** point (Fig. 8).
- In case the level of bulk-solid materials is measured, the measurement range is reduced. We recommend to consult the use with the manufacturer.




Fig. 8: Level meter installation outside the influence of filling

- The level meter must not be installed in places with direct **solar radiation** and must be protected against weather effects.
- If the installation in places with direct solar radiation is inevitable, it is necessary to mount a **shielding cover** above the level meter.
- It is suitable to run the cable under a cable bushing (obliquely down in slack) according to Fig. 10 to prevent **penetration of humidity**. Then the rain and condensing water can flow off freely.
- The cable bushing and connector have to be **sufficiently tightened** to prevent penetration of humidity.
- To lower the minimum distance to the measured medium, **a reflection board** made from solid, even and smooth material can be installed to the level meter. Then the tank can be filled nearly up to the maximum height. The solution is suitable for open tanks and reservoirs.
- Scattering or attenuation of the ultrasonic signal can result if the surface level has been **moderately stirred** or **rippled** (by a mixer, coming liquid etc.). It can result in reduction of the measurement range or unreliable function of the level meter (Fig. 12).
- Rotating **mixer blades** can cause that the surface is stirred, which results in false reflections of the ultrasonic signal from the surface level and unreliable operation of the level meter (Fig. 13).




Fig. 9: Solar radiation shielding cover




Fig. 10: Prevention to avoid intrusion of humidity

H + L = Dead zone
(blind zone, blocking dist.)




Fig. 11: Reflection board




Fig. 12: Moderately stirred surface




Fig. 13: Intensely stirred surface

6. ELECTRICAL CONNECTION

The ultrasonic level meter is designed to be connected to supply unit or to controller through a cable with the outer diameter of $6 \div 8$ mm (recommended cross-section of cores $0.5 \div 0.75$ mm²) by means of bolted clips placed under display module. Connect the plus pole (+U) to the terminal (+), the minus pole to 0 V to the terminal (-) and the shielding to the terminal (\perp) (only for shielded cables).

Procedure to connect the cable to the level meter:

1. Unscrew the nut of the upper transparent lid.
2. Take the upper edge of the display module and take it out carefully by mild swinging up.
3. If you cannot grasp the module, you can use a small screwdriver. Insert it as far as the seam and use from several sides to slightly lift the module.
4. Release the cable bushing and thread the stripped supply cable in.
5. Connect the cable into the bolted clips according to the diagram in Fig. 14.
6. Assemble the level meter and connect the cable to the sequential unit.




Fig. 14: Connection diagram of the level meter




Fig. 15: Internal view of terminal block



Electrical connection must be done in de-energized state!

With regard to possible occurrence of electrostatic charge on non-conductive parts of the level meter for explosive areas (ULM-70Xi-__-), level meters must be grounded with ground terminal! It will be done using a screw placed on the head of the level meter under the cable bushing.



The voltage source should be preferably realized as a stabilized power supply unit with safe voltage from 18 to 36 V DC ($18 \div 30$ V DC for Xi version), which can be a part of the evaluation or display device.

In case of strong electromagnetic interferences (EMI), parallel cable ducting with power lines, or when cable length exceeds 30m we recommended to use shielded cable.

7. SET-UP ELEMENTS



Fig. 16: Full view of ultrasonic level meter

Button



- Set-up mode access
- Confirmation of selected item in the menu
- Move the cursor in the line
- Saving of set-up data

Button

- Move in the menu
- Change of values

Button

- Cancelling of carried out changes
- Shift one level up



8. STATUS SIGNALIZATION

display	function
"NO ECHO"	Lighting intermittently – the level meter is not able to receive echo for a long time. Incorrect installation of the level meter
"DEAD ZONE"	Lighting intermittently – the measured level is in the "dead zone" of the level meter or the ultrasonic converter is dirty.
"NO PASSWORD"	It will appear in the item "MENU" – the level meter is protected using a password against unauthorised setting. Enter the correct password (see p. 17).
Symbol "T" ¹⁾	Lighting permanently – "TEACHING" mode activation.
Symbol "E" ¹⁾	Lighting intermittently – correct echo receiving (of the reflected signal) from the measured surface level.
Symbol "L" ¹⁾	Lighting permanently – level meter is locked against unauthorized settings by a password. You must enter the correct password to unlock it (see page 16).

¹⁾ symbol appears in the lower left corner of the display


9. OPERATION AND SETTING

Set the level meter using 3 buttons placed on the display module (see Chapter Set-up elements). After 5 min. of inactivity, the level meter automatically returns back to the measurement mode. If the password is active, the level meter will be also locked. The values that have not been confirmed using the button **OK** will not be saved! After the meter is locked, you cannot change the setting! When you attempt to edit, the words "NO PASSWORD" will appear on the display. How to unlock the level meter is given on page 16. After connection of the supply voltage to the level meter the display shows the logo "Dinel" and the text "Starting" (approx. 15 s). Then, the level meter goes to the measuring mode and the display shows the current measured value.





9.1. BASIC CONFIGURATION

After the first start of the level meter it is necessary to perform the basic configuration (setting of the measuring range, choice of units and possibly damping). The settings are accessible in the basic menu by pressing **OK** the "BASIC SETTINGS".



MIN LEVEL and MAX LEVEL

You can freely define the **minimum / maximum distance** from the front surface of the level meter (item "LEVEL"), and assign to this distance any current (item "OUTPUT") at the output in the range of 4 to 20 mA. The "DISPLAY" is intended to set the value displayed on the display. Setting the units is done in the "UNITS".



For clarity it is advised to assign a minimum level to current 4 mA and the maximum level to current 20 mA.

ACTUAL LEVEL: Actual distance to level

OUTPUT: Definition of minimum / maximum current in mA

LEVEL: Definition of the min / max level

DISPLAY: The value showed on the display


If in the bottom of the display appears (when entering the values) the inscription "OUT OF LIMITS", the value specified for the item "LEVEL" is outside the measuring range of the level meter. If the inscription "SPAN TOO SMALL" is shown, it must be specified a larger span between Min and Max values. For more information, see chapter "Specifications".

The decimal point position of the item 'LEVEL' is firmly set (according to the selected units), in the item "DISPLAY" it is freely adjustable

1. To enter to the menu press **OK** the same button to select "BASIC SETTINGS". Then, using **↕** and **OK** select "MIN LEVEL" or "MAX LEVEL".
2. Now it is shown the item "MIN LEVEL" ("MAX LEVEL"). By pressing **OK** and **↕** set the output current "OUTPUT", the distance for the defined current "LEVEL" the value on the display "DISPLAY".
3. By pressing **OK** button save the data. By next presses of the button **ESC** leave the menu. The level meter returns to measurement mode.

UNITS

Level meter can process and convert a large number of different **physical values**. The setting is done in the item "UNITS".




LEVEL: Unit selection (mm, cm, m, in, ft)
 DISPLAY: The unit showed on the display (% , mm, cm, m, in, ft, l, hl, m³, gal, bbl, mA)
 TEMPERATURE: Temperature unit (°C, °F)

1. To enter to the menu press **OK** the same button to select "BASIC SETTINGS". Then, using **↕** and **OK** select "UNITS".
2. Now the menu item "UNITS" is shown. By pressing the **OK** and **↕** button make the settings of individual items.
3. By pressing **OK** button save the data. By next presses of the button **ESC** leave the menu. The level meter returns to measurement mode.

DAMPING

Setting the **response time** of the measurements. The function is useful for suppressing level fluctuations, waves and rapid changes of the level. The reaction time of the measurement will be longer and the level meter will respond to rapid changes in a defined delay in seconds.




The damping time can be set in the interval from 0 to 99 s.

1. To enter to the menu press **OK** the same button to select "BASIC SETTINGS". Then, using **↕** and **OK** select "DAMPING".
2. Now the menu item "DAMPING" is shown. By pressing the **OK** and **↕** button make the settings of individual items.
3. By pressing **OK** button save the data. By next presses of the button **ESC** leave the menu. The level meter returns to measurement mode.

9.2. ADVANCED SETTINGS


In the supplemented configuration, you can set parameters of sensitivity, mapping of false reflections, temperature difference compensation, behaviour in case of fault conditions or HART® communication. Here, you can set the sensor into the initial state or reset it as well. The settings are accessible in the basic menu under the item "SERVICE".



SENSITIVITY

The setting is defined in three steps of the level meter **sensitivity**.

- "LOW" – Low sensitivity in case of surrounding interferences affecting the measurement.
- "MEDIUM" – Medium sensitivity (suitable for most applications).
- "HIGH" – Enhanced sensitivity for measured mediums partly absorbing the ultrasonic signal (bulk-solid mat., foams)




You can set the sensitivity in three degrees:
LOW – MEDIUM – HIGH.

TEACHING

The mode serves for **suppressing false reflections** resulting from reflection of the ultrasonic signal from roughnesses on walls of the tank, various partitions, mixers or other obstacles. The sensor starting this mode detects false reflections and save them in the memory. Then these false reflections will not affect the subsequent measurement (they are masked).

Before starting the mode it is necessary to empty the tank as much as possible (preferably completely).



If there are no above obstacles in the tank, it is not necessary to start this mode.

1. To enter to the menu press the same button to select "SERVICE". Then, using and select "TEACHING".
2. Now it is shown the item "TEACHING". By pressing set the value "LEVEL DISTANCE" (distance to the level) – supposed distance from the face of the sensor to the medium level. If the distance to the level is not precisely known, enter a value rather lower (in the tolerance field as shown in Fig. 17).
3. After entering the "SET LEVEL DISTANCE" by pressing button the system starts "teaching" (false reflection mapping). During the mapping, the display shows flashing sign "RUNNING".
4. The mapping of false echoes can be completed when you see the inscription "Press OK to stop" and you press (see note on page 13).
5. The procedure is completely finished when you can see the inscription "DONE". It is then possible to exit the menu by repeated pressing the button .



The mode "TEACHING" will stop automatically after ca. 1000 measurements.

In case of installed mixers, it is **necessary** to position the mixers under the level meter (direct the mixer blade to the ultrasonic signal beam).

Note: If there are significant obstacles in the upper half of the tank, **multiple false reflections** can occur especially in closed tanks. In such cases it is necessary to reduce the level in the tank as much as possible to correctly mask these possible multiple false reflections.




Fig. 17: The "Level distance" zone




If during the scanning of the tank in the bottom of the display appears the dialog "press OK to stop" (see figure) the level meter already found no further obstacles and "TEACHING" mode may be terminated. If it is not terminated, the level meter is still ready for the possible presence of obstacles (e.g. paddles of the agitator). Once it registers a further obstacle, the dialogue disappears and the obstacle is erased. This process may be repeated up to 1000 cycles. After this the "TEACHING" mode is automatically stopped.



MEDIUM TEMPERATURE

The level meter is equipped with **automatic temperature compensation**. If in the tank (open channel) is a big difference between the temperature of the measured medium (liquid) and temperature in the place of installation of the ULM (see mode, "DIAGNOSTICS" page 15), it is advised to improve the precision of the measurement by the zone temperature compensation. Otherwise, this mode is **not necessary to run**.





Inactive compensation (initial state), the word "NO" appears on the display.

See the "UNITS" menu for temperature unit selection (°C or °F).

After start of the zone temperature compensation mode it is necessary to set the temperature of the surface of the medium. The level meter then calculates the average value from the medium temperature and the temperature at the installation place of the level meter. With such an average temperature it counts in calculating of the velocity of acoustic waves propagation and for determination of the level position.

FAILURE MODE

It **defines the output current** of the level meter when the measured medium level is in the dead zone ("DEAD ZONE") or outside the measurement range in case of echo loss ("NO ECHO").



NO ECHO: Current in case of echo loss



DEAD ZONE: Dead zone current

The values can be set in three steps:

3.75 mA, 22 mA and LAST (last measured data).


HART


HART® mode (point to point, multidrop) and multidrop mode **address setting**. Up to 15 units can be connected to one two-wired cable in the multidrop mode.




In case of the address "00", the point to point mode is enabled. The range from "01" to "15" is reserved for addresses in the multidrop mode.

FACTORY DEFAULT


To **reset the initial values** of the level meter set by the manufacturer, press the button  (see the Factory default table, p. 24).




After you press the button  "RUNNING" will be displayed for about 3 sec. After the initial values are set, "DONE" will appear on the display.



RESET

Complete restart of the level meter. The same effect has also a short-time interruption of the supply voltage. To enable the resetting, press the button .





During the restart process, "RUNNING" will be displayed. Then the level meter will be automatically turned off and on.

9.3. ADDITIONAL FUNCTIONS

Additional functions include modes to display temperature in the tank or to find out the actual flowing current in the loop. Besides, to lock modifications using a password and information about the level meter version. All of the functions are accessible from the main menu.

DIAGNOSTICS

It contains information about the actual temperature inside the tank (or about the compensated temperature) "TEMPERATURE" and current flowing through the loop "CURRENT". If the temperature compensation ("MEDIUM TEMPERATURE") is activated, the corrected temperature is displayed.




The temperature is measured inside the tank where the level meter is installed.


If the temperature of the measured medium is different, we recommend you to carry out the temperature compensation "MEDIUM TEMPERATURE" because of accuracy (see p. 15). Then the displayed temperature is an average value from the temperature set in the "MEDIUM TEMPERATURE" and the actual temperature measured by the sensor.

CLONE SETTINGS


This mode is intended for **copying** of the level meter (ULM-70 body) **configuration into the display module** (DM-70) and back. The display module can then be removed from the level meter body and put into another level meter and make there the settings transfer (cloning).




The "CLONE SETTINGS" mode transfers all data, excluding setting of the "Teaching" and HART®.



1. Press **OK** to enter the menu and select the item "CLONE SETTINGS". Copying of the settings from the body of the level meter to display module is done by selecting "SENSOR → DISPLAY MODULE". To transfer the settings from the display module to another level meter select the item DISPLAY MODULE → SENSOR.
2. The selected mode starts by pressing button **OK**. During transmission the display shows "NOW CLONING".
3. After completing the process in the middle of the screen displays "DONE". It is then possible to leave the menu and the mode by pressing the button **Esc**.



▶ **Incompatible type of level meter.** Transfer of the settings can be realized only with the same type of level meter (e.g. ULM-70-02 → ULM-70-02, ULM-70-10 → ULM-70-10) and with the firmware version 2.0 and later.




▶ The data set is **not stored into the display module (DM-70)**. The transfer can not be done. It is necessary to repeat the procedure of the copying the settings in the mode "CLONE SETTINGS".




PASSWORD

You can **lock** the level meter data against **unauthorized editing**. After activating the password the data may be read, but can not be edited. If you try to edit the settings (without true password) the display shows "NO PASSWORD".

The password can be any 5-digit numeric combination. The combination of numbers 00000 is reserved for disabling the password.



1. Use the buttons and in the menu "PASSWORD" to select the mode "ENTER" for entering the password or the mode "CHANGE" for changing the password (when activated, the words are displayed inversely). Press the button once again to confirm the selection. You can change the password only when the level meter is unlocked. Otherwise, the words "NO PASSWORD" will be displayed.
2. Now you can edit the password. The actual edited item is displayed inversely. Press the button to move to the next position (clockwise direction), button serves to change the values (0 ... 9).
3. After the operation is completed, confirm the edited data by pressing the button .



Display of status information to confirm data:

"YES" – correctly edited password

"NO" – incorrectly edited password

"OK" – the password saved (only in case of "CHANGE")

The password is automatically hidden after it is edited or changed ("00000" will appear).

To deactivate the password, edit the numerical combination "00000" in the mode "CHANGE".




The level meter with activated password will be automatically locked after 5 minutes of inactivity or after 5 min. from switching to measuring mode. Locking of level meter is indicated in the lower left corner of the screen by the letter "L".



If the password is lost, contact the manufacturer.

INFO

Information about the type, serial number and production date of the level meter (type, serial number – SN and firmware version – SW).



The display modules DM-70 with firmware version 2.0 and later are not backwards compatible with ULM-70 body with firmware versions 1.0, 1.1 and 1.2.

11. HART® COMMUNICATION PROTOCOL

Universal communication interface for data communication of peripheral devices with the level meter. Data transmission runs through the same line as the $4 \pm 20\text{mA}$ current loop without impact on analog communication.





Fig. 18: Typical hardware configuration with HART®

The device must be installed to prevent tensile overload rope electrode level meter.

10. ORDER CODE



12. ACCESSORIES

Standard – incl. in the price of the level sensor

- 1 pc of Seal (for ULM-70_02-I, 06-I)

Optional – for extra charge

- Fixing nuts G1" and G1 ½"
- Horn adapter ST-G1 and ST-G1,5

13. SAFETY, PROTECTION, COMPATIBILITY AND EXPLOSION PROOF

The level meter ULM-70 is equipped with protection against reverse polarity and output current overload.

Protection against dangerous contact is secured by low safety voltage that complies with EN 33 2000-4-41.

Electromagnetic compatibility according to EN 55022/B, EN 61326/Z1 and EN 61000-4-2 to 6.

Explosion proof of ULM-70Xi type complies with the following standards: EN 60079-0 : 2007; EN 60079-11 : 2007 ; EN 60079-26 : 2007 and examined by FTZÚ-AO 210 Ostrava - Radvanice certificate No.: FTZÚ 09 ATEX 0277X.

Special conditions for safe use ULM-70Xi:

The device is designed for connection to the isolating repeater IRU-420. When the other approved supply unit is used, whose output parameters satisfy above mentioned output parameters, it is necessary to have a galvanic separation or, if supply unit without galvanic separation is used (Zener barriers), it is necessary provide potential equalization between sensor and point of barrier earthing.

For application in zone 0 the present explosive atmospheres - mixture of air with flammable gases, vapour or mists must comply: $-20^{\circ}\text{C} < T_a < +60^{\circ}\text{C}$; $0,8 \text{ bar} < p < 1,1 \text{ bar}$

The device must be installed in such a way, to prevent mechanical damage of sensor face.

14. USE, MANIPULATION AND MAINTENANCE

The level meter does not require any personnel for its operation. Follow-up displaying device is used to inform the technological entity operating personnel on the measured substance level height during the operation.

Maintenance of this equipment consists in verification of integrity of the level meter and of the supply cable. Depending on the character of the substance measured, we recommend to verify at least once per year the clarity of the ultrasound transducer emitting field and to clean it, respectively. In case any visible defects are discovered, the manufacturer or reseller of this equipment must be contacted immediately.



It is forbidden to perform any modifications or interventions into the ULM-70 level meter without manufacturer's approval. Potential repairs must be carried out by the manufacturer or by a manufacturer authorized service organization only.

Installation, commissioning, operation and maintenance of the ULM-70 level meter has to be carried out in accordance with this instruction manual; the provisions of regulations in force regarding the installation of electrical equipment have to be adhered to.

15. MARKING OF LABELS

Level meters label data

ULM-70N-02 and **ULM-70N-06:**

Symbol of producer: logo Dinel®

Internet address: www.dinel.cz

Level meter type: ULM-70N-02-I, ULM-70N-06-I

Serial number: Ser. No.: xxxxx – (from the left: production year, serial production number)


Supply voltage: $U_i = 18 \div 36 \text{ V} =$


Output current range: $I = 4 \div 20 \text{ mA}$

Ambient temperature range: $t_a = -30 \dots +70 \text{ }^\circ\text{C}$

Protection class: IP67

Compliance mark: **CE**

Electro-waste take-back system mark: 



Level meters label data

ULM-70N-10 and **ULM-70N-20:**

Symbol of producer: logo Dinel®

Internet address: www.dinel.cz

Level meter type: ULM-70N-10-I, ULM-70N-20-I

Serial number: Ser. No.: xxxxx – (from the left: production year, serial production number)


Supply voltage: $U_i = 18 \dots 36 \text{ V} =$


Output current range: $I = 4 \div 20 \text{ mA}$

Ambient temperature range: $t_a = -30 \dots +60 \text{ }^\circ\text{C}$

Protection class: IP67

Compliance mark: **CE**

Electro-waste take-back system mark: 



Level meters label data

ULM-70Xi-02 and **ULM-70Xi-06:**

Symbol of producer: logo Dinel®

Internet address: www.dinel.cz

Level meter type: ULM-70Xi-02-I, ULM-70Xi-06-I

Serial number: Ser. No.: xxxxx – (from the left: production year, serial production number)

Output current range: $I = 4 \div 20 \text{ mA}$

Limit operating parameters: $U_i = 30 \text{ V} =$, $I_i = 132 \text{ mA}$; $P_i = 0,99 \text{ W}$; $C_i = 370 \text{ nF}$; $L_i = 0,9 \text{ mH}$

Ambient temperature range for the zone 0: $t_a = -20 \text{ to } +60 \text{ }^\circ\text{C}$

Ambient temperature range: $t_a = -30 \dots +70 \text{ }^\circ\text{C}$


Label of non-explosive device: ; Performance: II 1/2G Ex ia IIB T5

Number of certificate of intrinsically safety: FTZÚ 09 ATEX 0277X

Protection class: IP67

Compliance mark: **CE**, No. of authorized person examining control of system quality:1026

Electro-waste take-back system mark: 



Level meters label data

ULM-70Xi-10:

Symbol of producer: logo Dinel®

Internet address: www.dinel.cz

Level meter type: ULM-70Xi-10-I

Serial number: Ser. No.: xxxxx – (from the left: production year, serial production number)

Output current range: $I = 4 \div 20$ mA

Limit operating parameters: $U_i = 30$ V $\bar{=}$, $I_i = 132$ mA; $P_i = 0,99$ W; $C_i = 370$ nF; $L_i = 0,9$ mH

Ambient temperature range for the zone 0: $t_a = -20$ to $+60$ °C


Ambient temperature range: $t_a = -30$... $+60$ °C


Label of non-explosive device: ; Performance: II 1/2G Ex ia IIA T5

Number of certificate of intrinsically safety: FTZÚ 09 ATEX 0277X

Protection class: IP67

Compliance mark: , No. of authorized person examining control of system quality:1026

Electro-waste take-back system mark: 



Level meters label data

ULM-70Xi-20:

Symbol of producer: logo Dinel®

Internet address: www.dinel.cz

Level meter type: ULM-70Xi-20-I

Serial number: Ser. No.: xxxxx – (from the left: production year, serial production number)

Output current range: $I = 4 \div 20$ mA

Limit operating parameters: $U_i = 30$ V $\bar{=}$, $I_i = 132$ mA; $P_i = 0,99$ W; $C_i = 370$ nF; $L_i = 0,9$ mH

Ambient temperature range for the zone 1: $t_a = -20$ to $+60$ °C

Ambient temperature range: $t_a = -30$... $+60$ °C


Label of non-explosive device: ; Performance: II 2G Ex ia IIA T5

Number of certificate of intrinsically safety: FTZÚ 09 ATEX 0277X

Protection class: IP67


Compliance mark: , No. of authorized person examining control of system quality:1026

Electro-waste take-back system mark: 



Real label size is 70x20mm.

16. MENU STRUCTURE



17. SPECIFICATIONS

TECHNICAL SPECIFICATIONS – LEVEL METER		
Measuring range ¹⁾	ULM-70_-02	0.15 ... 2 m
	ULM-70_-06	0.25 ... 6 m
	ULM-70_-10	0.4 ... 10 m
	ULM-70_-20	0.5 ... 20 m
Adjustable measuring range (SPAN)		Min. 200 mm
Supply voltage	ULM-70N-__	18 ... 36 V DC
	ULM-70Xi-__	18 ... 30 V DC
Output		4 ... 20 mA (Limit values 3.9 ... 20.5 mA), HART®
Resolution	ULM-70_-02; 10	< 1 mm
	ULM-70_-06	< 2 mm
	ULM-70_-20	< 2.5 mm
Accuracy (within the total range)		0.15 %
Temperature error		Max. 0.04% / K
Operating frequency	ULM-70_-02	120 kHz
	ULM-70_-06	75 kHz
	ULM-70_-10	50 kHz
	ULM-70_-20	30 kHz
Beamwidth (-3 dB)	ULM-70_-02; 10	10°
	ULM-70_-06	14°
	ULM-70_-20	12°
Ambient temperature range	ULM-70_-02; 06	-30 ... +70 °C
	ULM-70_-10; 20	-30 ... +60 °C
Short-time temperature stress resistance		+90 °C / 1 hour
Max. operation overpressure (on transmission surface)		0.1 MPa
Sensitivity		3 steps (low – medium – high)
Damping		0 ... 99 s
Measuring period		1 ... 4 s
Rise time		ca. 30 s
Additional technical data for Ex proof ²⁾ – Max. internal values		U=30 VDC; I _I =132 mA; P _I =0.99 W; C _I =370 nF; L _I =0.9 mH
Failure indication (echo loss, level in dead zone ³⁾ , internal failure)		Adjustable in modes: 3.75 mA ; 22 mA ; Last measured value
Protection class		IP67
Mechanical connection	ULM-70_-02	Screwing with thread G 1"
	ULM-70_-06	Screwing with thread G 1½"
	ULM-70N-10	HDPE flange
	ULM-70Xi-10	Aluminium alloy flange
	ULM-70_-20	Aluminium alloy flange
Maximal current output load resistance (U = 24 VDC)		R _{max} = 270 Ω ⁴⁾
Weight	ULM-70_-02	0.3 kg
	ULM-70_-06	0.4 kg
	ULM-70N-10	0.7 kg
	ULM-70Xi-10	1.2 kg
	ULM-70_-20	3.1 kg

¹⁾ In case the level of bulk-solid materials is measured, the measurement range is reduced.

²⁾ Allowed temperature range in the zone 0: -20 °C ... +60 °C; allowed pressure range in the zone 0: 80 ... 110 kPa.

³⁾ Dead zone = Blind zone = Blocking distance

⁴⁾ Including 250Ω resistor in case of HART® connection.

TECHNICAL SPECIFICATIONS – DISPLAY MODULE

Display type	Matrix OLED
Resolution	128 x 64 pixel
Character height / Number of digits measured value	9 mm / 5 Digits
Display colour	Yellow
Buttons	Membrane switch panel
Ambient temperature range	-30 ... +70 °C
Weight	46 g

AREA CLASSIFICATION (according to EN 60079-10 and EN 60079-14)

ULM-70N-__	Performance for non-explosive areas
ULM-70Xi-02 ULM-70Xi-06	Explosive proof – suitable for explosive areas (combustible gases or vapours) ⊕II 1/2G Ex ia IIB T5 with Isolating repeater (IRU-420), the whole level meter – zone 1, front head part – zone 0
ULM-70Xi-10	Explosive proof – suitable for explosive areas (combustible gases or vapours) ⊕II 1/2G Ex ia IIA T5 with Isolating repeater (IRU-420), the whole level meter – zone 1, front head part – zone 0
ULM-70Xi-20	Explosive proof – suitable for explosive areas (combustible gases or vapours) ⊕II 2G Ex ia IIA T5 with Isolating repeater (IRU-420), the whole level meter – zone 1

FACTORY DEFAULT

	ULM-70_-02	ULM-70_-06	ULM-70_-10	ULM-70_-20
MIN LEVEL (Distance to min. level)	2 000	6 000	10 000	20 000
MAX LEVEL (Distance to max. level)	150	250	400	500
UNITS	mm; %; °C	mm; %; °C	mm; %; °C	mm; %; °C
DAMPING	2	5	10	10
SENSITIVITY	MEDIUM	MEDIUM	MEDIUM	MEDIUM
MEDIUM TEMPERATURE	NO	NO	NO	NO
FAILURE MODE – NO ECHO	3.75 mA	3.75 mA	3.75 mA	3.75 mA
FAILURE MODE – DEAD ZONE ¹⁾	22 mA	22 mA	22 mA	22 mA
POOLING ADDRESS (HART®)	00	00	00	00
PASSWORD	No password	No password	No password	No password

¹⁾ Dead zone = Blind zone = Blocking distance

USED SYMBOLS

To ensure maximum safety of control processes, we have defined the following safety instructions and information. Each instruction is labeled with the appropriate pictogram.



Alert, warning, danger

This symbol informs you about particularly important instructions for installation and operation of equipment or dangerous situations that may occur during the installation and operation. Not observing these instructions may cause disturbance, damage or destruction of equipment or may cause injury



Information

This symbol indicates particularly important characteristics of the device.



Note

This symbol indicates helpful additional information.

Dinel[®]

industrial electronics

Dinel, s.r.o.

U Tescomy 249
760 01 Zlín
Czech Republic

Tel.: +420 577 002 003
Fax: +420 577 002 007
E-mail: sale@dinel.cz

www.dinel.cz

This project was realised under financial support from the funds of the state budget through the "Department of Trade and Industry".

The latest version of this instruction manual can be found at www.dinel.cz

Version: 01/2012

